


Fit band

Quick Start Guide

Welcome to use the Fitband



Please make sure the clasp is installed correctly

1. Starting the Fitband



Long press the side button to start the Fitband




Fitband will display the factory default time when first startup. After you connect with your smartphone, it will sync the mobile phone time automatically.

2. Download the Fitband App


- Scan the below QR code to download and install the App from Fitband official website ;



- Search “Fitband” from App store or Google Play. Download and use the app together with your Fitband.



3. Binding the Fitband



Tips :

a. Register, connection, synchronization process need to connect to the Internet and bluetooth.



4 Start to use the Fitband

App show your connection status



Not connected



Connected


Data Sync:

Open the App, click the side button and light up the Fitband screen, then it will sync data automatically.




Introduction

- Home page



Connected



Not connected

- Daily Steps Mode



steps



Calories



Distance



Goal achievement

- Real-time Sport Mode


Click the side button to switch to the Real-time Sport page, you can record your current sports data. e.g. sport time, speed, calories.



preparing



} Start off



Current sport time



Current sport speed



Calories consumed for current sport

• **Heart rate testing Mode**

Click on the side button to switch to the Heart Rate Testing page. Do not move and wave your arm when testing.



• **Find My Phone Mode**



Click the side button to switch to Find My Phone page. The phone will have a "beep" sound so you can find it.

Tips: Find My Phone function only worked when the APP run in current or on background. Please keep connecting between Fitband and phone(Bluetooth connection range: 10 meters)


- **Sleep Mode**

Long press the side button


to enter or exit the Sleep Mode

The screen display time, date, battery level

and Bluetooth connection status.



connected , music sleeping function can be used.



not connected , music sleeping function can't be used.

After falling asleep peacefully wearing the Fitband, it can automatically record the time of your light sleep, deep sleep, dreaming and waking up as well as the heart rate curve for the whole night.



- **Sleeping music**

1. open App

(Please open the autoplay in music Setting)

2. switch to sleep mode then mobile phone will play the music automatically. When Fitband detect you fall asleep, music will change with it, until you get into deep sleep, music will stop automatically.


Tips:

1. The music is provided by your mobile device, please keep connecting between Fitband and mobile phone.

2. Music sleeping function can not only help you fall asleep easily, also can improve sleep quality. And aerobic exercise 6000 steps each day, have significant effect to improve sleep quality.

- **Smart Alarm**

Set your alarm clock and Smart sleep Alarm period



when you open the smart sleep alarm, Fitband will wake you up when you are in a light sleep in the Smart Sleep Alarms period, If you are in a deep sleep state, Fitband will vibrate in the last time.

when Fitband vibrates, click the side button to close the alarm clock.

If it is not closed, the alarm clock will vibrate twice after 5 minutes.

- **Incoming Call Reminder**


Make sure the Incoming Call Reminder function is open.

If there is a phone call, Fitband will vibrate and display the calling number.

Tip: to use this function, please keep your Fitband and phone connected.

Fitband Charge

Please charge your Fitband as below picture.





low battery reminder



Charging



Fully charged

Common problems

1.Wechat scanning cannot download it

Suggest using qr code scanning software or the qr code scanning of browser to download.

If have used wechat scanning, please select "open" in the browser, download it again.

2.one Fitband can connect to multiple mobile phone at the same time

not allowed

3.Fail to connect?

A. Please check your Mobile devices, please make sure your mobile phone system should be: iOS7.0 and above or Android4.3 and above, and with Bluetooth 4.0 (BLE).

B. Connecting process need phone to connect to the internet, keep screen light up.

4. Have done the pairing through mobile phone bluetooth , unable to connect, how to solve?

Please cancel the bluetooth pairing in mobile phone "Setting" page, and rebinding the Fitband according to "Binding the Fitband" mentioned before.

5 It is always showing "wear tight" when you test the heart rate.

Entering the App: My Fitband – Calibrate your band to check your band

6. How to clean the Fitband

- a. Please use a wet cloth (without dripping) to clean the Fitband main body.
 - b. The charging contact and the strap can be cleaned by brush or soft cloth with cleaning material or alcohol. (Do not use corrosive solvent).
- Ensure a clean and dry surface of charging contact before charging.

7. Is Fitband waterproof and suitable for bathing or swimming?

Normal life waterproof, should not be used in the sauna and steam bath.

Not suggest to use when bathing and swimming.

Precautions

1. Use the device within a temperature range of 0-40°C, and store the device and its accessories within a temperature range of -10-50°C. When the ambient temperature is too high or too low, malfunctions may occur with the device.
2. Do not place the device close to any heat source or exposed ignition source, such as electric radiators, microwave ovens, toasters, stoves, candles or other places where the temperature may be high. Do not dry the device using external heating devices such as microwave ovens or electric driers.
3. Do not let the device and its accessories be strongly shocked or vibrated in order to avoid damaging your device and its accessories, thus causing failure.
4. Do not clean the device or its accessories with harsh chemicals, cleaning agents or strong detergents. Always wipe the device and its accessories using a clean and dry soft cloth.
5. The device is equipped with a non-removable battery. Do not replace the battery by yourself in order not to damage the battery or the device.
6. Do not throw the device into a fire, otherwise ignition or explosion of the battery may result.
7. Do not discard the battery at will. Dispose it properly according to the local regulations.

8. The device and its accessories contain some small parts. The device should be placed in a place inaccessible to children in order to avoid them mistakenly swallowing the small parts and causing choking or other hazards.

9. The device is not a toy, so a child should use the device under adult supervision.

10. Do not disassemble or modify the device and its accessories, otherwise it will no longer be within the company's warranty. In case of device failure, contact us in a timely fashion.

FCC statements: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.