


SMART VIDEO DOORBELL

User Manual


Packing list

After opening it, please check whether the product is in good condition or not; confirm whether the accessories are complete as below.



Machine

Fittings:




Screws Package *2



Wooden Screw *4

Appearance introduction

Before use, please be familiar with the interface and button of the doorbell.



Notes: Long-press the RESET button for 5 seconds, loosen it when hear the voice prompt "restore factory settings, please don't power off". Then it can be restored to the factory default configuration.

Indicator Introduction

Blue light always on	Startup
Blue light flashes slowly	APP remote monitor and setup
Red light flashes slowly	Battery lower power

Operation manual

1. Device ready

First step: Install the backplane where you need to install the doorbell. (Expansion screws need to be used on cement and stone walls, wood screws or 3M glue can be used on wooden walls.)

Second step: Install the doorbell body into the backplane.

2. Download APP



iCSee

Tips one: Scan QR code to download;

Tips two: Search and download "iCSee" in the Appstore or Googleplay;


3. Device network configuration

01. User login

- Open "iCSee", sign up a new account and log in(Figure1);
- If you have Wechat, You can use " WeChat shortcut login" directly (Figure1);

02. Device preparation

After the doorbell is installed, short-press the bell button to wake the doorbell.(Figure 2)



(Figure 1)

(Figure 2)

Notes: There is voice instruction throughout the process of device configuration. After hearing the voice prompt "wait to be configured", you can start configuring the device.

03. Add device

- After login successfully, click "Add My Camera" (Figure 3), input "WiFi password" (Figure 4). Finish the network configuration of the camera according to the APP operation hint.




(Figure 3)

(Figure 4)

Notes: Add My Camera (recommended): Connect the device to the router.
 Add My Camera (AP mode): Connect the device to the router via AP mode.
 Add Shared Camera: Add a device that others share to you. Add the camera via inputting the device serial number or sharing information code or scanning device QR code.

04. Access device

- After login success, you can use the mobile phone access the device through the APP, The device has the following states:




(Figure 3)

(Figure 4)

Notes: This device does not support the AP mode and the AP hotspot stand-alone mode.
 Notes: If the configuration fails, reset the device.

05. Message push

When a visitor presses a button or an alarm is generated, the device sends a message to the phone. You can receive the message in the following two ways:




(Figure 3)

(Figure 4)

Notes: If the Mobile phone is set up to power saving mode, such as screen off & network off, it will not receive the message in time. Since android phones do not agree on the default handling of message interceptions, it is recommended to use WeChat receive message except the iPhone and Huawei phones.
 notes: The device would only send the message to the account which has the contact permission, please ensure that current account has been assigned to the contact person.

06. Bell Device Configuration

If you buy a Bell Device, you can associate the Bell Device with the Video Doorbell, and the bell device will also ring when you press the bell button.




(Figure 3)

(Figure 4)

Notes: This device does not support the AP mode and the AP hotspot stand-alone mode.
 Notes: If the configuration fails, reset the device.

07. Bell Device Configuration

First step: Long-press the volume button of the Bell Device until the indicator of the bell is no longer flashing.




(Figure 3)

(Figure 4)

Notes: This device does not support the AP mode and the AP hotspot stand-alone mode.
 Notes: If the configuration fails, reset the device.

08. Bell Device Configuration

Second step: Short-press the bell button of the Video Doorbell; if the bell is ringing at the same time, the configuration is successful.




(Figure 3)

(Figure 4)

Notes: This device does not support the AP mode and the AP hotspot stand-alone mode.
 Notes: If the configuration fails, reset the device.

09. Bell Device Configuration

Second step: Short-press the bell button of the Video Doorbell; if the bell is ringing at the same time, the configuration is successful.




(Figure 3)

(Figure 4)

Notes: This device does not support the AP mode and the AP hotspot stand-alone mode.
 Notes: If the configuration fails, reset the device.

10. Bell Device Configuration

Second step: Short-press the bell button of the Video Doorbell; if the bell is ringing at the same time, the configuration is successful.




(Figure 3)

(Figure 4)

Notes: This device does not support the AP mode and the AP hotspot stand-alone mode.
 Notes: If the configuration fails, reset the device.

11. Bell Device Configuration

Second step: Short-press the bell button of the Video Doorbell; if the bell is ringing at the same time, the configuration is successful.



(Figure 3)

(Figure 4)

Notes: This device does not support the AP mode and the AP hotspot stand-alone mode.
 Notes: If the configuration fails, reset the device.

Warranty Card

Product Name		Model	
Purchase Date		Purchase Store	
Cause			
Process			
Customer Name		Customer Gender	
Customer Phone		ZIP	
Address			

Warranty period: one year.
 This warranty card is only for our company's products.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices). This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. FCC Radiation Exposure Statement: The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FAQ

Q: Why does the device do not respond when press the RESET button after startup?

A: It needs to wait 8 seconds to press the RESET button, please wake the device startup via pressing the bell button.

Q: Why do people hover, but the doorbell did not push the alarm?

A: Alarm push may be turned off, or user login the device remotely already.

Directions

App and device firmware will have new update irregularly, you could upgrade it online at app setting, instructions are for reference only.

Notice

While using this product, please modify the user password. Do not install the device in damp, dusty, children easy access to the venue.

Please place it under the specified condition of temperature and humidity, do not disassemble it at all.

Q: How does the device store video?

A: The video doorbell supports 32GB maximum TF card, which will automatically loop recording when it's fulfilled.

Q: How to fix the problem of device offline?

A: • Check whether the device electricity is exhausted.
 • Reconfigure the device.
 • Check if the home network broadband is normal.

Q: How to switch the network environment?

A: When used in a new network environment, please long-press the RESET button for 3~5 seconds, loosen it when hear the voice prompt "restore factory settings, please don't power off". After reset successfully, configure the network again.