


YD-829 4 CH RC QUAD-COPTER (LATEST 6-AXIS FLIGHT SYSTEM / 4 WAYS FLIPS)



Suitable for 14 years old and above

MAIN PARAMETERS:

Main blade diameter:	65mm	Frame width:	240mm
Frame length:	240mm	Frame height:	84mm
Battery:	3.7V300mAh	Main motor type:	7x10 4pcs
Total weight:	73g±2g	Charge time:	About 80 minutes
Gyroscope:	Built-in	Flight time:	6-8 mins

MAIN FEATURES:

1. the 4 motors within the heli give the heli stable flight and enable it to perform the actions easily.
2. with the modularized structure, it's easy to install and convenient to repair or repair work.
3. with the 6-axis gyroscope and position control system automated, the heli can be easily stopped and accurately aloft.
4. once fully charged, the 3.7V300mAh Li-Po battery gives approximately 6-8 minutes flight time.

ANTICIPATION

Thanks for choosing ATTOP product! This is a 4-axis aircraft which is capable of flying in confined space and outdoor, in order for you to maneuver the R.C. helicopter more conveniently and easily, please fly it only after this instruction manual is carefully read, in the meantime, this manual shall be properly kept for future necessary adjustment and repair work.

Suitable for indoor or outdoor which under Grade 3 winds.

WARNING LABEL LEGEND

WARNING Mistakes made due to negligence of these operation instructions may cause property loss and severe human injury.

CAUTION Mistakes made due to negligence of operation instruction may cause danger.

DANGER Please do not fly the R.C. helicopter under any specified forbidden environment.

LI-Po battery is comparatively more dangerous than other batteries. Please make sure you read this instruction carefully and read thoroughly followed prior to using them. ATTOP shall not be responsible for any damages caused by improper operation of the battery.

The battery can only be charged by authentic ATTOP charger, otherwise it may lead to fire or explosion. Do not hit, disassemble, burn or connect them to the wrong pole. Avoid contact from metal or sharp item otherwise it may cause short circuit or fire.

Be cautious when charging the battery and make sure it is within sight and beyond the reach of children to avoid any danger. Please do not charge the battery if it becomes warm during usage. Otherwise it will inflate, deform or even cause fire which could cause property damage and personal injury.


Please dispose abandoned batteries in accordance to the law and regulation of the corresponding region to prevent pollution to the environment.

CAUTION Stay away from heat source

Most of the RC aircraft are made of PA fiber, plastic and electronic materials therefore it should stay away from heat source, sun shine to prevent deformation even damage caused by high temperature.

WARNING Not to do it alone

This product is suitable for 14 years old or above. It is not easy to learn to fly 4-axis RC heli at the beginning, try not to fly it alone and make sure with experienced adult instructing.



IMPORTANT NOTES

This RC helicopter is not a toy, though it is just a mini RC 4-axis heli. It still could be dangerous. Please fly the model RC heli according to the manual instruction and its notices. Any modification, maloperation or unfamiliarity to the heli could bring about unexpected danger or accident, please be prudent.

NOTE: For RC helicopters, neither manufacturer nor dealers is responsible for any losses caused by maloperation or improper assembly or accidents owing to abnormal abrasion or inappropriate environment. This product is suitable for 14 years old and above. Please only operate the heli in safety environment, once sold ATTOP will not hold any responsibilities for property loss and personal injury caused by maloperation, disassembly and modification.

This model RC heli requires high operation skills and is consumable. After its package is opened and the heli is flown, varying degree of abrasions occur. Malfunction or dissatisfaction brought about during usage will not be entitled to replacement nor return. In case of operation and repair instruction, please contact ATTOP and our agencies for technical support and after-sale service.

SAFETY NOTES

CAUTION R.C. model and 4-axis aircrafts are products with danger; it must be away from the crowd when flying. Misassembly, defect, poor performance of the electronic control or improper operation could lead to unexpected incident like plane damage or personal injury. Please pay attention to flight safety and make sure it is well understood that responsibility will fall on the player for accidents caused by himself.

DANGER R.C. heli is for indoor and outdoor use only, must stay away from obstacles when flying. This product is suitable for indoor and outdoor (wind scale must be under 4) use only, for indoor, please make sure it is clear of obstacles, for outdoor, stay away from crowd and pets etc. do not fly in improper environment such as areas with heat source, power line and power source etc otherwise, fire or electric shock loss of fortune or personal injury could occur due to crash, emergency landing or entangling.

DANGER Stay away from damp conditions

The interior heli consists of many precise electronic and mechanic components, therefore moisture and water must be prevented and it shall not be performed in bathroom or in rainy days to avoid breakdown of the components that may cause unexpected accident!

DANGER Use the product properly


Please do not tear apart or modify the RC heli at will and only apply authentic ATTOP components to update, replace or fix RC heli to ensure its safety. Please only maneuver it within its limit. Any illegal purpose of use concerning its safety shall be stopped.

DANGER Attention to battery

When install batteries, make sure the electric polarities are correct, do not mix new batteries with old ones. For long time storage, please take them out to prevent battery leakage.

Please dispose abandoned batteries in accordance to the laws and regulations of the corresponding region to prevent pollution to the environment.

DANGER Instruction Li-Po battery



Introduction and attention of USB charger

1. Suitable for 3.7V Li-polymer battery pack.

3. Operation steps

3. Charging statuses corresponding to LED


Step	operation	LED status	Charging status
1	Connect the USB cable to the computer	LED is in red solid on	Power on
2	Step 1 + connect the battery pin to USB cable	LED red light is off	Charging
		LED is in red solid on	Saturated

4. matters needing attention

- (1) During charging, the charger should be put in dry and ventilated place and far away from heat source and inflammable and explosive substance.
- (2) Only used to charging 2S Li-ion or Li-polymer battery pack if not, the charger or battery may be damaged.
- (3) Never leaves the charger unattended during the process of charging in order to avoid risk of accidents.
- (4) Never immediately charge your battery pack as soon as the flight is finished, or when the temperature doesn't cool down, otherwise the battery will take a risk in swelling, even a fire.
- (5) Ensure the correctness of polarity before connection the battery to charge.
- (6) Avoid drop and violence during the process of charging, drop and violence will result in internal short circuit of the battery.
- (7) For the sake of safety, please use original charging equipment and battery pack, please charge new one in time when the flying time is becoming shorter due to long time usage.
- (8) If it is returned in the charger for a long time after saturated, the battery may automatically discharge. When the charger detects that the voltage of individual cells is lower than the rated voltage, it will re-charge until saturated. Frequently charging and discharging will shorten the lifetime of your battery pack. It is advised that please out of the power and took off the battery after the charging is saturated.

5. Maintenance of battery pack

- (1) The battery pack should be put in dry and ventilated place. The storage temperature of environment is ranged from 18°C to 25°C.
- (2) Please avoid frequent charging and excessive discharging the battery pack in order to prolong its life cycle.
- (3) It is a must to maintain the battery pack before long-term storage. That is to charge the battery to the level of 50-60% saturation.
- (4) If the storage term is over 1 month, it is advised to monthly check the voltage of every cell of the battery pack. The voltage of every cell should be not less than 3V. Otherwise, please refer to the above article (3).
- (5) From the view of protection, new battery pack should be replaced before usage. That is to charge and discharge 3-5 times, but discharge is not less than the level of 70% saturation. This process will make the battery lifetime longer and voltage more stable.



7. SPECIAL TIPS BEFORE OPERATING

1. Power on the aircraft: Connecting the power of aircraft, then put the aircraft on a flat ground or table 3 sec rest.
2. Power on the remote: the remote indicator light is flashing plus the throttle to the top and back to the lowest then the remote indicator light is solid lighting that means the aircraft has suggested connected with the remote, and you can prepare for your flying action.
3. Notes when flying: Throttle down the throttle stick to the lowest position promptly if the aircraft is crashing or the rotor block down. Otherwise, the received circuit board will be damaged.

8. REMOVAL OF RADIO TRANSMITTER AND RECEIVER

STEP 1
1. Cut the ground on the surface of the battery pack.
2. Push the throttle stick to the top and back to the lowest position.
3. Turn the trimmer clockwise to the lowest position.

STEP 2
1. Push the throttle stick to the top and back to the lowest position.
2. Turn the trimmer clockwise to the lowest position.

STEP 3
1. Turn the trimmer clockwise to the lowest position.
2. Turn the trimmer clockwise to the lowest position.


STEP 4
1. Turn the trimmer clockwise to the lowest position.
2. Turn the trimmer clockwise to the lowest position.

9. FLIGHT ADJUSTMENT AND SETTING

PRIOR TO FLIGHT, PLEASE PRACTICE FIRST

Prior to flight, please practice first so as to acquaint yourself with the operations. Before it is well understood how to maneuver the flight, please do not fly the R.C. heli. Please read instruction manual and keep practicing until the basic flying skills are mastered.

1. put the R.C. heli in an open area with its tail facing the playery.
2. practice operating all the controlling sticks on the remote (see detailed operation in below picture) and repeat the practice for throttle stick, L/R turning trimmer, and F/B flying trimmer.
3. practice for flight is crucial, please keep practicing until all the operations can be done on hearing the orders for each movement without thinking.



ISSUES	CAUSE	SUGGESTIONS
1. After the battery is inserted in the heli, indicator light on receiver keeps flashing, no response to operations.	Frequency adjusting between remote and receiver not successful	Re-adjust frequency for remote and receiver (please refer to P.6 for details)
2. No response after battery is inserted in the heli.	1. check if the power for remote and receiver is on 2. check the voltage of the batteries of remote and receiver 3. contact on the poles are not good	1. open the transmitter and make sure if the battery is inserted in right position. 2. use a fully charged battery 3. reinsert the battery and confirm if the contact for the pole is o
3. Motor does not run when operating the throttle stick and the indicator light on receiver keeps flashing	Power for the Li-Poly battery is not enough	Charge the battery or replace it with a full battery
4. Main motor blade spins but heli won't fly	1. the blade has deformed 2. battery power is not enough	1. replace the main blade 2. charge the battery or replace it with a fully charged battery
5. Heli shakes a lot	1. main blade has deformed 2. main frame has deformed	1. replace the main blade 2. replace the main frame
6. Turning trimmer has been finished but heli still spins speed to the right and left does not conform	1. main blade has deformed 2. motor does not work well	1. replace main blade 2. replace main motor
7. Heli leans forward/backward	Center on the gyro is not correct.	Turn on the heli and center the climbing and diving trimmer then restart the heli
8. It won't fly after it falls down	1. motor has dropped off 2. gear has loosened	1. reinsert the motor 2. tighten the gear

AUTO FREQUENCY ADJUSTING

Pull the left stick to lower left corner and right stick to lower right corner simultaneously. After 3 seconds LED light on the UFO head will flash, meanwhile adjusting is complete you can control the quadcopter now.

MODE	ILLUSTRATION	MODE	ILLUSTRATION
Attention		Throttle	
Elevator		Rudder	


TRIMMING ON THE FLYING ACTIONS

Slowly push the throttle stick up till the heli flies off the ground. If the heli tilts, trimmer can be utilized to modify it.

1. adjustment on flying forward and backward: When the heli takes off, if it leans forward/backward, if it leans backward, turn the trimmer down if it leans forward, turn the trimmer up.
2. adjustments on level turn: When the heli takes off, if it leans to the right/left, if it leans to the right, turn the trimmer to left, if it leans to the left, turn the trimmer to right.

360° flip function operation manual

1. slowly raise the throttle stick
2. keep the UFO flying smoothly in the air
3. Press the right top button once after "Beep...", the UFO is ready to do 4-ways 360° flip. Now you can pull the right direction stick to achieve front/back, left/right side flip. The right direction stick will auto restore to the default status. Repeat above method to continue your flip fun.



FCC statement

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference that is received, including any interference that may cause undesired operation.

*RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device is acting as slave and operating in the 2.4 GHz

Ad Hoc function is supported but not able to operate on non-US frequencies. Do not use the device with the environment which below minimum -10°C or maximum over 50°C.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.