



www.1more.com



1MORE iBFree Sport Bluetooth®  
In-Ear Headphones Instruction Manual  
1MORE iBFree 蓝牙耳机用户指南

1

### Power

**Power on:**  
Press and hold the "Play" button for 3 seconds.  
The blue light will go on for 1 second.

**Power off:**  
Press and hold "Play" for 5 seconds. The red light will flash for 1 second.

### Bluetooth Pairing

The pairing mode starts automatically the first time it was turned on. The red and blue lights will flash alternately. When the headphones are on, press and hold "Play" for 3 seconds to start the pairing mode.


### Charging

The red light is on while charging. When charging is finished, the red light will turn off. A quick charge for 15 minutes supports 1 hour of music playback. A complete charge takes about 2 hours.

2

3

### In-line Control



\*The above functions may vary in different devices.

4

5

### Extra Functions

**Security Pairing:** If the pairing phone has Bluetooth prior to 3.0, please use the default security code "0000".

**Unpairing:** Press and hold Vol- and Vol+ for 5 seconds. The headphones will switch to automatic discovery mode.

**Battery/Volume Display:** Currently supports iOS only; may not support other operating systems.

**Multi-Device Connection:** When there are two phones connected to the headphones, only one of the phones will be supported.

**If Out of Wireless Connection Range:** The headphones will try to reconnect for 5 minutes. Then they will turn off automatically if not connected to any device.

### We Appreciate Your Business

We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction. If you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to [www.1more.com](http://www.1more.com) and sign up for VIP, and 1MORE will treat you like one.

6

7

### Limited Warranty

1MORE products are warranted against defects in materials and craftsmanship for a period of one year from the date of original retail purchase, when used in accordance with 1MORE's user manuals. Under this warranty, your claim can be directed to 1MORE, even if you purchased the product from an authorized third party. During the warranty period, 1MORE will, at its sole option, repair or replace the original, defective parts or issue a refund in the amount of the original purchase price. This warranty does not include resulting from accidents, or from improper use, maintenance, or repair, or from other causes that are not defects in materials or craftsmanship.

Unfortunately, from time to time, 1MORE products are sold by dealers or internet sites that are not authorized by 1MORE. In most cases, products sold by these unauthorized companies were not purchased directly from 1MORE. 1MORE products sold by unauthorized details are sometimes:

1. Purchased on a "gray" market from other countries and illegally sold in the US
2. Counterfeit products not produced by 1MORE
3. Damaged, defective, or previously used products (B-stock)
4. Products stolen from authorized dealers or other sources

Unauthorized dealers may deceive consumers by implying the product is covered by 1MORE's warranty policy. Any products sold by unauthorized dealers are not entitled to 1MORE warranty coverage. We are using our best efforts to prohibit companies from taking advantage of consumers, but these practices still exist. To ensure quality and warranty on your purchase only buy from 1MORE USA authorized retailers:

- 1MORE.com
- AMAZON USA 1MORE USA Inc. Storefront
- AMAZON CANADA 1MORE USA Inc. Storefront
- Ebay 1more-usa
- Costco Wholesale Corporation

8

9

### Tips

1. Please read this instruction manual carefully and retain for future reference.
2. Please fully charge the battery before first use.
3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity.
4. Only use chargers that are FCC (Federal Communications Commission) approved.
5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product.

### Safety Information

1. Never disassemble the headphones. There are no user-serviceable parts inside.
2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C).
3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked.
4. Do not use oil or any volatile liquid to clean this product.
5. Do not listen at high volumes for extended periods of time.
6. Do not use the headphones while operating a motor vehicle. Do not use the headphones any time it would be dangerous to be unaware of noises around you.
7. Adult supervision is required for children age 6 and under.
8. If you don't feel comfortable after wearing the headphones, please refer to an auralist for advice on whether or not in-ear headphones are suitable for you.

### FAQ

1. The headphones don't turn on.  
Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes.
2. The headphones and my device do not connect, or take a long time to connect.  
1) Check that your headphones are in the "discoverable" mode (red and blue lights flash alternately).  
2) Make sure that your headphones are not connected to other devices, and that your device is not connected to other Bluetooth devices.  
3) We recommend that you press and hold both the Vol+ and Vol- buttons simultaneously for 5 seconds. Your headphones' pairing history will be cleared and will automatically enter the "discoverable" mode. If they are still not connecting, restart your device to connect.
3. My Android device successfully connects to the headphones, but the headphones don't play music.  
After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on.
4. My Android device successfully connects to the headphones, but there is no sound from the headphones while making phone calls.  
After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on.

10

11

5. The Bluetooth connection is not stable, causing some interruptions.  
1) Try shortening the distance between your headphones and device.  
2) Avoid solid barriers in between. Please keep away from strong interference sources, such as Wi-Fi and GPRS.  
3) Please make sure the Bluetooth antenna of your device is not blocked.

6. While using third party music/video player apps, some in-line remote control functions do not match those in the manual.  
1) Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions.  
2) We recommend that you use the music/video player apps that your device has originally provided.
7. I adjusted the in-line remote control to the maximum volume, but the actual volume still sounds low.  
In different operating systems, especially some Android systems, the headphones and your device have separate volume control systems. Please adjust the volume controls on both the device and the headphones according to your preference.

Note: For more detailed product FAQs, please visit the product support section under [www.1more.com](http://www.1more.com)

### CE

Hereby, 1MORE, declares that this Radio LAN device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

### WEEE

Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household wastage. It must be collected and disposed of separately to protect the environment. Your 1MORE retailer will advise you of the correct way of disposal in your country.

### FCC

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.

12