

正面:



Downloading the App

Scan the QR code of YiSmart App below and complete the installation.

You can also download it at the App Store/Google Play searching for YiSmart.




QR code of YiSmart APP

Thank you for choosing Yi Smart Camera

Getting Started

1. Plug in the power supply cable to the Micro USB port at the camera's back side.


- Before starting the camera, make sure the Wi-Fi network access is available.



2. Wait few seconds until a yellow light starts to blink at the camera's front side.


If the yellow light does not blink, use a clip to press the reset button at the camera's back side and wait the yellow light turns on.

Insert a 8-32GB Micro SD card (CLASS-4 or above) into the device to use ...



Connecting the camera to your phone

1. Please make sure the camera is ready to be connected to your mobile phone. The yellow light at the camera's front side should blink.
2. Follow the app instructions to add the camera to your mobile phone. You can configure more cameras one by one.



背面:

Watching live video

1. Use the YiSmart App to watch live videos in your mobile phone. You can also record, save and edit images/videos.



- History Playback (Only available when Micro SD card is added-in) Capacity: 4-32GB
- Voice Monitoring
- Video recorder

- Hold to talk (press the button)
- Photograph Folder

Switching Wi-Fi Network

If you move the camera to a new location with different Wi-Fi network:

1. Press the reset button at the camera's back side with a clip and wait the yellow light turns on.
2. Connect the camera to your mobile phone through the app. Your videos stored in the TF card would not be affected.



Attention

1. Place the camera in open areas with good Wi-Fi signals and away from metal objects.
2. Avoid place the camera behind furniture, near microwave oven or in locations with cables twisted together.

Congratulations! You have completed all the Yi Smart Camera's configuration.

This device complies with Part 15 of the FCC Rules / Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radio-électrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émission par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'attention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

MPE Requirements

To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

Les antennes installées doivent être situées de façon à ce que la population ne puisse être exposée à une distance de moins de 20 cm. Installer les antennes de façon à ce que le personnel ne puisse approcher à 20 cm ou moins de la position centrale de l'antenne.

The FCC des États-Unis stipule que cet appareil doit être en tout temps éloigné d'au moins 20 cm des personnes pendant son fonctionnement.



FCC ID: 2AFIB-H1500A
MSIP-CRM-stx-H1500A