

USB Dongle User Manual



INTRODUCTION:

The USB Dongle is a Bluetooth 4.0 receiver that acts as an accessory for the scanning pen. It can be used on terminal devices such as desktop computers, notebooks, and all-in-ones to receive scan data of the scanning pen and display scan information on the display of the terminal devices.

SPECIFICATIONS:

- 1.Model Name:WBDG-01
- 2.Product Size:18.5mm*14.5mm*5.9mm
- 3.Rated Power Input: 100mW(5V)

OPERATION:

1. Open the software, insert the scanning pen, and the software interface will display the name of the scanning pen.
2. Remove the scanning pen from the terminal device.
3. Insert the USB Dongle into the terminal device, the terminal device will automatically complete the driver installation.
4. USB Dongle will automatically connects to the scanning pen, later the host computer will prompt “ connection completed”.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment

off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.