


# Owner's Manual

Company:Shenzhen Silver Star Intelligent Technology Co., Ltd

Address:Building D, Huiqing Science-park, Dafu Industrial Areas,  
Guanguang Road Guanlan Town , Baoan District ,  
Shenzhen Guangdong

## Remote Control

Xrobot's remote control works at an average distance of 10 feet. It must be pointed directly at Xrobot with no obstacle blocking its signal. Xrobot's remote has the following buttons:



**Power** - Puts Xrobot in standby mode. To put Xrobot in standby mode, the power switch on Xrobot's side is still turned ON.

**Auto** - Activates Xrobot's default cleaning mode (Robot/Auto1).

**Walls/Corners** - Activates Xrobot's Wall Track™ mode. Sets Xrobot to clean along walls and perimeters of a room.

**UV** - Turns the UV light on and off.

**Spot** - Activates Xrobot's Spiral Track™ mode. Sets Xrobot to clean using spiral, spot-cleaning movements.

**Charge** - Sends Xrobot to search for his charging station.

**Speed** - Sets Xrobot's speed to either slow, medium, or fast.

**Navigation arrows** - Guide Xrobot forward, backward, right, or left. Hold each button down to keep Xrobot moving in the desired direction; release to stop him.

**Pause** - Pauses or un-pauses Xrobot's movement.

## Sync Xrobot with his remote

If Xrobot isn't responding to your commands on the remote, you may need to resynchronize the remote with Xrobot. Follow these steps:

1. Switch Xrobot OFF by turning the power switch on Xrobot's side OFF.
2. Press and hold the PAUSE ( || ) button on the remote.
3. While holding down the PAUSE ( || ) button, turn the power switch on Xrobot's side to ON.
4. Xrobot will chirp twice to indicate that the remote has been synchronized.
5. If you do not hear Xrobot chirp, repeat the process.

## Sync Xrobot with his remote

If Xrobot isn't responding to your commands on the remote, you may need to resynchronize the remote with Xrobot. Follow these steps:

1. Switch Xrobot OFF by turning the power switch on Xrobot's side OFF.
2. Press and hold the PAUSE ( || ) button on the remote.
3. While holding down the PAUSE ( || ) button, turn the power switch on Xrobot's side to ON.
4. Xrobot will chirp twice to indicate that the remote has been synchronized.
5. If you do not hear Xrobot chirp, repeat the process.

### Labelling requirements:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Information to user:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Information to the user:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Xrobot