
Instructions for use 14⁺_{age}



E-mail: service2@dowellin.com

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate

Warnings & Precautions

 Reorient or relocate the receiving ant 		Reorient or relocate the receiving antenna
	•	Increase the separation between the equipment a
		receiver.
		Connect the agginment into an outlet on a girouis

Connect the eguipment into an outlet on a circuidifferent from that to which the receiver is conne
 Consult the dealer or an experienced radio/TV technician for help

Additional Warnings & Precautions WARNING: To reduce the risk of fire or electric shock. do not expose this apparatus to rain,moisture

- erformance of procedures other than those specified

- Baftery shall not be exposed to excessive heat such as sunshine, fire, or the like. Keep new and used batteries away from children, if the battery compartment does not close securely, stop nsing the product and keep it away from children, If you think batteries might have been swallowed or If you think batteries might have been swallowed or
- placed inside any part of the body, seek immediat

14. Headless Mode...... 15. One Key Return......

16. Trouble Shooting..... 17. Contact Us.....

CONTENTS

Package Contents......

3. Propellers Replacement.....

5. Transmitter Battery Installation......

Charging the Drone Battery......

4. Transmitter Functions......

7. Fly Safety Information......

Calibrate the Gyro......

Flight Controls.....

9. Altitude Hold.....

11. Speed Setting......

13. Flip Mode......

12. Emergency Stop.....

Take off the drone......

Setting Trim & Countering Drift.....

10. One Key Rotation/One Key Spin......

Pair the Drone.....

Specifications.....

8. Flight.....

service2@dowellin.com

Part Name	Quantity
Drone	1
2.4 GHz Transmitter	1
Additional Propellers	4
USB Charging Cable	1
Propeller Screwdriver	1
Bonus Battery	1
	Drone 2.4 GHz Transmitter Additional Propellers USB Charging Cable Propeller Screwdriver

Package contents

service2@dowellin.com

Specifications

Instructions for Use

Model: D9 Weight: 26g

Flight time: 8-10minutes Operating temperature range: 32° to 140°F (0° TO 40°C)

Dimensions:4.13"x 4.13"x 1.2"

Transmitter Operating frequency: 2.4GHz

Max transmission distance: 164-328 feet (outdoor and unobstructed) Operating temperature: 32° to 140°F (0° TO 40°C)

Flight battery Capacity: 300mAh

Voltage: 3.7V Battery type: LiPo

Energy: 1.11 Wh Charging temperature range 41° to 104°F (5° TO 40 $^{\circ}$)

Charging time:30-40mins (depending on charging power)

Propellers Replacement A1/A2

1. Using the supplied propeller screwdriver, remove the propeller, by giving it a gentle pull. 2. Install the propeller. Each propeller is marked either A1/A2 or B1/B2. Please install the propeller in the correct position as shown above. Otherwise the drone may fail to take off or fly out of control. NOTES: A1=A2, B1=B2 (Power switch indicate the right of the drone)

service2@dowellin.com


Transmitter Functions Indicator Light Fly to Left/Fly to Right Power ON/OFF Forward Trim Left Trim -(long press) Backward Trim One Key Landing — Emergency Stop (short press) One Key Calibration Headless Mode (short press) (long press) One Key Return(long press) Transmitter Installation

service2@dowellin.com

Note:Always pay close attention to battery polarity to ensure they are fitted correctly.

service2@dowellin.com

Charging the Drone Battery



be sure the drone and remote control are both powered OFF and remove the battery from the drone when charging. Charging time is approximately 30-40 minutes. Charge fully before use for best performance

Connect the battery plug to the USB charging plug. 2.Connect the USB charging cable(included) to the USB charging port on a computer or USB power

While charging, the charger light will turn OFF. When charging is complete, the light will display a red light.

1.Be sure to correctly match the plug to the charging port or damage may occur. 2.Do not charge overnight. Do not leave unattended while charging.


3. When the drone's battery is low power, the LED lights on the drone will begin blinking fast, indicates that it just have 40-60s left to fly. At this time, you need to fly it to the safe area and press down the one key landing button to land it. If you fly it till it runs out of battery it will drops out of the sky.

Li-Po Battery Disposal & Recycling Wasted Lithium-Polymer batteries must not be placed with household trash.Please contact local environmental or waste agency or the supplier of your model or your nearest Li-Po battery recycling center.

not use the drone in adverse weather conditions such as rainy, snowy, foggy and ne basic flight guidelines are import for pilots' safety and the surroundings. Please read the safety guidelines carefully.

service2@dowellin.com

• Rotating propellers can be dangerous. Do not start the motor when there are people nearby. If the motor is still spinning, always keep your hands on the transmitter.



① Power on the drone and place it on a flat surface. The lights on the drone will blink as it searches for a signal from the transmitter. Be sure head facing forward and the tail facing towards the



2) Turn on the transmitter, push the left control stick fully forward, wait for a Di to sound, then pull the stick fully rearward, and wait for a second Di, and the lights on the drone stop blinking when the transmitter and the

Calibrate the Gyro



After pairing and calibration, press down the one key

take off/landing button, the drone will fly to the height of 80cm automatically. Then you can pull the left control stick up or down to adjust the height of the drone. Press automatically. After landing, wait for the propellers to stop spinning. Power OFF the transmitter Before powering OFF the drone. This will ensure that no nals are accidentally sent by the remote, reducing the chance of injury. After this is done, it is safe to pick

3) After pairing, press the "Gyro Calibration" key.

The LED lights of the drone will blink for 2-3 seconds

When the light turns solid, calibration is completed.


after a crash, we recommend the pilot calibrate the

(To ensure a stable flight, after pairing the drone and

gyro. And please do not calibrate the gyro while flying)

up and power off the drone.

the drone will rise or fall.



Push the left control stick left or right and the
Push the right control stick left or right and the drone will rotate to the left or to the right. drone will fly to the left or to the right




If the drone keeps drifting leftwards when vering, press the right side-fly trimmer to



If the drone keeps flying backwards when hovering, press the forward trimmer to adjust


If the drone keeps flying forwards when hovering, press the backward trimmer to until it gets balanced.

service2@dowellin.com





Setting Trim & Countering Drift






adjust until it gets balance.

rim will help counter this effect and allow better control of the drone. But it will not entirely liminate it. Air currents and other factors may still cause slight drift while airbome.

service2@dowellin.com



unction meaning this drone will hover steadily During flight, altitude hold function allows you to release the throttle joystick and maintain its height, without descending to the ground.


One Key Rotation/ One Key Spin

Short press the spin button, the drone will spin in a anticlockwise direction(A). And short press again to exit the spin mode(A). Long press the spin button, the drone will spin in a circles(B). And long press

again to exit the spin mode(B). You can use the left control stick to adjust the height of the drone while

NOTE: Before you press the spin button, please make sure you fly the drone at least 8 feet away

Speed Setting



-Low: Provides smooth and predictable control of the drone. The remote will chime once to indicate the low speed setting. -Medium: The drone will move and respond faster to all control inputs. The remote will chime twice to

-High: Highest setting for maximum performance. The remote will chime three times to indicate the Note: The 3 speed modes can only be cyclically changed in this order: low speed - medium speed - service2@dowellin.com



Note: The emergency stop function can be only used in case of emergency during the flight to avoid any of damage or injury. For any reason, if you need to stop the drone, press the "Emergency Stop" button or pull the left joystick down to the lowest, the drone will stop the propellers from spinning. Be sure the ground is clear of any objects as this will command the rotor to shut down and crash land.

Before attempting a flip, be sure that there is enough clear space around the drone, ideally 9-10 ft. in all directions. It is not recommended to attempt to flip around or through any obstacles, as this may Press the **Flip button** to activate Flip Mode, then move the Right Control Stick in any direction and the drone will perform a flip in the same direction. Press the **Flip button** again to deactivate without performing a flip.




Caution: the drone will perform these maneuvers best with a fully charged battery

service2@dowellin.com



NOTE: Do not use the Headless Mode until you totally comprehend the instructions For Use. Flying in Headless Mode without sufficient experience might result in loss or damage to the device.


1. Place the drone in front of the pilot before pairing the drone to the transmitter. Make sure the head of the drone faces forward and the tail faces towards the pilot. 2. After pairing and calibration, press the Headless Mode button to enter Headless Mode function. A beep will be heard from the transmitter, indicates that drone is in headless mode. 3. Press the headless mode button again, you will hear a beep which indicates the drone exits the




It is very important that the pilot does not change the direction or orientation he or she faces, otherwise the drone and transmitter will lose connection, causing controls to not perform as Please use Headless Mode and One Key Return function after you totally comprehend these

functions; otherwise, it may result in the loss and/or damage of the drone.

One Key Return Please avoid using this feature when the drone is near to the pilot, to avoid injury.






X Wrong Track

With a press of the One Key Return button, the drone will return towards the original direction of You can rotate the right joystick in any direction to retake control of the drone and cancel the One Key Return Function. It is recommended to use the return function when headless mode is activated.

NOTE: Please use one key return function after you totally comprehend these functions: otherwise, it may result in the loss and/or damage of the drone.

service2@dowellin.com



Email: service2@dowellin.com

service2@dowellin.com

Drone does not spond to controls. Be sure the power plug are firmly connected. drone is out of range. Be sure the remote has an unobstructed line o sight to the drone. Remain within the emote's 328ft. rang Drone is difficult to Power OFF remote and (see pg.7). rone drifts while in Drone suffers from Damage to body, propellers . Repair or replace parts or other major components. as needed. echanical trouble. LED lights ON but

1. The remote-control distance will be shorten when the power of drone/transmitter is insufficient 2. When the power of drone is insufficient, the drone would have trouble taking off or unable to fly

damaged(rotor wing breakage), or it might lead to injury. you do not use the drone/transmitter for a long time.

Get Your Drone Ready



Take Off the Drone



- Hed all Warnings.
 Intended for children ages 14 and higher, Adult supervision 1s required.
 Only use attachments/accessories specified by the

- broken parts.

 Pilots are responsible for their actions and any damage caused from improper use.

 Pilots should keep the craft in sight at all times during flight. If you lose sight of the craft at any time, power down and cease flight immediately.

 Only fly in large, open areas that are free from obstacles or potential hazards, such as trees, nower

pursuant to Part 15 of the FCC Rules. These limits are lesigned to provide reasonable protection against harmfu nterference in a residential installation. This equipment

Important Safety Instructions

- Read and follow all instructions.
 Keep these instructions for future reference,
- manufacturer.


 Before flying, always check the body, rotors, and battery for any damage or obstructions.

 Battery should be free from cracks or swelling.

 Keep the rotors clear of any obstructions and body parts to avoid potential damage, and injury.

- Never leave the craft unattended while it is powered on or while the battery is charging.

- may result in personal injury.
 WARNING: Changes or modifications to this unit expressly approved by the party responsible for appliance could void the user's authority to operate
- equivaient tyoe. Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of according to state and local guidelines. They should never be disposed of in normal household waste,








Press the Speed button on the remote to change the drone's speed.

indicate the medium speed setting.

3D Flip Mode





Please make sure the pilot to stay in the same orientation as the drone head faces when the


headless mode.

O Right Track


Long Press

Flight Safety Information

Fly in Open Areas Maintain Line of Sight Fly Below 50 m







ow battery power. respond to controls.

5.Don't crash the drone from high altitude or crash it seriously, or might shorten its lifetime.

3.Please repair the drone in time when it is damaged.Don't fly the drone when it is seriously




Stay away from the rotating No Fly Zone propellers and motors.

Recharge the battery.

Please feel free to reach us at our e-mail if you need further support. We are always at your service.

4.Please remove the batteries or avoid the damage to the product caused by batteries leakage if





FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for **compliance could void the user's authority to** operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.