

User Guide

Smart Bracelet ID133Color HR



Thanks for choosing our device, please read the user guide carefully before using.

Setting

Use VeryFitPro on iOS or Android smart phone to set the wristband as follows:

Note: hardware and system of devices should meet the requirements:



iOS 8.0 & Above, Android 4.4 & Above, Support Bluetooth 4.0

1. Download VeryFitPro

Search and download

Search and download "VeryFitPro" from the Apple Store or Android App store.

Scan the QR code and download

It probably has a problem to open the link with WeChat or other scan tools, please copy the link and open it through browser.



2. Product activation and installation

The product must be activated by charging before initial use, and then charge the product to ensure normal power supply. The hand ring will automatically power on.

Take out: Pull open the strap and take out the bracelet body



Charge the battery: Insert the chip-mounted end of the bracelet body into the USB interface to activate the product by charging (be cautious not to reverse the polarity, and comply with the required voltage and current: 5V / 500mA)



Installation: Mount the bracelet body into the slot of the wrist strap.



Wear on: Adjust the length of the wrist strap until it is appropriate to wear on the wrist.




3. Touch key




Single click the touch key: Interface switch


Press and hold the touch key: Enter



4. Make sure the Bluetooth of smart phone is ON, open app VeryFitPro



When selecting the right band from the search list, please slide the screen of wristband to wake up the device and then complete connecting.



Wear the device on your wrist horizontally, about 2cm to carpal, the same method as wearing watches.


1. Wearing Method

To monitor Heart Rate more accurately, please wear the device on the upper position of your wrist and a bit tighter than usual when you are taking exercise.



3. Heart Rate Monitoring

Automatic heart rate Monitoring is ON as default, monitor Heart Rate all the day automatically.



4. Interface



Click the touch key to display successively




Note: To go back to the Data Reading Mode by clicking the touch key on the final interface of Data Reading Sub-Mode



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




Note: Alarm clock function should be turned on in App for the alarm clock to be displayed.



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode


1.2.1 Data Reading Sub-Mode



[Click the touch key] to enter the next sub-mode



Note: To go back to the Data Reading Mode by clicking the touch key on the final interface of Data Reading Sub-Mode




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



1.2.2 Sports Mode



[Press and hold the touch key for 2s] to enter the Sports Mode



[Click the touch key] to enter the next sports mode; and in case there are no other sports modes, it will go back to the time mode.



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




1.2.3 Heart Rate Mode




[Click the touch key] to enter the next sports mode; and in case there are no other sports modes, it will go back to the time mode.




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)



Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




Note: Types of Sports mode can be selected in App (App can handle 3 types of track recording sports and 11 types of other activities)




1.2.4 Sports Stop Mode




[Click the touch key] to enter the next sub-mode of "Sports Underway" [Press and hold the touch key for 2s] to enter any interface of Data Reading, press and hold 2s to exit the sports mode.




Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.




Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.



Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.




Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.



Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.




Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.




Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.



Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.



Note: The speed and distance of riding can be displayed, but App need to be connected and the riding and App needs to start at the same time.



1.2.5 Event Reminder in Sports Mode



[Click the touch key] to remove the reminder of automatic quitting from sports mode.




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.




1.2.6 Sports Stop Mode



[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)




Note: If the sports last less than 1 minute, the user will be reminded of not saving the data.




Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed




Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed



Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed



Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed



Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed



Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed




Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed



Note: If the sports last more than 1 minute, the Sports End Reminder will be displayed



1.2.7 Sports Underway Mode




[Click the touch key] to enter the sports data display mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode




Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode




Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



Note: When the memory of wrist strap is full of sports data, the user will be reminded of exiting from the Sports Mode



1.2.8 Sports Stop Mode




[Click the touch key] to quit from the reminder waiting mode




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



1.2.9 Sports Stop Mode




[Click the touch key] to accept the inaccessible sports mode for low-battery




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.




Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will occur when a user tried to start the sports mode with the battery of device is in low.



Note: The reminder will