

User Guide



Working condition for mobile







iOS 7.1 & above Android 4.4 & above Support Bluetooth 4.0

Quick Start Guide

1. Download VeryFitPro app

The smart band need to pair with the smart phone through app. Before downloading, please refer to working condition for mobile. Way to download 1: Searching the QR code, scan and download app.


Please use the QR code Scan tool to scan the following QR code and open the link and download app. In case there is any problem to open the link, please try to copy the link and open it by browser.

Way to download 2: Search in the phone market and download. Please search and download the "VeryFitPro" from App Store or Google play store.





Make sure power is working normally before initial use. In case device is under low battery, connect the device to the charger. Device will automatically boot up (please connect the USB in normal DC port (5V-500mA) for charging as below. The host should be separated from the strap when charging).



Open pair device in the app, please make sure the Bluetooth is ON when pair the device. When searching and pairing device, please long press on the screen of the device and activate the device (light on). App will search the device automatically, choose the device name and connect the device to the app.



How to Use

Key Definitions: Tap: function switch

Long Press: activate, mode switch



Once the device connected to the app successfully, it will record and analyze your activities and sleep automatically, Touch the click toggle, the display order is as follows

1. Normal Mode







Note: alarm mode and find phone will only be displayed on the screen after switch ON in the APP.

. Remote Camera Shoot Mode



Put the camera shoot ON in the APP, then device enter in remote shoot screen, control remote photograph shooting with following actions: (lift wrist sense / tap screen) to shoot a picture.

3. Sport Mode Click to exercise mode, long press to start the



Sport Step Mode Sport Distance Mode Sport Calories Mode

| MON OI 12:45 # | -> | Depart Clock Mode | Sport Clock Mode | Long press IS into the end of the movement | Sport stop Notify mode | Sport stop No

Incoming call notify 13523600 Message notify Hello~Hel Alarming notify 12:45 Am Sedentary notify

Anti-lost notify Low-power notify

Charge full notify

Notification Mode instruction:

1.Under incoming call, message notify mode, the screen will still display the last time text and sliding, when there is a new notification coming in.

2. If there is a call or message come, the device will force into call/message a mode no matter under whatever other mode, after quit, it returns to previous mo

Activities Record:

Record daily activities, you could check daily activities including steps, distance and calorie consumption in the app;

Sleep Monitoring:
Device could automatically recognize your state and monitoring the whole sleep progress with analyzing the deep sleep and light sleep hours;

Alarm alert, call alert, sedentary alert, etc. by silent vibration; Anti-Lost:
When the smart phone is beyond the Bluetooth range (5m), the device

Remote Camera Control: Operation on the screen could control remote photograph shooting

Heart Rate Monitoring: Device monitors your heart rate status and help user make suitable

Device Data Storage: The activity data will be cleared every 0:00am as a cycle, but the device itself could restore 7 days' data, after 7 days, the data will be cleared. We suggest

user to sync data with app at least one time within 7 days during use.

O Can't find device when pairing device? Please make sure the smart phone Bluetooth is ON and smart phone OS

Android 4.4 & above and iOS 7.1 & above.

Please make sure the device is near the smart phone when pairing (normal 0.5m) and among the normal Bluetooth communication distance range (within 10m). Please make sure the device is not under low battery. If there is still problem

after full charge, please contact us.

• Can't connect the device with app?

Some smart phone Bluetooth service will be abnormal when reboot. Please reboot the Bluetooth or reboot smart phone for pairing device.

O How to Restore Factory Defaults

Make sure the device is connected with app, go in the app, enter "Mine-SystemSetting" and choose "Reboot Device".

O How to update the device

Make sure the device is connected with app, go in the app "Device"-Device update", please wait some minutes before update done.

Basic Specifications

Model: ID115U HR CPU: Nordic Sensor: Kionix

HR Sensor: Silicon Labs

Host Weight: 18g Battery Type: Li-ion Polymer Battery

Battery Capacity: 45mAh

Data Sync: Bluetooth 4.0 Working Temperature: -10 'C - 45 'C Dustproof and Waterproof level: IP67

Standby: more than 7 days

Frequency bands: 2402-2480MHz Maximum output power: 3,65dBm

to the following two conditions:

This product is applied with professional Bluetooth RF signal and self

developed algorithm, the accuracy of step pedometer could be up to 95%. This device complies with Part 15 of the FCC Rules. Operation is subject

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particula installation

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Correct Disposal of this product. This marking indicates that this

product should not be dispose other household wastes throughout the EU. To prevent possible harm to the environment or human he from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental