

PHILIPS

NORELCO





Tripleheader shaver

S7000



BC





English 6

Contents

IMPORTANT SAFETY INSTRUCTIONS _____	6
General description _____	12
Introduction _____	12
What do the icons on my product handle mean? _____	13
What does the icon on my Quick Clean Pod mean? _____	15
How do I charge my product? _____	15
How do I use my product? _____	17
How do I clean my shaver? _____	23
How do I use the Quick Clean Pod? (S7885 and S7886 only) _	27
How do I connect my shaver and smartphone? (Fig. A) _____	30
How do I replace the shaving heads? _____	32
Accessories _____	34
Assistance _____	34
Disposal _____	35
Full Two-Year Warranty _____	35
45-DAY MONEY-BACK GUARANTEE _____	36
Trademarks _____	38

IMPORTANT SAFETY INSTRUCTIONS

When using an electric product, basic precautions should always be followed, including the following:

Read all instructions before using this product.

DANGER

To reduce the risk of electric shock:

- To charge the product, only use a USB power source on a certified product with output rating 5 V, ≥ 1 A. For safe charging in a moist environment (e.g. in a bathroom), only use an IPX4 (splash-proof) power source. A suitable power source (e.g. Philips HQ87) is available via www.philips.com/support. If you need support finding the correct USB power source, contact Philips support at 1-800-243-3050. Using a non-certified USB power source may cause hazards or serious injuries.
- Keep the USB cable and the USB power source dry.



- Do not reach for a corded product that has fallen into water. Unplug immediately from the power outlet.
- Do not place or store the product or charging stand where it can fall or be pulled into a tub or sink. Do not place or drop the product or charging stand into water or other liquid.
- This product does not work while it is connected to the power outlet. Except when charging, always unplug this product from the power outlet.
- Remove USB power source from power outlet and product before cleaning.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

8 English

- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Children should be supervised to ensure that they do not play with the product.
- Use this product only for its intended household use as described in this manual. Misuse can lead to hazards or serious injuries. Do not use attachments not recommended by Philips North America LLC. Accessories supplied may vary for different products.
- Never operate this product if it has a damaged USB power source, if it is not working properly, after it has been dropped or damaged, or after the product or the USB power source has been dropped into water. For assistance call 1-800-243-3050.
- Keep the USB cable and the USB power source away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use the USB power source in or near a power outlet that contains an electric air freshener to prevent damage to the USB power source.
- Do not charge or plug in product or charging stand outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Always check shaving heads (guards and cutters) before using the product. Do not use the product if cutters or guards are damaged, as injury may occur.
- Always attach the USB cable to the USB power source and the product or charging stand first, then attach the USB power source to the power outlet. To disconnect, set all controls to 'off' position. Then remove the USB power source from the power outlet.

- Plug USB power source directly into power outlet. Do not use an extension cord.
- Unplug USB power source before plugging in or unplugging the product.
- Be careful when handling your smartphone near water and in moist environments.
- Radio waves may impair the operation of pacemakers and other medical devices. Consult your physician for advice and keep the appliance at least 8 inches (20 cm) away.
- The batteries used in this product may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100 °C (212 °F) or incinerate.
- Only use original Philips accessories or consumables.
- Charge, use and store the product at a temperature between 5 °C and 35 °C.
- Keep product and batteries away from fire and do not expose them to direct sunlight or high temperatures.
- If the product becomes abnormally hot or smelly, changes color or if charging takes longer than usual, stop using and charging the product and contact Philips.
- Do not place products and their batteries in microwave ovens or on induction cookers.
- Do not open, modify, pierce, damage or dismantle the product or battery to prevent batteries from heating up or releasing toxic or hazardous substances. Do not short-circuit, overcharge or reverse charge batteries.
- If batteries are damaged or leaking, avoid contact with the skin or eyes. If this occurs, immediately rinse well with water and seek medical care.
- When you handle batteries, make sure that your hands, the product and the batteries are dry.

- To avoid accidental short-circuiting of batteries after removal, do not let battery terminals come into contact with metal objects (e.g. coins, hairpins, rings). Do not wrap batteries in aluminum foil. Tape battery terminals or put batteries in a plastic bag before you discard them.

Philips Norelco Quick Clean Pod Cartridge fluid

- Do not take internally.
- Avoid contact with the eyes. In case of eye contact, thoroughly flush with cold water. If irritation persists, get medical attention.
- Keep out of reach of children.

Electromagnetic fields (EMF)

This Philips product complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

FCC Compliance



- The frequency band in which the appliance operates is 2.4 GHz.
- This appliance is equipped with Bluetooth class 2.
- The maximum radio frequency power radiated in the frequency band in which the appliance operates is less than 20 dBm
- This device complies with the FCC RF exposure limits and has been evaluated in compliance with portable exposure condition.

Changes or modifications not expressly approved by Philips could void the users' authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful

interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- There is no limitation as to which distance can be used from the human body.

The Bluetooth® wordmark and logos are registered trademarks owned by Bluetooth SIG,

Inc. and any use of such marks by Koninklijke Philips N.V. is under license.

SAVE THESE INSTRUCTIONS

General description

- 1 Pop-up trimmer
- 2 Trimmer release slide
- 3 Shaving unit
- 4 Shaving unit release button
- 5 On/off button
- 6 Handle
- 7 Socket for small plug
- 8 Charging stand (S7885 only)
- 9 USB cable








Note: A suitable supply unit (e.g. Philips HQ87) is available via www.philips.com/support.










- 10 Small plug
- 11 Protection cap (S7887 only)
- 12 Travel case (S7885, S7886 only)
- 13 Quick Clean Pod Cartridge (S7885, S7886 only)
- 14 Quick Clean Pod (S7885, S7886 only)
- 15 Cleaning brush


Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome or via the app.


What do the icons on my product handle mean?

Icon	Behavior	Meaning
	Pulsing	The cleaning program is in progress.
	Flashing slowly when you remove the shaver from the Quick Clean Pod during the cleaning program	The cleaning program was interrupted. If you put the shaver back into the Quick Clean Pod within four seconds, the cleaning program resumes automatically.
	Flashing when you switch off the product	Clean the shaver in the Quick Clean Pod.
	Lights up continuously	The cleaning program is in progress.
	Flashing quickly when you remove the shaver from the Quick Clean Pod or press the on/off button during the cleaning program	The cleaning program was stopped. If you wish to continue, you need to restart the cleaning cycle by putting the shaver into the Quick Clean Pod and pressing the on/off button.
	Lights up	The SenseIQ technology is actively detecting your shaving behavior.
	Lights up green	The correct shaving motion (circular movements) was used.

Icon	Behavior	Meaning
	Lights up orange	Your shaving motion can be improved. See the app for details and advice.
	Lights up	Open the app. Either there is a notification waiting for you or you need to sync your shaves to prevent data loss (see 'How do I connect my shaver and smartphone? (Fig. A)').
	Flashing slowly	No connection is established between your shaver and smartphone (see 'How do I connect my shaver and smartphone? (Fig. A)').
	Flashing quickly	An error has occurred (e.g. the motor is blocked). Check the app for details.
	Flashing	The product must be disconnected from the power outlet before you can switch it on.
	Flashing when you press the on/off button	The travel lock is activated (see 'Storage and travel!').
	Lights up when you pick up the product	The number of bars lit up show the remaining battery charge.
	Bottom light flashing orange	The battery is almost empty (see 'How do I charge my product?!').
	Lights flashing in sequence	The product is charging.

Icon	Behavior	Meaning
	Lights up continuously	The product is fully charged.

What does the icon on my Quick Clean Pod mean?

Icon	Behavior	Meaning
	Becomes visible on the Quick Clean Pod	The Quick Clean Pod Cartridge needs to be replaced.

How do I charge my product?

Charge the product before you use it for the first time and when the bottom light of the battery status indicator flashes orange, indicating that the battery is almost empty.

Charging takes approx. 1 hour.


Quick Charge: After approx. 5 minutes of charging, the battery contains enough energy for one full shave.

When the product is fully charged it has a cordless operating time of up to 60 minutes.


Note: You cannot use the product while it is charging.

Warning: Keep the USB cable and the USB power source dry.

- 1 Make sure that the product is switched off.
- 2 Insert the small plug of the USB cable into the socket in the bottom of the product.



- 3** Insert the USB plug into the USB power source (not included).




- 4** Insert the USB power source into the power outlet.
- While the product is in quick charge mode, the lights of the battery status indicator light up one after the other. After approximately 5 minutes, the bottom light of the battery status indicator flashes. The battery now contains enough energy for one full shave.
 - While the product charges, first the bottom light of the battery status indicator flashes and then lights up continuously. Next the second light flashes and then lights up continuously, and so on until the product is fully charged.
 - When the product is fully charged, all three battery status indicator lights light up continuously. After approx. 30 minutes, the light goes out automatically.
- 5** After charging, remove the USB power source from the power outlet and pull the small plug out of the product.

'Unplug for use' symbol



The 'unplug for use' symbol flashes to remind you to disconnect the USB power source from the power outlet and remove the small plug from the product before you switch it on.

Charging in the charging stand (S7885 only)



- 1 Make sure that the product is switched off.
- 2 Put the small plug of the USB cable in the charging stand.
- 3 Insert the USB plug into the USB power source (not included).
- 4 Insert the USB power source into the power outlet.
- 5 Put the product in the charging stand.
- 6 After charging, remove the USB power source from the power outlet and pull the small plug out of the product.

How do I use my product?

Always check the product and all accessories before using. Do not use the product or any accessory if it is damaged, as this may cause injury. Always replace a damaged part with one of the original type.

Note: This product is waterproof. It is suitable for use in the bath or shower and for cleaning under the tap with water. For safety reasons, this product can only be used without cord.

Use this product for its intended household use as described in this manual.

For hygienic reasons, the product should only be used by one person.

SenseIQ technology

This product is equipped with SenseIQ technology which intelligently detects your beard density and shaving technique. For a better technique, you can get personalized shaving advice in the app.

You get advice in 2 ways: guided shaves in real time and synchronized shaves. We advise you to start with the guided shave to enhance your shaving experience.

- Correct handling of your product will contribute to the best shaving results.
- Follow the advice obtained from the synchronized shaves and the personalized programs.

Shaving

You can use this product either wet or dry, or even in the shower. For a wet shave, apply some water and shaving foam or gel to your skin and rinse the shaving heads under the tap with warm water before following the steps below.

- 1** Switch on the product.



- 2 Move the shaving heads over your skin in circular movements to catch all hairs growing in different directions. Make sure each shaving head is fully in contact with the skin. Exert gentle pressure for a close, comfortable shave.


Note: Do not press too hard, as this can cause skin irritation.



Note: If you are shaving with gel or foam, rinse the shaving unit regularly during your shave to ensure that it continues to glide smoothly over your skin.

- 3 Switch off and clean the product after each use.

Note: Make sure you rinse all foam or shaving gel off the product..



- 4 Use the narrow sides of the shaving unit to shave in hard-to-reach areas such as along your jawline and under your nose.

SenseIQ: When you have finished shaving you receive feedback on the handle. The Motion Control sensor icon lights up in various colors, giving you feedback on your overall shave.



- When you shave in the correct motion (circular movements), the Motion Control sensor icon lights up green.



- When your shaving motion can be improved, the Motion Control sensor icon lights up orange. See the app for details and advice.

21-Day adaptation process

- 21 Day Trial and Conversion Process. It is a fact that your skin and beard need time to adjust to a new grooming system.
- Use your new shaver exclusively for 3 weeks to fully enjoy the closeness of a Philips Norelco shave.
- At first you may not get as close a shave as you expect, or your face may even become slightly irritated. This is normal since your beard and skin will need time to adjust. Invest 3 weeks and you'll soon experience the full joy of your new shaver.
- Stick with it! If you alternate shaving methods during the adjustment period, it may make it more difficult to adapt to the Philips Norelco shaving system.
- If you are still not convinced after 21 days, Philips Norelco will refund you the full purchase price as long as the request is received within 45 days of purchase.

Cleaning reminder



When you switch off the product, the cleaning reminder flashes to remind you to clean the product.

- Clean the product and attachments after each use (see 'How do I clean my shaver?') to prevent clogging and damage.
- Clean the shaving heads thoroughly once a month or when the product does not shave as well as it used to.

Synchronize your shaves

This shaver stores your shave data so you don't need to take your smartphone with you when you shave.




When the data storage is almost full, the notification symbol flashes. To prevent data loss, synchronize the shaver with the app (see 'How do I connect my shaver and smartphone? (Fig. A)').

- 1 Make sure you are close to the shaver and open the app.
- 2 The app connects automatically and synchronizes your last shaves.

Trimming

You can use the pop-up trimmer to groom your sideburns and moustache.



- 1 Push the trimmer release slide downwards to open the trimmer.
- 2 Switch on the product.




- 3** Hold the trimmer perpendicular to the skin and move it downwards while exerting gentle pressure.
- 4** You can also use the trimmer under your nose.
- 5** Switch off the product and clean the trimmer after each use to prevent clogging and damage (see 'How do I clean my shaver?').
- 6** Close the trimmer.

Storage and travel

- Make sure the product is switched off. Remove the USB power source from power outlet and the product before storing the product in a safe, dry location where it will not be crushed, banged, or subject to damage.
- Do not wrap cord around the product when storing.
- Store cord and other accessories in a safe location where these will not be cut or damaged.
- Do not place or store the product where it can fall or be pulled into a tub or sink, water or other liquid while plugged in.

Note: We advise you to let the product and its attachments dry completely before you store them for the next use.



- Put the protection cap (S7788 and S7786 only) on the shaver to protect it.
- Store the product in the pouch (S7783 and S7782 only)
- Alternative, store the product on the charging stand (S7782 only).

Travel lock

You can lock the shaver when you are going to travel to prevent it from switching on accidentally.

Activating the travel lock

Press the on/off button for 3 seconds to use the travel lock mode.

When the travel lock is activated, the travel lock symbol flashes.



Note: Bluetooth is switched off when the travel lock is activated.

Deactivating the travel lock

Press the on/off button for 3 seconds.

Once the travel lock is deactivated, the product switches on automatically.



Note: The product unlocks automatically when connected to a power outlet.

How do I clean my shaver?

Clean the product and the attachments after each use for optimal performance.

Cleaning the shaver with water

Clean the shaver after each use to prevent clogging and damage.

Never dry the shaving unit with a towel or tissue, as this may damage the shaving heads.

While rinsing the shaving unit, water may drip out of the base of the shaver. This is a normal occurrence.



- 1 Switch on the shaver.
- 2 Rinse the shaving unit with warm water.



- 3 Switch off the shaver. Press the release button to open the shaving unit.



- 4 Rinse the hair chamber with warm water.



- 5 Rinse the shaving head holder warm water.
- 6 Carefully shake off excess water and let the shaving head holder air-dry completely.



7 Close the shaving unit.

Thorough cleaning

We advise you to clean the shaving heads thoroughly once a month or when the shaver does not shave as well as it used to.

- 1** Make sure that the appliance is switched off and disconnected from the wall socket.
- 2** Press the release button on the shaving unit and pull the shaving head holder off the shaving unit.



- 3** Rinse the hair chamber and shaving head holder with warm water.
- 4** Remove the shaving heads. For detailed instructions, see 'How do I replace the shaving heads?'.



Note: Do not clean more than one cutter and guard at a time, since they are all matching sets. If you accidentally put a cutter in the wrong shaving guard, it may take several weeks before optimal shaving performance is restored.




- 5 Clean the cutter and guard with warm water.
- 6 Shake off excess water.
- 7 Put the shaving heads back into the shaving unit. For detailed instructions, see 'How do I replace the shaving heads?'
- 8 Insert the hinge of the shaving head holder into the slot in the top of the shaving unit and close the shaving unit.


Cleaning the pop-up trimmer

Clean the trimmer after each use to prevent clogging and damage.

Never dry the trimmer teeth with a towel or tissue, as this may damage the trimmer teeth.




- 1 Make sure that the appliance is switched off and disconnected from the wall socket.
- 2 Push the trimmer release slide down to open the pop-up trimmer.
- 3 Switch on the appliance and rinse the pop-up trimmer with warm water.
- 4 After cleaning, switch off the appliance.
- 5 Carefully shake off excess water and let the pop-up trimmer air dry.
- 6 Close the trimmer.




Tip: For optimal performance, lubricate the teeth of the pop-up trimmer with a drop of mineral oil every six months (oil not included).

How do I use the Quick Clean Pod? (S7885 and S7886 only)


Preparing the Quick Clean Pod for use




- 1 Twist and remove the top of the Quick Clean Pod.




- 2 Twist the lid off of the Quick Clean Pod Cartridge.




- 3 Lift the tab on the seal and pull it by the corner to remove the seal from the Quick Clean Pod Cartridge.



- 4 Press the small circular piece on the handle of the Quick Clean Pod Cartridge to break the snap hook on the handle.



- 5 Place the Quick Clean Pod Cartridge into the Quick Clean Pod.




- 6 Put the top of the Quick Clean Pod back onto the base and turn it clockwise until you hear a click.



Do not tilt the Quick Clean Pod to prevent leakage.


Using the Quick Clean Pod

Note: If you use the shaver with shaving foam, shaving gel or pre-shave products, thoroughly rinse the shaving heads before you use the Quick Clean Pod (see 'How do I clean my shaver?').



Always shake excess water off the shaver before you place it in the Quick Clean Pod.

- 1 Place the shaver upside down into the Quick Clean Pod. The shaver automatically detects that it is in the Quick Clean Pod.
- 2 Switch on the shaver to start the cleaning program.



Each cleaning program takes approximately one minute. During the cleaning program the cleaning symbol lights up continuously and the blue icon pulses.

The shaver handle vibrates twice quickly when the cleaning program is finished.


- 3 Let the shaver air-dry completely in the Quick Clean Pod before storing it.

Replacing the Quick Clean Pod Cartridge




Replace the Quick Clean Pod Cartridge immediately when the cartridge replacement icon on the Quick Clean Pod becomes visible or follow the table below.

Frequency of use	Cycles	When to replace the Quick Clean Pod Cartridge
Every day	About 30	Every month
A few times per week	About 20	Every 2 months
Every week	About 13	Every 3 months



- 1 Twist and remove the top of the Quick Clean Pod.



- 2 Lift the Quick Clean Pod Cartridge out of the Quick Clean Pod by the handle.



- 3 Pour any remaining fluid down a drain and recycle the empty cartridge in accordance with local waste regulations.



- 4 Place a new Quick Clean Pod Cartridge into the Quick Clean Pod (see 'Preparing the Quick Clean Pod for use').

Scan the QR code to the left or visit www.philips.com/cleaning-cartridge to order replacement Quick Clean Pod Cartridges.


How do I connect my shaver and smartphone? (Fig. A)

Note: Make sure your smartphone is equipped with **Bluetooth®** 4.1 or higher.

This shaver is compatible with **Bluetooth®** 4.1 and higher to connect to the app. When you have paired your shaver and smartphone, Bluetooth on your shaver is switched on automatically, even when the shaver is switched off. This allows your shave data to be synced later so you don't need to take your smartphone with you when you shave.



The first few times you switch on the shaver, the notification symbol flashes if no connection is established with a smartphone.



You can switch off Bluetooth on your shaver by activating the travel lock (see 'Storage and travel').

Pair the shaver and smartphone

You can use the app to synchronize your shave data, change your personal settings and get routine-based coaching.



The app is compatible with a wide range of iPhone and Android™ smartphones.

More information is available at

www.philips.com.

- 1 Download the app.
- 2 Make sure Bluetooth on your smartphone is switched on.



- 3 Switch on the shaver.
- 4 Open the app and follow the instructions to start the pairing process.
- 5 Once paired, the shaver and app connect automatically when the app is open and Bluetooth on your phone is switched on.

Notification symbol



The shaver is equipped with a notification symbol. The notification symbol lights up when there is an important message for you in the app. When it lights up, simply open the app on your smartphone and follow the easy tips that the app gives you. If you need further support, visit www.philips.com/support.

Unpair the shaver and smartphone

You can pair your shaver with only one smartphone at a time. To unpair your shaver from your smartphone (e.g. when you get a new smartphone), follow these steps:

Unpair the shaver: press and hold the on/off button on the handle for approx. 10 seconds to remove the bond between shaver and app.

Note: Unpairing is successful when the notification symbol lights up 4 times briefly.



Unpair your smartphone:

- 1 Go to the settings on your smartphone and select Bluetooth.
- 2 Tap on the name of the shaver.
- 3 Tap 'forget' or 'unpair'.

Note: The unpairing procedure may vary by smartphone. Please check your smartphone manual for more information.

How do I replace the shaving heads?


For maximum shaving performance, replace the shaving heads once a year. Replace damaged shaving heads immediately.

Always replace the shaving heads with original Philips Norelco shaving heads (see 'Accessories').


Replacing the shaving heads



- 1 Switch off the shaver.
- 2 Press the release button on the shaving unit and pull the shaving head holder off the shaving unit.



- 3 Turn the retaining rings counterclockwise and remove them. Place them aside in a safe place.




- 4 Remove the shaving heads from the shaving head holder.


Discard the used shaving heads immediately to avoid mixing them with the new shaving heads.




- 5 Place new shaving heads in the holder.




- 6 Place the retaining rings back onto the shaving heads and turn them clockwise to reattach the retaining rings.



- Each retaining ring has two recesses that fit exactly into the projections of the shaving head holder. Turn the ring clockwise until you hear a click to indicate that the ring is fixed.



Note: Hold the shaving head holder in your hand when you reinsert the shaving heads and reattach the retaining rings. Do not place the shaving head holder on a surface, as this may cause damage to the shaving heads.



- 7 Insert the hinge of the shaving head holder into the slot in the top of the shaving unit and close the shaving unit.

Accessories



Replacement parts and accessories may be purchased at a store near you or on our website www.philips.com/store.

The following accessories and spare parts are available:

- SH91 Philips Norelco replacement shaving heads
- CC12 Philips Norelco Quick Clean Pod Cartridge 2-pack

Assistance

For assistance, visit our website:

www.philips.com/support or call toll free 1-800-243-3050.

Online information is available 24 hours a day, 7 days a week.

Disposal



- This product contains a rechargeable lithium-ion battery which must be disposed of properly.
- Contact your local town or city officials for battery disposal information. You can also call 1-800-822-8837 or visit **www.call2recycle.org** for battery drop-off locations.
- For assistance, visit our website **www.philips.com/support** or call 1-800-243-3050 toll free.
- Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. For recycling information, please contact your local waste management facilities or visit **www.recycle.philips.com**.

Full Two-Year Warranty

Philips North America LLC warrants this new product (except shaving heads) against defects in materials or workmanship for a period of two years from the date of purchase, and agrees to repair or replace any defective product without charge.

IMPORTANT: This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any

attachment not provided with the product or loss of parts or subjecting the product to any but the specified voltage or batteries.*

NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

In order to obtain warranty service, simply go to **www.philips.com/support**. It is suggested that for your protection you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty.

NOTE: No other warranty, written or oral, is authorized by Philips North America LLC.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion and limitations may not apply to you.

*Read enclosed instructions carefully.

45-DAY MONEY-BACK GUARANTEE

To enjoy the closest and most comfortable shave from your new Philips Norelco Men's Shaver, the shaver should be used exclusively for 3 weeks. This allows your hair and skin enough time to adapt to the Philips Norelco Shaving System. If, after that period of time, you are not fully satisfied with your Philips Norelco Men's Shaver, send the product back along with dated sales

receipt and we'll refund you the full purchase price.

The product must be shipped prepaid by insured mail, insurance prepaid, have the original sales receipt, indicating purchase price and date of purchase, and the money-back guarantee return authorization form enclosed.

We cannot be responsible for lost mail.

The product must be postmarked no later than 45 days after the date of purchase. Philips reserves the right to verify the purchase price of the product and limit refunds not to exceed suggested retail price.

To obtain money-back guarantee service, please go to www.PhilipsMoneyBack.com.

Delivery of refund check will occur 6–8 weeks after receipt of returned product.

Supplier's Declaration of Conformity



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

We, PHILIPS CONSUMER LIFESTYLE B.V., hereby declare that the equipment bearing the model name specified below was tested conforming to the applicable FCC Rules under the most accurate measurement standards possible, and that all the necessary steps have been taken and are in force

to assure that production units of the same equipment will continue to comply with the Commissions requirements.

Unique Identifier: PHILIPS, NORELCO S7788, S7786, S7783, S7782

Responsible Party – U.S. Contact Information
Philips North America LLC

P.O. Box 10313

Stamford | CT 06904

1-800-243-3050

Trademarks

Apple, the Apple logo, iPad, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android is a trademark of Google Inc. Google Play and the Google Play logo are trademarks of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Philips Personal Care is under license.

Manufactured for:
Philips Personal Health
a division of Philips North America LLC
P.O. Box 10313, Stamford, CT 06904



This symbol on the product's nameplate means it is listed
by Underwriters' Laboratories, Inc.

Norelco and Tripleheader are registered trademarks of Philips North
America LLC.

PHILIPS and Philips shield are registered trademarks of Koninklijke
Philips N.V.

©2022 Philips North America LLC. All rights reserved.

3000.089.3324.1 (04/14/2022)



>75 % recycled paper
>75 % papier recyclé