

Contents

- Packing List
- Get to Know TransMount Image Transmission Transmitter
- Preparing and Charging the Battery
- Installation
- Install on ZHIYUN Stabilizer and Connect Cables
- Install on Other Devices and Connect Cables
- How to Use
- Indicators and Buttons
- Download APP
- Use with ZHIYUN Stabilizer
- Use with Other Devices
- Firmware Update
- Product Specifications
- Disclaimer and Warnings
- Reading Tips
- Warnings
- Safe Operation Guidelines
- Warranty Terms
- Warranty Period
- This Warranty does not apply to the followings
- Warranty Claim Procedure
- Contact Card

TransMount Image Transmission Transmitter




User Guide

FCC ID:2A1HFZYCOV01


User Guide

Packing List

The product package comes with the following items. In case any item is found missing, please contact ZHIYUN or your local selling agent.



Get to Know Image Transmission Transmitter




- Antenna
- Micro USB Charging/Communication Port
- Light Indicator
- Power Button
- Mounting Plate Slot
- Safety Lock
- HDMI Input
- Camera Control Port

1 Zhiyun-tech.com

Preparing and Charging the Batteries

TransMount Image Transmission Transmitter adopts built-in battery. When using the transmitter for the first time, please fully charge the transmitter to activate the battery. Charging method: Connect the transmitter to the adapter (not provided, 5V1A is recommended) with provided Micro USB cable. Plug the adapter into a power outlet to start charging. When the blue light indicator stops, the charging is completed.




It is recommended to fully charge the transmitter each time before use. If the battery level is too low, the performance will be affected.


Installation

Install on ZHIYUN Stabilizer and Connect Cables


1. To install the transmitter on WEEBILL-S, for example. Take out Transmitter Mounting Plate, two screws and the wrench. Install the plate to the bottom of Quick Release Mounting Plate (be aware of the direction). Use the wrench to fix the screws.



2. Slide the transmitter to the mounting plate. Push the transmitter towards the tilt axis motor and fix it with the safety lock. Rotate the antenna 270 degrees clockwise. The installation is completed.



The antenna can only be rotated in one direction. The maximum rotation angle is 270 degrees. Please notice the rotation direction.




2 Zhiyun-tech.com

User Guide


Preparing and Charging the Batteries

3. Connect the camera control port on the tilt axis and the Micro USB charging/communication port of transmitter with ZW-Micro-002 cable.




This cable is for communication between stabilizer and transmitter. After connection, the stabilizer will automatically charge the transmitter, thus the runtime of stabilizer will be affected.

4. Connect the camera USB port and the camera control port of transmitter with corresponding camera control cable. Connect the camera HDMI port and HDMI input of transmitter with corresponding HDMI cable (not provided).



Camera control cables should be plugged in Micro USB port of transmitter except for Sony camera control cable.




Connect and disconnect the cables when the stabilizer and transmitter are turned off. The cables marked red in the above steps are for instructions. The actual color of all cables is black.

Balance the stabilizer after installing the device. For balance and adjustment, please refer to the stabilizer user manual.

Install on Other Devices and Connect Cables

1. To install the transmitter on camera hotshoe, for example. Install the transmitter mounting plate (be aware of the direction) on hotshoe adapter (not provided). Tighten the screws.




3 Zhiyun-tech.com

User Guide

Preparing and Charging the Batteries

2. Slide the transmitter to the mounting plate. Push the transmitter and fix it with the safety lock. Rotate the antenna 90 degrees anti-clockwise. The installation is completed.





To charge the transmitter, you can connect the Micro USB charging/communication port with power bank and power adapter with provided Micro USB cable. Recommended power output: 5V1A.

This chart is to demonstrate cable collocation example. Please check TransMount Image Transmission Transmitter Compatibility List for full details.

Control cable type	ZW-Micro-002	ZW-Mini-002	LN-MBUC-B01	LN-MCUS-A03
Camera port type	Micro USB	Mini USB	Type-C	Multi USB
Camera brand and model	Nikon D850 SD Mark IV	Canon 6D Mark II	Parasonic Nikon EOS R GH5 Z6	Sony A7RM3

How to Use

- Power Button [O]
- Long press for 3 seconds to power on or off the transmitter.
- After power on, Press the button for five times to restore factory defaults.
- Blue Light Indicator [●]
 - Shines solid when charging
 - Stops shining when fully charged
- Green Light Indicator [●]
 - Shines solid when turning on or WiFi is working normally.
 - Blinks slow when WiFi is not ready.
 - Blinks fast when turning off.
- Red Light Indicator [●]
 - Shines solid when no HDMI signal input after connecting HDMI cable.
 - Blinks slow when the battery level is low, around 5%-20%.




4 Zhiyun-tech.com

User Guide

Preparing and Charging the Batteries

3. Connect the camera control port of transmitter and camera USB port with corresponding camera control cable. Connect the camera HDMI port and HDMI input of transmitter with corresponding HDMI cable (not provided).





To charge the transmitter, you can connect the Micro USB charging/communication port with power bank and power adapter with provided Micro USB cable. Recommended power output: 5V1A.

This chart is to demonstrate cable collocation example. Please check TransMount Image Transmission Transmitter Compatibility List for full details.

Control cable type	ZW-Micro-002	ZW-Mini-002	LN-MBUC-B01	LN-MCUS-A03
Camera port type	Micro USB	Mini USB	Type-C	Multi USB
Camera brand and model	Nikon D850 SD Mark IV	Canon 6D Mark II	Parasonic Nikon EOS R GH5 Z6	Sony A7RM3

How to Use

- Power Button [O]
- Long press for 3 seconds to power on or off the transmitter.
- After power on, Press the button for five times to restore factory defaults.
- Blue Light Indicator [●]
 - Shines solid when charging
 - Stops shining when fully charged
- Green Light Indicator [●]
 - Shines solid when turning on or WiFi is working normally.
 - Blinks slow when WiFi is not ready.
 - Blinks fast when turning off.
- Red Light Indicator [●]
 - Shines solid when no HDMI signal input after connecting HDMI cable.
 - Blinks slow when the battery level is low, around 5%-20%.




5 Zhiyun-tech.com

User Guide

Preparing and Charging the Batteries

2. Slide the transmitter to the mounting plate. Push the transmitter and fix it with the safety lock. Rotate the antenna 90 degrees anti-clockwise. The installation is completed.





To charge the transmitter, you can connect the Micro USB charging/communication port with power bank and power adapter with provided Micro USB cable. Recommended power output: 5V1A.

This chart is to demonstrate cable collocation example. Please check TransMount Image Transmission Transmitter Compatibility List for full details.

Control cable type	ZW-Micro-002	ZW-Mini-002	LN-MBUC-B01	LN-MCUS-A03
Camera port type	Micro USB	Mini USB	Type-C	Multi USB
Camera brand and model	Nikon D850 SD Mark IV	Canon 6D Mark II	Parasonic Nikon EOS R GH5 Z6	Sony A7RM3

How to Use

- Power Button [O]
- Long press for 3 seconds to power on or off the transmitter.
- After power on, Press the button for five times to restore factory defaults.
- Blue Light Indicator [●]
 - Shines solid when charging
 - Stops shining when fully charged
- Green Light Indicator [●]
 - Shines solid when turning on or WiFi is working normally.
 - Blinks slow when WiFi is not ready.
 - Blinks fast when turning off.
- Red Light Indicator [●]
 - Shines solid when no HDMI signal input after connecting HDMI cable.
 - Blinks slow when the battery level is low, around 5%-20%.




6 Zhiyun-tech.com

User Guide

Preparing and Charging the Batteries

3. Connect the camera control port of transmitter and camera USB port with corresponding camera control cable. Connect the camera HDMI port and HDMI input of transmitter with corresponding HDMI cable (not provided).




To charge the transmitter, you can connect the Micro USB charging/communication port with power bank and power adapter with provided Micro USB cable. Recommended power output: 5V1A.

This chart is to demonstrate cable collocation example. Please check TransMount Image Transmission Transmitter Compatibility List for full details.

Control cable type	ZW-Micro-002	ZW-Mini-002	LN-MBUC-B01	LN-MCUS-A03
Camera port type	Micro USB	Mini USB	Type-C	Multi USB
Camera brand and model	Nikon D850 SD Mark IV	Canon 6D Mark II	Parasonic Nikon EOS R GH5 Z6	Sony A7RM3

How to Use

- Power Button [O]
- Long press for 3 seconds to power on or off the transmitter.
- After power on, Press the button for five times to restore factory defaults.
- Blue Light Indicator [●]
 - Shines solid when charging
 - Stops shining when fully charged
- Green Light Indicator [●]
 - Shines solid when turning on or WiFi is working normally.
 - Blinks slow when WiFi is not ready.
 - Blinks fast when turning off.
- Red Light Indicator [●]
 - Shines solid when no HDMI signal input after connecting HDMI cable.
 - Blinks slow when the battery level is low, around 5%-20%.



7 Zhiyun-tech.com

Warranty Card

Warranty Claim Procedure

1. If failure or any problem occurs to your product after purchase, please contact a local agent for assistance, or you can always contact ZHIYUN's customer service through email at SERVICE@ZHIYUN-TECH.COM or website at WWW.ZHIYUNTECH.COM.
2. Your local agent or ZHIYUN's customer service will guide you through the whole service procedure regarding any product issue or problem you have encountered. ZHIYUN reserves the right to reexamine damaged or returned products.

Warranty Card

Product model: COV-01

Customer Name: _____ Contact No: _____

Address: _____

Sales Information

Sales Date: _____ Prod. Serial No: _____

Dealer: _____

Contact No: _____


#1 Maintenance Record

Service Date: _____ Signature of Repairman: _____

Cause of Problem: _____

Service Result: Solved Unsolved Refunded (Replaced)

Contact Card



Tel: +86 (0) 773-3561275
 USA Hotline: +1 800-319-6137 9:00-18:00 GMT+7 Mon-Fri
 Europe Hotline: +49 (0)101 8152 10:00-17:00 GMT+1
 Mon-Fri
 Email: service@zhiyun-tech.com
 Website: www.zhiyun-tech.com
 Address: 20th Floor, Building 13, Creative Industrial Park, Guimo
 Gulin, Zhushan Information Technology Co., Ltd.
 Gulin Zhushan Information Technology Co., Ltd.
 Please download the latest version from www.zhiyun-tech.com
 This document is subject to change without notice.
 ZHIYUN™ is a trademark of ZHESHEN.
 Copyright © 2019 ZHESHEN. All rights reserved.

8 Zhiyun-tech.com

FCC statements:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types COV-01(FCC ID: 2A1HFZYCOV01) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use when properly worn on the body is 1.169 W/kg. Simultaneous RF exposure is 1.557W/Kg.

. This device was tested for typical body-worn operations with the back of the handset kept 5mm from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 5mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.