Content

Content		.1
1 Introdu	ction	.3
1.1	Acknowledgement	.3
1.2	Announcements	.3
1.3	Safety Instruction	.3
1.4	Abbreviation/Terminology	.4
2 MID In	troduction	.6
2.1 N	MID Operation and Preparation	.6
2.2	MID Status and Reminder	.6
3 Quick S	Start Guide	.7
3.1	Keys Function	.7
3.2	Startup and Shutdown	.7
3.3	Open and Close of the Screen	.7
3.4	Usage of Touch Screen	.8
3.5	Home Page	.9
3.6	Visit Application Procedures	3
3.7	USB Connection	4
3.8	Typing words	4
3.9	Operation Technique	5
3.10	Quick Setting	6
4 Basic S	etting	17
4.1	Network and Internet	7
4.2	Bluetooth	22
4.3	Apps & notification	24
4.4	Battery	25
4.5	Display	26
4.6	Sound	27
4.7	Storage	28
4.8	Security&location	28
4.9	Users & accounts	29
4.10	Accessibility	30
4.11	System	30
5 Multi-M	Iedia	35
5.1	Music	35
5.2	Photo Gallery	36
5.3	Camera	37
6 Internet		18
6.1	Browser	18
6.2	Email	19
7 other ch	naracteristics	1

7.1 SmartTextSelection	41			
7.2 Auto-Fill	42			
Other Application Procedures	42			
8.1 Clock	42			
8.2 Calculator	42			
8.3 File Manager	43			
Recorder	44			
0 Installation of Procedures	57			
10.1 Installation	57			
10.2 Uninstall	57			
1 Troubles Shooting				

1 Introduction

1.1 Acknowledgement

Thanks for your purchase of our product Koral 8W2, is a 8inches high clear board computer. Its CPU is RK3326, it is based on Android 9.0 operation system, and easy to expand the third application procedure.

The product is designed with various functions, including WIFI, BT and so on. There are many sensors which offer you brand-new operation and entertainment; besides, it has camera shooting, which leads electronic consumption to enter into a fresh palm internet entertainment time.

The manual systemically introduces the functions, use techniques and announcements, please read this manual carefully before your operation.

1.2 Announcements

Preventive maintenance

- Please always keep the MID dry. To avoid the device short trouble, corrosion fault and electric short, please prevent the device, battery and charger from water and moisture, and don't operate the device or charger by wet hand.
- To avoid failure of device, battery and charger, please prevent the device, battery, charger from violent shock or shake.
- To avoid failure of device, battery and charger, please prevent the device, battery, charger of all over heating or too cold circumstance
- Never shock, throw, prod the MID, or drop, extrude, bend the MID.
- Never disassemble the device and accessories arbitrarily, otherwise the device and accessories are not in our company warranty scope.

1.3 Safety Instruction

Before the operation of the MID, please read this chapter and teach your kids about these information. For further details, please refer to the safety instructions and announcement.

• Never use the MID when driving car, in order to ensure safe driving.

- In the medical area, please abide by related rules and regulations. Please shut down the MID when it is near to the medical area.
- To avoid the wireless signal to interrupt the plane- controlled signal, please shut down the MID or using airplane mode when you are boarding a flight,
- To avoid electronic equipment failure, please shut down the MID in the vicinage of high-accuracy electronic equipments.
- Please don't disassemble the MID and accessories. Only authorized agent has access to service the MID.
- Please keep the MID far away from magnetic equipments, the radiation of MID may erase the data stored in the magnetic equipments.
- Never use the MID in the vicinage of high temperature, inflammable gas (gas station).
- Protect the MID and accessories from kids reach scope, and avoid the kids to use the MID without parents' supervision.
- Please comply with related rules and regulations, and respect others' privacy and legal rights while using the MID.
- Please strictly adhere to related instructions in the manual when using USB cable to ensure the safety of the MID or PC.
- Never use the MID in bathroom or other humid environment, and please protect the MID from liquid wash or wet.

1.4 Abbreviation/Terminology

Abbreviation/Terminology	Full Name	Description
MID	Mobile Internet Device	Mobile Internet Terminal
WIFI	Wireless Fidelity	Base on IEEE 802.11b\g\n standard wireless LAN
ΤF	TransFlash	Alternative name Micro SD, super miniature memory card

2 MID Introduction

2.1 MID Operation and Preparation

Battery Charging

If this navigator is first used, please use AV adaptor to fully charge it.

1. Apply the power adaptor to charge for MID.

2.2MID Status and Reminder

Reminder icons

When some remind message appears in your reminder window, please click column and slip the screen to open the reminder list. Choose the menu you need, and confirm the information. Then you can close the reminder window through clicking the column to slide up. Please refer to below status icons:

@	New email	¥	Airplane Mode on
\bigcirc	USB connected	\bigcirc	USB debugging connected
\Diamond	Return button		Downloading
	Display recently-used application	0	Home button
Ω.	Current electric volume.	►	WIFI connected, internet is available

Reminder board

Reminder icons will work while receiving emails, WIFI is open, you can open the reminder board to view the detailed information.

Open the reminder board

When the reminder column shows new reminder icon, please hold the column and slip down your finger, then the reminder board is opened.

3 Quick Start Guide

3.1 Keys Function

Keys Function Description:

Power button	Short press to sleep/wake up, long press to startup and
	shutdown.
Volume + (up)	increase the volume
Volume - (down)	decrease the volume
HOME button (home)	Click it in any interface will return to main interface.
Back button (back)	click it in any interface will return to previous menu
Menu button	This button will display in menu interface.
Setting button	display recently browsed history; double click this button, you can switch between the last two applications

3.2 Startup and Shutdown

Startup

Long press **POWER key for three seconds,** you can enter into startup picture. The system enters into screen lock status, please unlock it.

Shutdown

- 1. Long press POWER, it will popup shutdown window.
- 2. Shutdown window contains power off, restart and screenshot mode three options.
- 3. Click screenshot is the last step.

3.3 Open and Close of the Screen

Screen will be closed on its own when no operation happens.

- 1. Screen will be closed on its own if no operation happens for some time to save battery power
- 2. When screen is open, press POWER key, the screen will be closed immediately.

Open the screen when it is closed.

If the screen is closed, short press POWER to open the screen. The screen will be locked open it, it will show the picture as below picture, left slide to unlock and enter into camera, right slide the unlock icon and enter into Voice Search, upward slide unlock the screen.



Picture 3.3-1

3.4 Usage of Touch Screen

MID operating methods

There are below methods to view the main screen, menu and application procedure in your MID.

Click

When you want to use the screen keyboard typing or choose application in the main interface, you only need to touch it by your finger.

Press on

If you want to open some item(textbox or the link in the webpage), or shortcut and main procedure move, you can press on this item.

Quickly slide or slide indicates

Quickly slide or slide indicates make quick vertical or horizon movement by finger.

Pull


Before you pull, you need to hold the it with strength until you pull it into the position you want.

Rotate

For most pictures, you only need to rotate the MID sidewise to change the screen direction from horizon to vertical. For instance, when you are typing words, and watching movies.

3.5 Home Page


Main interface as below picture 3.5-1, long press the blank and it will popup windows to set wallpaper, folder, widgets, and shortcut.



The extended home page

The home page can be extended beyond the wideness of screen to provide more space, which you can put new-added shortcuts and widgets. Click the blank space in home page then slide right or left to extend to the right or left of the screen. In the home page, there are two extended pictures, as Picture 3.5-2.

9




Picture 3.5-2

The shortcut icons management in desktop application.

Create folder icon in desktop


1. Drag the icons need to be put together on one icon(can also overlay several icons)as Picture 3.5-3.



Picture 3.5-3

2. Then click the overlaid icons, the applications can be folded, as Picture 3.5-4.

Click the unnamed folder in the black box, it will popup the hidden keyboard, the folder name can be renamed (this is similar with Apple IOS system), the icons position can be changed through long press.



Picture 3.5-4

3. Long press to enter the home screen settings, as Picture 3.5-5. you can set different application icon shapes, such as square, squircle, circle, teardrop as Picture 3.5-6



Picture 3.5-5

				🖨 マ 🖹 🛔 3:40 am
Home settings				
Add icon to Home screen For new apps				•
Change icon shape Use system default			_	
	Change icon shape	e		
	Ose system de	fault		
	O Square			
	O Squircle			
	O Circle			
	O Teardrop			
			CANCEL	
	4	0	D	

Picture 3.5-6

Remove the icons in desktop

1. Long press the icons need to be remove, then on the right above of the screen, it




2. Drag the icon to the above of the remove icon, till the icon become red, then move your finger to delete the icon.

Change the wallpaper of desktop

- 1. In home page, long press any blank space in main screen, it will popup a window to change the wallpaper.
- 2. Click the gallery or wallpaper gallery to select the wallpaper.


3.6 Visit Application Procedures

Click in right top of Picture 3.5-1, enter into main interface as Picture 3.6-1, choose the application procedure you want to visit.



PinnedShortcuts

If you press an application software, you can pop-up the sub menu, and then you can use this way to use some functions of the application quickly as Picture 3.6-2



Picture 3.6-2

3.7 USB Connection

MID storage configuration

Before transmitting documents, you have to conduct storage configuration for your MID:

- 1. Connect the MID and computer by USB cable, the reminder column will show the remind information.
- 2. Open the reminder board; please view the MID status and reminder to learn how to open the board.
- 3. In the reminder board, click the "USB for file transfer", it will as below Picture 3.7-1, then click "File transfers".
- 4. Now the USB is connected successfully.

1:19 A	M E P	* 🖓 🖞
÷	USB Preferences	۹
	USB USB	
	USB controlled by	
	Connected device	
	This device	
	Use USB for	
۲	File Transfer	
0	USB tethering	
\bigcirc	РТР	

Picture 3.7-1

Copy the document into memory card

- 1. Connect the MID to computer with USB cable.
- 2. As MID storage configuration, it is connected with computer successfully.
- 3. Open the "My computer" in your computer, check the items in "MTP devices".
- 4. Copy the documents you need into "MTP devices".
- 5. After copying finishes, unplug the USB can.

3.8 Typing words


Use the screen keyboard

When you start the procedure or choose the words or numbers edition, it will show the screen keyboard. The keyboard contains below typing options:

1. Android keyboard

Choose the typing method you want

- 1. Click Setting procedure application.
- 2. Click Language and Keyboard.
- 3. In the text setting area will reveal all the installed words-typing methods in your MID.
- Tick the typing method you want. 4.



Use and switch of input method

Picture 3.8-1

1	switch the capital and small letter
2	switch the mode of words input
3	click to insert the space
4	click input to execute
5	delete the character in the left of cursor, click and hold to delete all the characters in the left on the cursor.

Operation Technique 3.9

Enter widgets interface

In the application interface, click widgets on the above of screen, or slide the screen, it will switch into widgets interface. Long press any widget to create its shortcut, then you can enter into the application through the shortcut icon.


Create application shortcut icons in the desktop

In the application interface or widgets interface, long press any icon to switch into desktop automatically, drag and hold the icon, you can move to any position in the desktop.

Remind: If the target position has no space, the widget won't be add in the main screen.


3.10 Quick Setting

Swipe-down gesture from the top of the screen, there are nine shortcuts icons, such as Wi-Fi, Bluetooth, Auto-rotate, and so on. In the full Quick Settings list you can also tap the edit button at the bottom right to rearrange the tiles or replace them with others, as Picture 3.10-1. The optional extras list is pretty minimal: Just Hotspot, Data saver and Invert colors. But developers are now able to create custom Quick Settings tiles for their apps, which will definitely make things a lot more interesting in the coming mouths.



Picture 3.10-1

Swipe-down gesture from the top of the screen,Long press push message to see a switch, operate it to open and close the future of this app so all notifications as Picture 3.10-2



Picture 3.10-2

4 Basic Setting

4.1 Network and Internet

Reset Wi-Fi, mobile&Bluetooth

Click icon in right top of Picture , select Reset Wi-Fi, mobile&Bluetooth

This will reset all network settings ,including Reset Settings

4.1.1. Connect Wi-Fi

1) In the main menu or interface, choose setting application procedure.

- 2) Click WLAN, open wifi, MID will automatically search the available Wifi wireless internet. As Picture 4.1-3
- 3) Choose the Wi-Fi internet you want to connect, if it has password, it will popup the password window, enter password, click connect.

						🖹 📋 12:03 ам			
÷	Wi-Fi	Wi-Fi							
	On								
	•	HUAWEI-TEST				â			
	$\overline{\mathbf{v}}$	googlevpn1				۵			
	$\overline{\mathbf{v}}$	googlevpn2				â			
	$\overline{\mathbf{v}}$	googlevpn3				۵			
	$\overline{\mathbf{v}}$	NETGEAR42				۵			
	$\overline{\mathbf{v}}$	TP-LINK_4554				۵			
	$\overline{\mathbf{v}}$	360??WiFi-A3				۵			
	$\overline{\mathbf{v}}$	360免费WiFi-17				۵			
	$\overline{\mathbf{v}}$	TP-LINK_google				۵			
	$\overline{\mathbf{v}}$	D-Link_share mid				۵			
	$\overline{\mathbf{v}}$	E9				۵			
			\triangleleft	0					

Picture 4.1-3

1.Add Network

1) Click Add network icon in right top, as Picture 4.1-4

										3G 🛋 🖺 9:40 AA
Add network										
Network name										
Enter the SSID										
Security										
None										*
Advanced options										~
									CA	NCEL SAVE
				Suggest conta	ict names? Toucl	h for info.				
1	2	3	4	5	6	7	8	9	0	
q	W	е	r	t	у	u	i	0	р	×
а	S	d	f	g	h	j	k	1		
	Ũ	G		9		ŗ	i.			
	-	V	0		h	n	m	ļ	?	
T	Z	Х	С	V	b	n	m	!	f	T
?123	, I									٢

Picture 4.1-4

- 2) Input network SSID, the wireless network name, click save.
- 3) Click user name already saved, click connect to use network, as Picture 4.1-5

					🎯 🖹 📋 12:04 AM
÷	Wi-Fi				
	On				•
	Ŧ	HUAWEI-TEST Connected			â
	•	googlevpn1			â
	•	googlevpn3			â
	$\overline{\mathbf{v}}$	360免费WiFi-17			â
	$\overline{\mathbf{v}}$	googlevpn2			â
	$\overline{\mathbf{v}}$	NETGEAR42			â
	$\overline{\mathbf{v}}$	TP-LINK_4554			â
	$\overline{\mathbf{v}}$	TP-LINK_google			â
	$\overline{\mathbf{v}}$	D-Link_share mid			۵
	$\overline{\mathbf{v}}$	E9			۵
			\triangleleft	0	

Picture 4.1-5

2.Network Notice

If you open Network Notice, when WIFI signal appears, the right bottom will remind you available WLAN network, as Picture 4.1-3

Check WIFI data usage

Slide on the data usage page to find "Wi-Fi data usage" and click it, as Picture 4.1-8

		* ● ▼ 4G⊿ 🖞 15:52
÷	Wi-Fi data usage	
Ма	r 11 – Apr 8	~
	2.64 GB used	100%
		50%
	Mar 11 Apr 8 Carrier data accounting may differ from device accounting	0%
	Android OS	2.04 GB
	Google Play Store	232 MB
	iPerf	147 MB
		101 MB

Picture 4.1-8

4.1-4 Network sharing and portable hotspots

Portable WI-FI hotspots

- 1. Click setting application in main menu.
- 2. Click more when wifi is well connected, open network share and portable hotspot

0			📓 🗓 12:03 ам						
÷	Hotsp	Hotspot & tethering							
		USB tethering Share tablet's Internet connection via USB							
		Bluetooth tethering Share tablet's Internet connection via Bluetooth							
		Wi-Fi hotspot							
	i	Use hotspot and tethering to provide Internet to other devices through your mobile data connection. Apps can also create a hotspot to share content with nearby devices.							

Picture 4.1-9

- 3. Click keep WI-FI hotspots on, choose open time.
- 4. Return to previous menu, open portable WLAN hotspots, click Set up WI-FI hotspots as Picture 4.1-10

				🖹 🛿 12:03 ам
Wi-Fi hotspot				
Off	Set up Wi-Fi hotspot			
Basic settings	Network name AndroidAP_1676			
Keep Wi-Fi hotspot on	Security WPA2 PSK		-	
Set up Wi-Fi hotspot AndroidAP_1676 WPA2 PSK	Password			
WPS connect Selected Wi-Fi protected setu	The password must have at least 8 ch	aracters.		
Connected users	Show password Select AP Band 2.4 GHz Band		*	
0 connected user	Reset network SSID, security and pass for WPS)	word to default (out-o		
Blocked users 0 blocked user			RESET OOB	
0 blocked user	Maximum connections 6 users		*	
			CANCEL SAVE	
	<	0		

Picture 4.1-10

5.Set passwords you want to, password should be more than 8 numbers.


4.1-5 VPN

Open VPN, click **add VPN network**, as Picture 4.1-11. Input **name** and server address, then save.

٢																	* 😑	💎 4G 📶 🗳 15:54
÷	VPN			I	Edit Name	VPN pr	ofile											+
				I		address							Ŧ	I				
				L	•••			(1005)	`		с	ANCEL	SAVE					
G					Tha	anks			Т			W	e					Ŷ
Q	W	2	Е	3	R	4	Т	5	Y	6	U	7	I	8	0	9	Ρ	×
A		S		D		F		G		Н		J		к		L		\ominus
+	Z		Х		С		۷		В		Ν		М		ļ		?	+
?123	,								English	h					:			?123
						\bigtriangledown			0									

Picture 4.1-11

Click VPN, as Picture 4.1-12, input VPN user name and password, click connect.





4.1-6 Airplane Mode

Airplane Mode can turn off WIFI and GSM card function quickly, when airplane mode is turned on, WIFI and GSM can't get any signal, then airplane mode is turned off, WIFI and

GSM module will recover to previous state.

4.2 Bluetooth

Bluetooth function operation

- 1. Click setting application in main menu interface
- 2. Click **Bluetooth** and open it.
- 3. If somebody open Bluetooth in your surroundings, click search device in right above, then MID will automatically search the Bluetooth device nearby. As picture 4.2-1

			* 🗢 🐨 🖹 🛿 15:4
÷	Pair r	new device	
		Visible as "Android Bluedroid" to other devices	
		Available devices	•
	Ę.,	BH704	
	Ľ.	~uou~	
		ANDROID BT	
	i	Tablet's Bluetooth address: 00:00:46:00:00:01	

Picture 4.2-1

4. Click the available Bluetooth device, it will popup request window, enter into related password, and match the device to connect.

5. After match successfully, choose the operation you want to, click to enter into Picture 4.2-2.

•						՝ 🗢 🛡 🔟 🗴 15։47
÷	Bluet	ooth				
	On					•
		Visible as "Android Bluedroid"	' to other devices			
		Paired devices				
		Android Bluedroid	Paired devices			\$
	+	Pair new device	Name Android Bluedroid			
		Device name Android Bluedroid	Use for			
		Received files	Contact sharing	ок		
	i	Tablet's Bluetooth address: 0	0.00.40.00.00.01	_	_	

Picture 4.2-2

Bluetooth setting

1.Rename tablet

Click icon in right top of Picture 4.5, as Picture 4.2-3, select rename tablet, you can rename it as you want

0			🕈 🖤 📓 🔒 12:29 ам
÷	Bluet	poth	
	On		•
		Visible as "Android Bluedroid" to other devices	
		Paired devices	
	+	Pair new device	
		Device name Android Bluedroid	
		Received files	
	(j)	Tablet's Bluetooth address: 8C:6D:5E:06:29:70	
		⊲ 0 □	

Picture 4.2-3

2.Display the file you received Choose display the file you received in Picture 4.2-3, you can view download and upload files.

4.3 Apps & notification

4.3-1 APPS

- 1. Click setting application in Apps.
- 2. Select application, after enter, you can manage and delete installed application. (As Picture 4.3-1)

٩						* 🕕 ЗС 🎾 🖥 6:22 рм
÷	Apps	& notifications				
		Recently opened apps				
	•	YouTube Go 1m ago				
	3	SIM Toolkit 15m ago				
		File Manager 1h 13m ago				
	ø	Factory Mode 1h 14m ago				
	L	Phone 1h 14m ago				
	>	See all 28 apps				
		Notifications On for all apps				
		App permissions Apps using Location, Microphone, Camera				
		Advanced		-	_	
			\triangleleft	0		

Picture 4.3-1

4.3-2 Notification

1. Open settings, click Notification, as Picture 4.3-2

•	9					* ◎ 30	6:22 рм
÷		App inf	0				÷
	All ap	ps					
		**	Basic Daydreams 123 kB				
		- + =	Calculator 1.16 MB				
			Calendar 3.28 MB				
			Camera 57.34 kB				
		0	Chrome 1.37 MB				
		8	Clock 10.38 MB				
		-	Contacts 40.96 kB				
			File Manager 45.06 kB				
		-		⊲	0		

Picture 4.3-2


2. Click on any app icon in the list, then you can choose to show notifications silently, block all notifications or don't silence or block, as Picture 4.3-3

٩					≭ (⊡ 3G³⁄́́а́ 🔒 6:39 рм			
÷	Notifications							
	City Racing Lite							
	On			•	•			
	Allow notification dot							
	Allow interruptions Let the app make sound, vibrate, and/or pop notifications on screen							
	Override Do Not Disturb Let these notifications continue to interrupt when Do Not Disturb is set to Priority Only							
	<	1	0					
	< 1	4	0					

Picture 4.3-3

4.4 Battery

Click setting function, select battery, you can view the battery situation, as Picture 4.4-1



Picture 4.4-1

4.5 Display

4.5-1 Adjust the screen brightness

- 1. Click **Setting** application procedure.
- 2. Click **display**, choose brightness,
- 3. Drag the portico to adjust the brightness volume, as Picture 4.5-1

• • •					* 🕕 ЗСі́́́ 🔒 7:38 рм
÷	Display	·			
	MiraVision™ Display picture quality optir	nization			
	Brightness level 74%				
	Adaptive brightness Optimize brightness level for	or available light			
	Wallpaper				
	Sleep After 1 minute of inactivity				
	Auto-rotate screen				••
	Font size Default				
	Display size Default				
	Gsensor Calibrate Calibrate the gsensor				
		<	0		

Picture 4.5-1

4.5-2 Wallpapers

- 1. Click setting application.
- 2. Click display, click wallpaper.
- **3.** You can choose different wallpapers as you like—gallery---live wallpapers ---photos--- wallpapers (system defect)

4.5-3 Auto rotation

System is defaulted as open auto rotation, when it is turned off, system won't rotate MID screen by G-sensor.

4.5-4 Sleep

- 1. Click setting application.
- 2. Click display.
- 3. Click sleep.
- 4. Set the sleep time as you want

4.5-5 Font size

Click font size to adjust the size of the text

4.5-6 Display size


Click Display size to adjust the size of the icons

4.5-7 Mira Vision

Mira Vision is a set of engines to enhance display picture quality.

4.6 Sound

Open settings, click Sound, as Picture 4.6-1



Picture 4.6-1

1.Vibrate

In picture click Also vibrate for calls, MID will vibrate when someone calls you.

2.Volume

In picture click volume, you can set ringtone, media, and alarm volume

4.7 Storage

Open setting function, click Storage

Picture 4.7-1

(1)Internal storage

Internal storage is MID local NAND storage, as Picture 4.7-2, if you need to check the storage content, you can check it in main menu.

(2)SD card

Click SD card to check the storage content

Safely remove or format SD card

- 1. Click
- 2. Click Settings
- After the above two steps you can choose what you want to do,remove or format SD card

Note: Removing SD card safely can protect SD card and increase its lifetime.

4.8 Security&location

4.8-1 Set locked screen

Lock the touch screen by unlock icon or password to protect your MID.

Note: After setting screen locked, you should enter the pass code each time when you startup or screen is locked

Set unlocked picture

- 1. Click setting application in main interface.
- 2. Click security.
- 3. Click screen lock.
- 4. Choose **pattern** in text setting area.
- 5. Click next following the remind message.
- 6. The unlocked pattern board pop up, there are nine touch spots, connect 4 points from vertical, horizontal or diagonal direction. As Picture 4.8-1, move

your finger from the screen when finish. The system will record yours new unlock pattern.

- 7. Click continue.
- 8. When you see the reminder, enter the unlock pattern, then click confirm.

Set unlock PIN code

- 1. Click setting application in main interface.
- 2. Click security.
- 3. Click screen lock.
- 4. Choose **PIN** in text setting area.
- 5. Enter new PIN code(numbers) and click **continue**.
- 6. Enter new PIN code again and click confirm.

Set unlock password

1. Click setting application in main interface.

2.Click safe.

3.Click screen locked.

4.Set password in text setting area.

5.Set new password(letters and numbers) and then click continue.

6.Enter the password again and the click confirm.

4.8-2 Location service

Click setting, select Location

4.9 Users & accounts

- 1. Select setting application
- 2. Open account and sync

3. Click add an account

4. After successfully load, it will open the sync function

4.10 Accessibility

4.10-1. Font size

Click it to make system font large size

4.10-2. Click power button to end calls

When Click call, press "power" button, call will end but not hold.

4.10-3. Touch and hold delay

Click touch and hold delay to increase time,

4.10-4 Install webpage script

It will allow you install webpage scrip when you open system,, but it will increase the risk when you are browsing webpage.

4.11 System

4.11-1 Language and Input Method

Click setting, select language and input method, choose **language**, then click **Add a language**, select the language you want to add from the language list, as Picture .Back to language preferences page, you can drag the language you want to set to the first to switch language.

Click setting, choose language and input, choose Google keyboard setting, click input language

Choose the language you want to change in the language list

4.11-2 Gestures

Jump to camera

0		🖹 🔋 12:01 ам
÷	Jump to camera	
	Jump to camera To quickly open camera, press the power button twice. Works from any screen.	
	⊲ ○ □	

Operate it to open and close of this app as Picture 4.11-5

Picture 4.11-5

4.11-3 Date and Time

According to the preset, system will voluntarily apply the date, zone, and time provided by internet. as Picture 4.11-6

Manual set date, time and zone

- 1. Click Setting application procedure.
- 2. Slide down the screen, then click date and time.
- 3. Turn off "auto setting of date and time".
- 4. Turn off "auto setting zone".
- 5. Click Zone Selecting, then choose the zone lists. Slide down the list to view more zones.
- 6. Click **Set date**, then click upper or down button to adjust date, month, and year, click **setting** when you finish selection.
- 7. Click **Set Time**, then click upper or down button to adjust hour and minute, click AM or PM to change morning or afternoon (there is no such selection when you se 24-hour format). Click **Setting** to finish.
- 8. Click **24-hour format**, switch between 12-hour or 24-hour format, the time format you choose will be used on the alarm clock.
- 9. Click date format setting, then choose the time format you want to show on MID.

				🕒 🖹 🗵 12:46 лм
\	Date & time			
	Automatic date & time Use network-provided time			
	Automatic time zone Use network-provided time zone			
	Set date January 1, 2018			
	Set time 12:46 AM			
	Select time zone GMT+00:00 Greenwich Mean Time			
	Use 24-hour format 1:00 PM			
		\triangleleft	0	

Picture 4.11-6

Note: If you use the time internet provided, you will not able to set the date, time and time zone.

4.11-4 backup

Connect WIFI and login your google account, choose **backup my da**ta, system will backup your data into google server. as Picture 4.11-7

		📓 🗵 12:04 ам
÷	Backup	?
4	Back up to Google Drive	
	Automatic backup ensures you can easily restore or switch phones at any time. Learn more	
	Backup includes: - Apps and apps data - Call history - Device settings (including Wi-FI passwords) - Google Contacts - Google Contacts - SMS	
	Google Calendar and Google Contacts are synced to your Google Account and may be used across services.	
	Sync may be enabled even if backup is turned off. Sync settings can be changed in Settings > Accounts > Google.	
	\triangleleft O \square	

Picture 4.11-7

4.11-5 System update

Check to see if the system is up-to-date ,as Picture 4.11-8

- •		📓 🔋 12:05 ам
	Your system is up to date	
	Security patch level: April 5, 2018	
	→ Check for update	
	⊲ 0 □	

Picture 4.11-8

4.11-6 Reset options

If you need to recovery factory reset, please click reset, as Picture 4.11-9, if you need to formulate NAND, please click reset tablet.

0 🖪 🗑					🕈 🗢 🖤 🖹 🚊 1:33 ам
÷	Erase all data (factory reset)				
This will era	ase all data from your tablet's internal storag	je , including:			
 Your Goo System a Download Music Photos Other use 					
			RESET TABLET		
		\triangleleft	0		

Picture 4.11-9

4.11-7 Engineer Selection

1. USB debugging

After opening USB bugging, you can use some software to read MID software, but when USB debugging is turned on, USB storage needs to manual adjust.

2.Stay awake

If you open stay awake, it will never auto sleep when your MID is charging.

3.Pointer Location

If you open pointer location, it will display touch vertical and horizontal direction.

4. Show taps

If you open display touch screen operation, it will display touch operation on the screen. It is suggested to use with same direction as pointer location.

5. Show surface updates

If you open screen refresh, it will display related area when the area is refreshing.

6. Show CPU usage

After open CUP usage, in the right top of MID will show CPU usage situation. as Picture 4.11-10

			🔰 🗘 🎔 🖹 🗄 1:41 ам
÷	Deve	loper options	
	On		•
		Memory	
		Take bug report	
		Desktop backup password Desktop full backups aren't currently protected	
		Stay awake Screen will never sleep while charging	
		HDCP checking Use HDCP checking for DRM content only	
		Enable Bluetooth HCl snoop log Capture all bluetooth HCl packets in a file	
		OEM unlocking Allow the bootloader to be unlocked	
		Running services View and control currently running services	
		Picture color mode Use sRGB	

Picture 4.11-10

4.11-8 About Tablet

Check MID state

1. Check Setting application.

2. Click about tablet, check state message, model, Android version, version No and so on.

1. Click state message, check battery status, battery level, SIM status, IMEI information, IP address and so on.


5 Multi-Media


5.1 Music

Enter into music player: in menu or desktop click music click the music you want to play, as Picture 5.1-1:



icon to enter into music player,





- Drag the progress bar to adjust play progress.
- Operation of music player button as Picture 5.1-2

5.2 Photo Gallery

Photo gallery application can auto search photos and video files in SD card, and photo gallery will classify these photos and videos in folder. You can apply photo gallery to view and edit photos, set the photos as wallpaper and watch the video.

View pictures

- 1. Click gallery application in main interface.
- 2. Enter into gallery, click the folder you want to view.
- 3. Click the picture you want to view, the system will play it in full screen mode automatically.
- 4. The pictures can be zoom in and zoom out, put two fingers on the screen, the separate the fingers(gather up the fingers, the picture will be zoom in) or double click the screen.

Note: when you browse the pictures, slide left or right to view more pictures.

Edit and set pictures

When check the pictures in full screen mode, click menu key to display menu selection, you can choose the selection you need to edit and setting pictures.

- Slide Show
 - 1. Open a picture, use virtual key to click menu key, display menu selection.
 - 2. Click **slide show**, it will auto loop play
- Crop
 - 1. Click **menu** key to display menu selection.
 - 2. Then click crop, click and drag related area to adjust the cropper.
 - 3. Click cropper and drag it inside and outside to adjust the image.
 - 4. After adjust the size you want, click **crop**.
 - 5. If you wish to give up to crop, click **cancel** to return to picture browse.
- Edit
 - 1. Click **menu** key, display the menu selection.
 - 2. Click edit.
 - 3. Adjust the brightness, style, color, ant alias setting in selection.
 - 4. Click save.

5. If you want to give up edit, click **return** key, click **not** to return to picture browse.

5.3 Camera


In the main interface or desktop, click camera application procedure \bigcirc , enter into camera Operation of camera ,Switch camera: choose Menu key, click switch front/back • camera, as Picture 5.3-1. HDR capturing Auto capture when Flash on/off mode smile is detected Gesture capture View the pictures and videos normalCamera [Hog 07 2 mode Click it to take pictures Face beauty 8++ mode camera shooting mode Panoramic)7 mode Sub menu \triangleleft 0 Save button Picture 5.3-1

6 Internet

6.1 Browser


In case of Wi-Fi or mobile internet is connected well (Please refer to Chapter 4.1 for wireless and

internet setting), click IE browser 📀 in the main menu or desktop to enter the IE interface, as Picture 7.1-1



Picture 7.1-1

Click address bar to input the website, click start, enter into related webpage, then you can browse the website information, as Picture 7.1-2 and you can click the menu you can refresh ,save to bookmarks, share page, bookmarks, history and setting the webpage.



Picture7.1-2

6.2 Email

Email application procedure contains email setting guide, you can add the external POP3 OR IMAP email account of normal web email service provider (For instance, Yahoo, Gmail, Hotmail and 163),as Picture 7.2-1

N N					¥ 3G³⊿ 🖁 11:21
Account setup					
	Email accour You can set up you		few steps.		
	Email address				
	MANUAL SETUP		NEXT	>	
	\bigtriangledown	0		2	

Picture 7.2-1

a. Email Setting

- 1. After you click the sending email icon you can see the email setting guide, which can help you to set.
- 2. Input your email address and password.
- 3. Click "Next step" button, choose your email type is POP3 or IMAP.
- 4. Click "Next Step" button to check whether the email box servicer can receive or send emails
- 5. Input the email account and display the email subject, and click finish.
- 6. If the email box is available, you will enter into your mail box automatically.

b. Delete the email account

You can delete stetted POP3 or IMAP email account from your MID.

Click

- 1. Enter into your mail box.
- 2. Press Menu key.
- 3. Click Account
- 4. Press the account you want to delete.
- 5. Click confirm to remove.

c. Send E-mail

- 1. Click to display your mail box.
- 2. Click the inbox, it will refresh the new emails automatically; click it to read new email.
- 3. Press Menu key. Menus will popup.
- 4. Click Edit
 - Edit to enter into new email editing interface.
- 5. Input the receiver's email address.
- 6. Input the subject and email content.
- 7. If you want to add attachment, click menu key, the menu popup.
- 8. Click "Attach file" (photo, music, video, contacts).
- 9. Click "send" to send the email out.

												Click it	and
												Add	
												attachmei	nt
) 🗆 (0								*	🕩 💎 4G 🛛	96% 14:10	
÷	Cor	npose									ھ	> :	
			From I	huanxu	uexh@163	.com							
			То							~			
			Subject										
			Compo	se em	nail								
q	1	2 W	е	3	r	t 5	У	U 7	i ⁸	9 O	р	×	
	а	S	5	d	f	g	h	j	k	I		Done	
_		Z	х		с	V	b	n	m	!	?	<u>+</u>	
?123	}	@										.com	
					\bigtriangledown		0						

Picture 7.2-2

7 other characteristics

7.1 SmartTextSelection

Automatically detect the function that applies it to the corresponding application. If you click on the address of a restaurant sent to you by a friend, Google will know what you want and automatically use the map to start the route. Telephone numbers, e-mail addresses, etc. can also be done as Picture 8.3-1

중 🖪 🕊 🎭 Þ						\$	1	09:09
← Gmail			•	Ī			•	:
(no subject) Inbox								\swarrow
Lily.yi@szroco.com to me 09:09 View details battery_history.txt PHONE COPY SHARE SELECT AL 13714081435 Lily.yi@szrocc m 深圳市隆科电子有限公司 深圳市奎安区沙井镇兴业西路裕达富工业园5栋	L WEB SEARCH					4	+	
Reply		K Reply all		F	➡ Forward			
	\triangleleft	0						

Picture 8.1-1

7.2 Auto-Fill

For the most frequently used applications on the user's device, it will help the user to log in quickly without having to fill in the account name and password every time.

For example, when users use a new device, they can extract saved account names and passwords from Chrome. After the selection, the auto-fill function can be performed locally. It is suitable for most applications that you may use.

8 Other Application Procedures

8.1 Clock

Click **Clock** procedure, enter into the interface. There are clock, picture, music and homepage buttons.

3.2 Calculator

- 1. Click.
- 2. Enter into the basic board of calculator.

3. Soft touch the numbers or operator in calulator to calculate.

マ Зб ᆀ 🔒 7:57 рм

$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	7	8	9	÷	DEL	INV	DEG	%
1 2 3 - π e ^	4	5	6	×		sin	COS	tan
	1	2	Q			In	log	!
. 0 + = () v			5			π	е	۸
		Ō		+	=	()	



8.3 File Manager

- II 🖬 🔍

File manager will copy, cut, delete, rename the documents or the folder in the TF card, it also will share the files, install apk etc

In the main menu or desktop, click the document manager icon to enter into documents manager.

- ^a Copy, cut, delete, rename the files and folder: choose the file or folder, long press the file or er to enter into the interface, you can operate the file or folder.
- b. Paste the copy or cut file: choose the file you want to paste, icon to enter into,

Picture9.3-3

C. Share file:choose any file, long press it, it will popup "share", choose the share way you want in the list

d. Install apk file: Choose the file suffixed .apk in the file manager, you can install the third part software as reminder.

e、Build new folder: Choose the menu you want to build the file, click icon in right top, choose new folder, you can build new folder as reminder.

9 Recorder

In the main interface or desktop, click recorder icon **U** to enter into record interface, click

record key to start record. Click Stop key to stop recording. Click Play key to play the recorded sound. The system will auto remind you to use or abandon this record, please choose it manually.

Play the record: choose the video player to play the recorded sound, choose the recorded sound in the source manager, and click it to play.

10 Installation of Procedures

10.1 Installation

Install the third party application procedure

- 1. Click "file manager" application procedure; choose the application procedure you need to install.
- 2. Hold the application procedure you need to install.
- 3. It popup install, click install apk.
- 4. Finish the installation as guide, it will operate.

Note: The third party procedure searched from internet to use on the system are all suffixed with .apk.

10.2 Uninstall

Uninstall application procedure

- 1. Click setting icon in main interface.
- 2. Click **apps**, list all the application procedures installed in the system.
- 3. Click the APK you want to uninstall, click uninstall.
- 4. Click **confirm** to finish uninstallation.

Skill: The procedure manager installed by system has many convenient methods to uninstall after opening procedure manager, click uninstall, it will list all the application procedures installed by system.

11 Troubles Shooting

1. The first startup of MID is slow

After the MID system upgraded, the first startup need to install the pre-installed application software, the lead time is around 2-3 minutes, the startup afterwards will be much quicker.

2. MID can't connect Wi-Fi

- Make sure the wireless router of internet service can work in normal.
- Ensure the MID and wireless router in certain distance, and no wall or other barrier between them.
- Ensure the user name and password both correct.

3. MID feels hot

When many application procedures are used in meanwhile, or the brightness of screen open to the lightest or under charging, MID may feel fever. It is normal.

4. Email can't be set or Registration of application procedure.

- Ensure your internet is well connected.
- Make sure your email setting way is correct.
- Keep your system time and local time consistent.

5. The system is abnormal and can't work.

When you install some third party application procedure, it may cause abnormal work, you can press **Reset key**(next to power port) to reset the system.

6. The webpage can't be opened

- Please keep the distance between from route to MID in effective range.
- Please restart WIFI and try again.

7. MID works terribly slow sometimes

It is normal phenomenon. Please turn off some application you don't need in advanced task management, or uninstall some third party application to release more system resource.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm between the radiator & your body