

1. About the Click+

Click+ is a small, smart button that connects to your phone or tablet through Bluetooth. Through the free app, you can program the Click+ to perform a variety of actions to simplify interacting with your phone.

Each Click+ can control three different actions. Single-click for your first action, double-click for your second, and click and hold for your third.

Click+ can help you find your missing phone, control music playing from your phone, take better photos, navigate while driving and so much more.

2. Before You Start

Here are a few important points you should know before getting started with your Click+.

A. The Click+ app **MUST** be running in the background of your phone to communicate with your Click+ for a selection of the available actions. This includes: Find My Phone, Vibrate, Flashlight, Safari, Text Message & Navigate

B. A maximum of 4 Click+ smart buttons can be connected to one mobile device at a time.

C. Click+ smart buttons can only be paired to **ONE** mobile device at a time.

D. The Bluetooth on your device must always be ON.

3. Getting Started

A. Remove the plastic tab from the Click+ unit. Wait 10 seconds for the battery to fully activate.
Remove the Click+ Tab Wait 10 Seconds

B. Push the Click+ smart button, you should see a small blue light blinking near the centre of the button.

C. From your phone/tablet, make sure Bluetooth is turned ON.

D. Download the "ClickPlus by PowerStick" app from iTunes. If you have an Android, follow the instructions [here](#).

E. Open the Click+ app. A window will pop up asking if you would like the Click+ app to send you notifications. Tap **ALLOW** for the app to perform to its full potential. (A selection of the available actions do require notifications.)

Click+ Notification Request

F. Once your app is open, tap **LET'S GET STARTED**.

G. Swipe through the introduction screens to get an overview of how the Click+ works.

H. On the final introduction screen, tap LET'S ADD A CLICK+.

4. Pairing Your Click+

A. If this is your first time pairing, follow the instructions from the Getting Started section to bring you to this screen. Tap LET'S ADD A CLICK+.

B. As instructed in the app, press the button on your Click+ to pair it to your phone.

C. You may get a pop-up telling you that the Click+ is requesting to pair. Tap PAIR.

D. To pair additional Click+ smart buttons, open the app to the homepage (also called "Your Click+ Collection"). This screen shows you all of the Click+ smart buttons that have been paired to your Click+ app. Tap ADD in the top right corner of the screen.

E. You will then be brought to the pairing screen where you can press the button on your Click+ to pair as you did with your first Click+.

F. Your new Click+ will be added to "Your Click+ Collection"

5. Deleting Your Click+

A. To delete your Click+, open the app and tap the Click+ you would like to delete from "Your Click+ Collection".

B. This will bring you to the action set-up screen. Tap the menu button in the top right corner.

C. The settings menu will drop down. Tap REMOVE THIS CLICK+.

D. You will get a pop-up telling you to make sure to forget your Click+ from your phone's Bluetooth devices. This ensures that the Click+ is fully deleted from your phone and ready to be paired to a new phone.

E. The Click+ will now be removed from "Your Click+ Collection".

6. Renaming Your Click+

A. To rename your Click+, open the app and tap the Click+ you would like to rename in "Your Click+ Collection".

B. This will bring you to the action set-up screen. Tap the menu button in the top right corner.

C. The settings menu will drop down. Tap RENAME.

D. Type in the name that you would like this Click+ to have. You can name it after the person who owns the Click+ (ex. Tyler's Click+), the name of the room it is used in (ex. Living Room), the name of the function it serves (ex. Music Control), etc.

E. Tap DONE. Now your Click+ will be labelled with the new name you have given it.

7. Setting Up Your Click+ Actions

A. This is the screen that shows your Click+ actions. You can reach this screen by opening "Your Click+ Collection" screen and tapping the Click+ whose actions you want to edit.

B. Tap SINGLE-CLICK to choose the action you would like to perform with a single click of your Click+ smart button.

C. Tap DOUBLE-CLICK to choose the action you would like to perform with two quick clicks of your Click+ smart button.

D. Tap CLICK AND HOLD to choose the action you would like to perform with a click and hold (for a minimum of 3 seconds) of your Click+ smart button. From this point, setting up actions is the same for Single-Click, Double-Click and Click and Hold.

E. Here is an example of how to set up a Single-Click action. (This example uses the "Find My Phone" action. To see how to set up all of the actions, see the All Actions section of this support page.) Tap SINGLE-CLICK.

F. This brings you to the list of all the available actions that can be added to your Click+. Simply tap the action you would like to set up. For this example, tap FIND MY PHONE.

G. This is the information screen for the "Find My Phone" action. All actions have an information screen, some including different settings for you to edit. For this example, you can select the volume of the alarm that will sound from your phone when the Click+ button is pressed.

H. When you're finished setting up your action, tap DONE. You will be brought back to the action set-up screen where you can follow the same process to set up the Double-Click and Click and Hold actions.

FAQ

What is the range of my Click+?

The Click+ is for use up to 30 feet from your phone or tablet.

How many Click+ smart buttons can I pair to one device?

You can pair a maximum of 4 Click+ smart buttons in total to one device.

Why won't my Click+ pair?

Here are a few things to check if your Click+ won't pair:

Have you removed the plastic tab blocking the battery?

Is your operating system up to date?

Is your Bluetooth on?

How do I replace the battery?

Flip your Click+ over so you are looking at the bottom side

You will see a plastic back plate that needs to be removed to place the battery inside

Put your nail or a small coin in one of the slots beside "close" or "open"

Turn the plate clockwise to open the Click+

Replace with CR2032 cell battery

Place the back plate back on the Click+

Press and turn counter-clockwise to close the Click+

How do I reset my Click+?

Open the Click+

Remove the battery for 20-30 seconds

Place the battery back in the unit

Close the Click+ back up

Wait for 10 seconds for the battery to connect

What happens if I get a new phone?

To switch your Click+ to a new device:

Delete your Click+ from the app (Click+ smart buttons can only be paired to one device at a time so you will be unable to pair with the new device if it is still paired with another)

Download the Click+ app on the new device that you would like your Click+ to be paired with

Pair your Click+ as usual

What can I do if I am having connection issues with my Click+?

If you are experiencing connection issues with your Click+, there are a few things you can do:

Delete the Click+ from the app

- Open the Click+ app
- Tap the Click+ you are having connection issues with
- This will bring you to the action set-up screen for that Beagle, tap the menu button in the top right corner
- Tap REMOVE THIS CLICK+

Rest your Bluetooth connection

- Open your phone or tablet's Bluetooth settings
- Forget the Click+ device from the list of available devices
- Turn your Bluetooth off for about 30 seconds
- Turn your Bluetooth on again

Reset your Click+

- Open the Click+
- Remove the battery for 20-30 seconds
- Place the battery back in the unit
- Close the Click+ back up
- Wait for 10 seconds for the battery to connect

FCC Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Information and Statement :

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.