215*70mm

Magnetic 5.000 mAh 5W wireless powerbank UP-9193 Manual

Congratulations on your 5,000 mah powerbank. This powerbank is a charging system for mobile phones and other small portable electronic devices requiring a 5V/2A (maximum) current draw. It contains a 5.000 mAh A-grade Lithium-ion cell. It will fully charge an iPhone. Android or other common mobile phones with each charging cycle.



- 1. Type-C Input port
- 2. USB Output port 3 On/Off button
- 4. LED indicator
- Wireless charging area

POWERBANK DETAILS:

- Battery size: 5.000 mAh/18.5Wh
- Type-C Input: 5V/2A USB Output: 5V/2A
- · Wireless Output : 5W

TO CHARGE THE POWERBANK

By cable:

- . Plug in the supplied Type-C cable to your wall charger. The USB connector goes to your charger, the Type-C goes to your powerbank
- . When fully charged disconnect the powerbank and it's ready to use. Imporant: Only use included accessories or certified and tested accessories to charge the powerbank. Using third party accessories can influence the item safety.

TO CHARGE YOUR MOBILE DEVICE USING THE POWERBANK By cable:

- Plug your cable into the USB port on the power bank, the other end goes into your device.
- . The power bank will take approximately two hours to charge your mobile device to 95%.
- · After you have charged your device, recharge the power bank before using again.

Wireless:

- Make sure your phone is compatible for wireless charging.
- · Switch on the powerbank using the on button
- Put your wireless charging enabled device on the wireless charging surface of the powerbank.
- If your device supports MagSafe, the magnets in your iPhone and inside the item will connect which each other when you put the item on the device. This item is also compatible with other items, the magnetic function just won't work.

WARNING!

- . Do not vigorously shake, hit or throw the product.
- If the power bank is not used for long time, please charge/discharge it once every three months to ensure the service life of the product.
- Some phone cases may block the wireless charging
- Do not place other materials, like metal objects, magnets, and magnetic stripe cards, between the mobile device and the wireless charger pad.
- Check your mobile device's battery percentage using the charging icon displayed on the screen of your phone.
- . When the mobile device is not placed on the charging surface accurately, your mobile device may not charge properly.
- If you use the wireless charger in areas with weak network coverage, you may lose your network reception.
- Please do not expose this device to moisture or heat sources
- This is not a toy, not suitable for children under the age of 7
- . Only use included or certified accessories (cables, chargers) to use the item. Unsafe cables or chargers can influence the safety of the item.

ECC STATEMENT

This device complies with part 15 and part 18 of the FCC Rules. Operation is Subject To the following two conditions: (1) This device may not cause harmful interference. (2) this devicemust accept any interference received, including interference that may cause undesired operation. Changes or modifications not explicitly approved by the partyresponsible for compliance could void the user's authority tooperate this equipment.

Note: this equipment has been tested and found to comply with the limits for aClass B digital device, pursuant to part 15 and part 18 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates, uses and canradiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference torado or television reception, which can be determined by turning the equipment off and on, the user is encouraged totry to correct the interference by one or more of the following measures:

- . Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The equipment complies with ECC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

This device complies with Part 18 of the ECC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and any other radio device.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.