

Camera **SMART WATCH**



Pairing and Operating instructions

Charging the watch:

The watch features a USB charger. Simply plug in the mini USB plug into the USB receptacle on your watch. Insert the USB plug into your computer or USB wall plug from your phone. Charge for one hour.

Pairing to I-Phone.

1. On your phone ensure Bluetooth is enabled. Also, check on your watch that BT power is on. Settings, BT settings, power on.
2. Download APP MEDIATEK from APP store.




Mediatek SmartDevice

Liang Lv

★★★★☆ (33)

OPEN


3. Open Mediatek APP on your phone. You will see the following screen. Select Tap to add device. You will see the device name appear, please select. The APP will now connect to your watch. **DO NOT LEAVE THE APP!**




Please wait for a window to appear as shown. Select pair. Your watch may start to receive Notifications from your phone. If you have many Notifications in history this may take a few seconds.

It is important that you clear your notifications Periodically for the proper operation of the watch Notification and SMS system.

One more step



4. Now go to your phone's Bluetooth settings:
Go to Settings/Bluetooth on your phone and you will see the following.
Click on your device name under other devices.
It will now appear in your device section twice.
The watch is now fully paired.



**** Due to the low power nature of BT connections. Occasionally you may need to Re-Pair your watch. The procedure is as follows.**

Select the blue circle with I next to your device name. You will be redirected select "Forget This Device". Do this for both listings. Go to the Mediatek APP select the device name and you will be redirected, select forget this device. Now follow the pairing instructions above.




Pairing to an Android device

1. Ensure that you phone BT is on. Also ensure that the watch BT is on. Go to settings, BT Settings, Power on.
2. Go to your phone Bluetooth settings, select search for device. When your device name appears, select. Your device will now appear in the paired section.
3. Go to Google play and download MEDIATEK SMART DEVICE APP.





Mediatek SmartDevice
MediaTek Inc
Everyone

4. You will be prompted through a series of pages. Please accept all the notifications and information that you want your watch to receive (you must allow notification access). Please note the information on your watch is temporary. Each Android device may be different.



Once you have enabled all the notification you will see a pairing request page. Please select Pair. Once selected you will be redirected to the app page and your device will show as paired.

Your watch may start to receive Notifications from your phone. If you have many Notifications in history this may take a few seconds. It is important that you clear your notifications Periodically for the proper operation of the watch notification and SMS system.



**** Due to the low power nature of BT connections. Occasionally you may need to RePair you watch. The procedure is as follows.**

Go to phone Bluetooth and un-pair watch. Turn off and turn on Bluetooth. Your watch will appear under devices follow the pairing procedure outlined above.

Operating Instructions

Swipe screen to enter menu pages



To power on or off your watch simply press the power button for a few seconds.

Choosing a dial style:

Press on the screen

Wait for dial to go into Select mode. Swipe to Advance to next design

Press OK to select dial



Camera and video recording



Camera



Video recorder



Select camera or video icon to enter into recording mode. You will now see the image to record. In order to start recording, select the icon in the lower middle part of the screen. In camera mode once you take the image you need to select “back” in order to take another image.

In order to view Images, select Image viewer. Your saved image files will appear on the screen. Select the file name and your image will appear.

In order to view video, select video player. Your saved videos will be displayed on this screen. Select to play.

It is important to download or delete unwanted videos and images to ensure sufficient storage space.

To download images and videos. Connect you watch to your computer using the USB charging cord. You will be redirected select Mass Storage and your files will appear files folder.

Menu Functions: Press Icon to enter function.



Phonebook

Phonebook: If enabled your contact list will be uploaded to your watch. You can dial a call directly from your contact list similar to your phone.



Call logs

Call Logs: If enabled your call logs will be uploaded to your watch. You can dial directly from your call logs similar to you phone.



Dialer

Dialer: Calls can be directly dialed from your watch.



Messaging

Messaging: (Android only) With this icon messages from an Android device may be viewed.



Remote notifier

Notifications: (iOS Only) Read your text messages and notifications from you iOS device.



Find my device

Find my phone: If you are paired with your phone and are within range your phone will ring helping you locate it.



Alarm



Calendar

Alarm: You can set multiple alarms on you watch as well as view daily and monthly calendar.




Remote capture


Remote capture: Turn on the camera on your phone then select this icon. Press iOS button for Apple and you phone will take a picture. Select Android and the image that your phone is capturing will appear on you watch. Select icon on screen to take a picture.



BT music



iOS





Select BT stream

BT Music: You can stream music from your phone to you watch. Or you can remotely control what is playing on your phone. Select BT music and be redirected to Music control.



Pedometer

Activity Tracker



See conversion table on page 12

Activity tracking with history: Select the Start/Stop button to enable activity tracking. This feature is suitable for all day tracking or to track a walk or run. Options: You can see your history, set your step goal, enter your height and weight for approximate calories burned count. Please note Values can only be added in Metric see conversion table on last page.

Calories burned is an estimate based on height and weight.



Sound recorder

Audio Memos



Select Icon, start to record, voice memos can be uploaded to your computer or can be played on your watch.



Stopwatch

Stopwatch: You can measure an event, laps or split time.



Settings

Settings: You can select a variety of features to enhance your user experience. We will cover a few more important settings.

- **BT Setting:** Ensure that power is on or your watch will not pair.
- **Clock:** Your watch is set to automatically sync with your watch. If you want to manually set or toggle between military time Select Time sync and turn off. You will now see manual setting mode.


- **Sound:** You can choose a variety of sounds for your various functions. You can also adjust the volume in the volume section for each function.
- **Motion:** You can enable a variety of functions. Wake-Up gesture turns the dial on when you raise your hand. You can also enable motion to turn off notification and incoming calls.
- **International:** Select language of your choice

Operating tips

1. **Clearing notifications.** It is important that you clear your notifications from your phone on a regular basis. You can select what notifications to receive on your phone from your settings area.

Clear notifications from iOS


Swipe down on your screen from Any menu. Select X then clear.



Select X Then Clear

Choosing Music stream

iOS:



Select device

Swipe up from any screen. You will see the screen shown. Select the device that you want to stream sound to. Your watch is the default setting use this area to redirect sound to your phone. In order to use your watch as a remote control for your music player you must choose a different device such as your phone or headset.

Please note: You can only stream to one device at a time.

Height conversion

for pedometer setting

1 foot = 34.8 centimeter

4.0 feet = 130 cm

4.5 feet = 150 cm

5.0 feet = 170 cm

5.5 feet = 190 cm

6.0 feet = 200 cm

6.5 feet = 220 cm

Weight conversion

1 pound = 454 of a kilo

You weight in pounds is approximately 1/2 of your weight in kilos.

100 lbs = 45.4 kilos

120 lbs = 54.48 kilos

140 lbs = 63.56 kilos

160 lbs = 72.64 kilos

180 lbs = 81.72 kilos

200 lbs = 90.8 kilos

220 lbs = 99.8 kilos

240 lbs = 108.8 kilos

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.