
# **User Manual of RF405A**



#### **Item**

#### 1.1 ZG button6

Click the ZG button, the actuator moves to ZG position, stop when click any button during the movement;

Press and hold the ZG button for 5s, timer LED of remote flashes, the control box records current position as ZG position;

When in the process of movingto memory positions, the head and foot actuatorsmove first, then the tilt and lumbar actuators move;

#### 1.2 AntiSnore button9

Click AntiSnore button, actuators move to AntiSnore position, stop when click any button during movement;

Press and hold AntiSnore button for 5s, timer LED of remote flashes, the control box records current position as AntiSnore position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

# 1.3Head upbutton 4

Press and hold HEAD UP button of remote, head actuator moves out, stop when released:

#### 1.4 Head downbutton 5

Press and hold HEAD DOWN button of remote, head actuator moves in, stop when released;

## 1.5 Foot upbutton7

Pressa and hold FOOT UP button of remote, foot actuator moves out, stop when released;

## 1.6 Foot downbutton 8

Press and holdFoot DOWN button of remote,Foot actuator moves in, stop when released;

## 1.7 Flatbutton 15

Click FLAT button, the bed goes flat, stop when click any button during the process of going flat:

# 1.8 Massage all 3

Click Massage all button, all massage motor switches massage intensity, massage intensityswitches among 0-1-2-3;

# 1.9 M3/M4 motor upbutton11

Press and holdM3/M4UP button of remote,M3/M4 actuator moves out, stop when released;

#### 1.10 M3/M4 motor downbutton 12

Press and holdM3/M4down button of remote,M3/M4 actuator moves in, stop when released;

# 1.11Memory position button 10 and 13 14

Click memory position to move the actuator to the memory position.

Press and hold the button for 5s, timer LED of remote flashes, the control box records current position as the memory position;

## 1.12Under bed lightbutton 1

Click the under bed light button, the under bed light switch its on/off state; After the under bed light opens, if do not manually close, it will automatically turn off after 5 minutes;

## 1.12 Sensor light switch 2

Turn up the switch, open the Sensor function of the bed light , the turn down the switch to close sensor function.

#### **FCC Statement**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

#### **FCC Warning**

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

The product is the remote control of the bed, and the matching model is MC120NM. FCC ID: 2AK23MC120NM

RF Function:2.4G SRD Operating Band/Frequency:2403-2480MHz Antenna Type:PCB antenna Maximum Antenna Gain:1dBi

Manufacturer: Keeson Technology Corporation Limited Address: No. 195, Yuanfeng East Road, Wangjiangjing, Xiuzhou District, Jiaxing City, China 314000