
	Issue Department: Bedding Division	Date:	2022-12-23
	<b>System Instruction</b>	Author:	
<b>Instruction of RF427A</b>		Edition:	1.0
		Page 1 of 7	

## Instruction of RF427A



Figure 1 button of remote

	Issue Department: Bedding Division	Date:	2022-12-23
	<b>System Instruction</b>	Author:	
<b>Instruction of RF427A</b>		Edition:	1.0
		Page 2 of 7	

---

## Item

### 1.1 Child Lock 1

Click the Child Lock button for 3 second to lock or unlock the remote.

### 1.2 Bed lamp 2

Click the bed lamp button to open or shut the light under the bed.

### 1.3 Antisnore 3

Click the Antisnore button, the bed moves to Antisnore position, press and hold Antisnore button for 5s, until backlight flashes, the control set the current position as Antisnore position

### 1.4 TV 4


Click the TV button, the bed moves to TV position, press and hold TV button for 5s, until backlight flashes, the control set the current position as TV position.

### 1.5 LUMBAR UP 5

Press and hold LUMBAR UP button, Lumbar actuator moves out, stop when released.

### 1.6 LUMBAR DOWN 6

Press and hold LUMBAR DOWN button, Lumbar actuator moves in, stop when released.

	Issue Department: Bedding Division	Date:	2022-12-23
	<b>System Instruction</b>	Author:	
<b>Instruction of RF427A</b>		Edition:	1.0
		Page 3 of 7	

### **1.7 M1 7**

Click the M1 button, the bed moves to M1 position, press and hold M1 button for 5s until backlight flashes, the control set the current position as M1 position

### **1.8 M2 8**

Click the M2 button, the bed moves to M2 position, press and hold M2 button for 5s until backlight flashes, the control set the current position as M2 position

### **1.9 HEAD UP 9**

Press and hold HEAD UP button, head actuator moves out, stop when released.

### **1.10 HEAD DOWN 10**

Press and hold HEAD DOWN button, head actuator moves in, stop when released.

### **1.11 FOOT UP 11**


Press and hold FOOT UP button, foot actuator moves out, stop when released.

### **1.12 FOOT DOWN 12**

Press and hold FOOT DOWN button, foot actuator moves in, stop when released.

### **1.13 ZG 25**

Click the ZG button, the bed moves to zeroG position, press and hold zeroG button for 5s,

	Issue Department: Bedding Division	Date:	2022-12-23
	<b>System Instruction</b>	Author:	
<b>Instruction of RF427A</b>		Edition:	1.0
		Page 4 of 7	

until backlight flashes, the control set the current position as zeroG position

#### **1.14 HEAD MASSAGE 14**

Click the HEAD MASSAGE button, head message motor switches message intensity, message intensity switches among 0-1-2-3;

#### **1.15 MESSAGE model 13**

Click the MESSAGE MODEL button to change the message model.

#### **1.16 FOOT MASSAGE 15**

Click the FOOT MASSAGE button, foot message motor switches message intensity, message intensity switches among 0-1-2-3

#### **1.17 FLAT 24**


Click the FLAT button, the bed goes flat.

#### **1.18 MESSAGE FREQUENT 28Hz 16**

Click the 28Hz button to set the message frequent 28Hz.

#### **1.19 MESSAGE FREQUENT 40Hz 17**

Click the 28Hz button to set the message frequent 40Hz.

	Issue Department: Bedding Division	Date:	2022-12-23
	<b>System Instruction</b>	Author:	
<b>Instruction of RF427A</b>		Edition:	1.0
		Page 5 of 7	

### **1.20 Left Fan without heat 18**

Click the Left Fan without heat button, Left Fan switches intensity, Fan intensityswitches among 0-1-2-3;

### **1.21 Left and right Fan without heat 19**

Click the Left and right Fan without heat button, Left and right Fan switches intensity, Fan intensityswitches among 0-1-2-3;

### **1.22 Right Fan without heat 20**

Click the right Fan without heat button, right Fan switches intensity, Fan intensityswitches among 0-1-2-3;

### **1.23 Left Fan with heat 21**


Click the Left Fan with heat button, Left Fan switches intensity, Fan intensityswitches among 0-1-2-3;

### **1.24 Left and right Fan with heat 22**

Click the Left and right Fan with heat button, Left and right Fan switches intensity, Fan intensityswitches among 0-1-2-3;

### **1.25 Right Fan with heat 23**

Click the right Fan with heat button, right Fan switches intensity, Fan intensityswitches among 0-1-2-3;

	Issue Department: Bedding Division	Date:	2022-12-23
	<b>System Instruction</b>	Author:	
<b>Instruction of RF427A</b>		Edition:	1.0
		Page 6 of 7	

## FCC Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## ISED Statement

- English: This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.  
The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).
- French: Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

	Issue Department: Bedding Division	Date:	2022-12-23
	<b>System Instruction</b>	Author:	
<b>Instruction of RF427A</b>		Edition:	1.0
		Page 7 of 7	

This radio transmitter (ISED certification number: 22406-RF408A) has been approved by Industry Canada to operate with the antenna types listed with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio (ISED certification number: 22406-RF408A) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.