

Size: 360*50mm
 Foldable size: 72*50mm

Front

Wireless earbuds with mic
 Model:20BS06

PRODUCT GUIDE

Ver.01 12/11/18

What's in the Box

Product Guide
 Micro-USB Charging Cable
 3 Earbud Sizes

Bluetooth® In-Ear Headphone

Ver.01 12/11/18

Power On

Press and hold for 2 sec

Blue light flashes

Ver.01 12/11/18

Power Off

Press and hold 2 sec

Ver.01 12/11/18

Bluetooth Pairing

Press and hold 5 sec when power off

LED will flash red and blue when ready to pair

Blue LED flashes when connected

Activate the Bluetooth and select 'BT EARBUD 18LY48' in the Settings of your device

Ver.01 12/11/18

Play

1 x Press Play/Pause

1 x Press Press and hold 15s Siri/Google Assistant

1 x Press Press and hold

1 x Press Press and hold

Ver.01 12/11/18

封面

P1

P2

P3

P4

Back

Phone Controls

1 x Press Answer

1 x Press Hang up

Press and hold for 2 sec Decline

1 x Press

Ver.01 12/11/18

Charging

2 Hours Full Charge

(Solid red) Charging → (Solid blue) Charging Complete

Plug micro-USB cable into computer's USB port

Plug micro-USB cable into USB wall charger

Ver.01 12/11/18

Product Information

- Product Name: Wireless earbuds with mic;
- Pairing Name: BT EARBUD 20BS06
- Speaker Rated Power Input: 3mW(0.31V);
- Speaker Maximum Input Power: 5mW(0.40V);
- Loudspeaker Diameter:Φ10mm;
- Speaker Impedance: 16±15% Ω;
- Sensitivity: 93±3dB;
- Charging Cable: 0.3m

Ver.01 12/11/18

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, these limits are designed to provide reasonable protection against harmful interference in a residential installation, this equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. May cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warning:
 Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Ver.01 12/11/18

Troubleshooting

- **Headphones fail to turn on**
 - Ensure headphones are fully charged before turning it on.
- **My mobile device is unable to find the Bluetooth headphones**
 - Check that the headphones is in pairing mode (blue/red indicator lights flashing).
 - Remove "BT EARBUD 20BS06" from Bluetooth settings list and setup again.
 - If still no search result, please restart the headset and phone, and try again.
- **After successfully pairing, headphones disconnect**
 - Check the battery level and recharge if low.
 - Ensure headphones are within 30ft of mobile device and free of obstructions.
 - The connection may be affected by obstructions such as walls or other electronic devices. Try moving closer to the device you are connected to.
- **When answering a call, I cannot hear anything**
 - Ensure the mobile device is connected to headphones and not on speakerphone mode.
 - Increase the volume on your mobile device.
- **There is no sound when listening to music**
 - Increase the volume on your mobile device.
 - Reconnect the headphones to your mobile device.
 - Check if the app has paused or stopped playback.
- **Headphones fail to charge**
 - Check whether the charging cable is functional.
 - Ensure the micro-USB charging cable is fully seated in the headphones and wall charger ports.
 - Ensure the charging cable and wall charger are functional.

Ver.01 12/11/18

P5

P6

P7

P8

封底