


WIRELESS TIRE PRESSURE MONITORING SYSTEM

Sensor (On-valve) Instruction Manual



TPMS



Implementation Standard: Q/YAT001-2017

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Sensors (4 sensors as standard) are already paired with monitor in package, fix sensors on tires then it's ready for use.

Be sure to fix sensor to right tire according to the tire position (LF, LR, RF, RR) marked on each sensor.


SPECIFICATIONS

Detecting pressure range	0~6BAR (0~87PSI)
Operation temperature	-20°C~85°C
Storage temperature	-20°C~85°C
Frequency	433.92MHz
Transmission power	<10dBm
Pressure accuracy	±0.1 bar(±1.5 psi)
Temperature accuracy	±3°C
Dimension	21(dia.)x17.5(H)mm
Weight	9g


INSTALLATION



1 Screw in the nut to valve.




2 Screw the sensor onto valve and fasten.



3 Screw the nut counterclockwise with spanner, fasten it until it's in touch with sensor.


REPLACE SENSOR BATTERY




1 With the provided tools to screw sensor counterclockwise to open its cover.



CR 1632 Lithium battery



2 Fix in the new battery (positive+ side facing up).



3 Examine if the sealing rubber is in good condition, clockwise screw back the sensor cover by provided tools.