




Bluetooth®
Shop Light
Installation Instructions




ATTACH YOUR RECEIPT HERE

Item Number _____ Purchase Date _____

Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-866-492-6566.

PACKAGE CONTENTS



Part	Item Name	Qty.
A	Fixture	1
B	Chain	2
C	"J" Hook	2

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product. Failure to do so could lead to electric shock, fire or other injuries that could be hazardous or even fatal.

- Be sure the electricity to the wires you are working on is shut off. Either remove the fuse or turn off the circuit breaker.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This product must be installed in accordance with local, state and national electrical codes.
- Installation work shall be completed by a licensed installer that is familiar with the construction and operations of the product.

CAUTION:

- The fixture body is one piece. Do not disassemble it.
- This product can NOT be used with a dimmer switch.

NOTICE

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and the receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.
- If the fixture will not be operated for a long period of time, the power plug should be disconnected from the outlet.

INSTALLATION INSTRUCTIONS

1. Mark two (2) locations on mounting surface spaced apart by 34-in.
Ensure that the mounting holes will be located on a sturdy surface such as wood rafters, plywood or drywall studs. The mounting holes should NOT be located over a drywall surface without a backing support, as this may not provide enough support for the weight of the fixture.




Fig. 1

2. Drill pilot holes in each of the two marked locations. Screw in the two "J" hooks (C), one in each pilot hole. Hook the loop end of one chain (B) onto each "J" hook (C).




Fig. 2

3. Insert the hook end of one of the chains (B) into the support slots on the fixture back as shown in Fig. 3 to support the fixture on the mounting surface. Repeat for the second mounting hole.





Fig. 3


INSTALLATION INSTRUCTIONS

4. After mounting the fixture plug the power cord into a grounded outlet to finish the installation.




OPERATING INSTRUCTIONS

1. The light can be switched on and off by using the pull chain. The speakers will continue to work whether the light is on or off, as long as connection to bluetooth device is maintained.



2. To connect the shoplight to your Bluetooth® device, plug in the shop light fixture to power on the speakers (shop light LED illumination does not need to be switched on), then listen for a double chime sound from the speakers.

Enter the Bluetooth® menu on cell phone or other source device and access the list of “Available Bluetooth® Devices”.



Check the list of available devices on the Bluetooth® device to see if “SL-*****” (where * stands for a unique number) is detected. The list may need to be refreshed, or manually scanned for new connections. Select the “SL-*****” name to pair device with the fixture. Once connection is established, the fixture speakers will emit a single chime.

If “SL-*****” is not available after 1 minute of powering on, unplug the fixture power cord and plug back in to reset the speakers.

Volume can be adjusted from your source Bluetooth® device.

Please note that only one Bluetooth® device can be connected to each fixture, and only one fixture can be connected to each Bluetooth® device.

Typical connection range is approximately 32 feet (10 meters), and connection reliability may be affected by obstructions within the room. If interruptions occur during streaming, try relocating the Bluetooth® device to a different location.

www.energeticlighting.com

CARE AND MAINTENANCE

Clean with a mild, non-abrasive glass cleaner and soft cloth. Do NOT use solvents or cleaners containing abrasive agents. When cleaning the fixture, make sure the power is turned off, and any liquid spray should be applied to the cleaning cloth and not sprayed directly onto the fixture itself.

TROUBLESHOOTING

Problem	Possible Solution	Corrective Action
Fixture does not light.	Power is off.	Check circuit breaker or wall switch.
Bluetooth® connection cannot be established.	Reset power to fixture. Rescan for available devices from device settings menu.	Unplug the power plug from outlet, and plug back in. Check device Bluetooth® settings menu. Ensure that device has Bluetooth® enabled, also check that device has sufficient battery charge.
Poor sound quality from speakers.	Device is out of range from fixture. Other wireless devices in close proximity causing interference. Device settings may need to be enabled or adjusted.	Ensure that the fixture is within 32 feet (10 meters) of the Bluetooth® device and check for obstructions between device and fixture. Try relocating source device away from other Bluetooth® or Wi-Fi devices, or try turning off other devices to see if connection can be restored. Check device volume is not muted or set too low. Check if the phone has any low battery power management regulating Bluetooth® connection.

WARRANTY

This fixture is warranted to perform free from defects for three years. If it fails to do so, you may return it with proof of purchase to 13445 12th St., Chino, CA 91710 for replacement.

www.energeticlighting.com