








 <p>Wireless Kinetic DoorBell User Guide</p>	<p>Product Description:</p> <p>This Wireless Kinetic doorbell employs micro-energy acquisition technology to provide battery-free installation and use. The ease of installation, IP67 waterproof rating, and various ring tones, make the Door Bell the ideal choice.</p>  <p>Specifications:</p> <ul style="list-style-type: none"> • Operating Voltage: AC 100V-240V 50/60Hz • Power Supply: Self-Powered • Communication: RF 433MHz • Working Range: 100m(Outdoors)40m(Indoors) • Volume Level: 4 levels • Ring tones: 38 songs optional • Temperature Range: -20℃ ~ +55℃ • Storage Capacity: <ul style="list-style-type: none"> • The receiver can be paired with up to 10 Doorbell Transmitters • One doorbell Transmitters can be paired with an unlimited number of receivers 	<p>Installation:</p> <p>1. Plug the doorbell receiver directly into the electrical socket and it will ring once after the power is on. This product is suitable for indoors use only. Please avoid using it in high temperature, high humidity, dusty, and strong electromagnetic interference environments. (It is recommended to install it above 50cm from the ground, otherwise the signal will be weakened.)</p>  <p>2. Use 3M sticker paste the Transmitter: Tear off the 3M sticker on the back of the Transmitter and then paste it on the fixing part. (Do not stick on a metal door, otherwise it will affect the signal.)</p> 	<p>Or use screws to install the Transmitter:</p>  <p>3. To remove the Transmitter from the plate, please use a small screwdriver to push into the small hole at the bottom of the Transmitter and then pry upwards lightly. The Transmitter will slide up and out of the wall plate.</p>
<p>Receiver keys' Function:</p>  <ul style="list-style-type: none"> • Volume key: Press this key and the volume will switch between levels 1-4. • Ringtone selection key: Press this key to cycle through the available ring tones. • Ringtone selection key +pairing button: Used for pairing and changing the ringtone to the previous one. <p>Pairing Method:</p> <p>1. The Transmitter and Receiver in your package are already paired. If more than one Transmitter or Receivers are required to be paired, please follow the below steps:</p>  <p>a. Press the ringtone selection key - for 3 seconds until the light is flashing, then release the button.</p>  <p>b. Press the Transmitter once and the light will go off. This means that the pairing is successful.</p>	<p>Receiver clear Pairing:</p>  <p>Press the ringtone selection key - for 12 seconds until the light changes from flashing to still to off. The button can then be released. Once done all pairing information is cleared down.</p> <p>Power cut memory</p> <p>After a power cut the doorbell memorise the last set ringtone and ring volume.</p> <p>Silent mode</p> <p>When the volume is lowest, it defaults to silent mode.</p> <p>Restore the default state</p> <p>Press the Volume key for 3 seconds, then the The ring tone and volume will be restored to the initial state.</p> <p>FCC Warning</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital</p>	<p>device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance, such modifications could void the user's authority to operate the equipment.</p>	<p>CERTIFICATE INSPECTED</p> <p>Statement: Wireless kinetic DoorBell is a product of Shenzhen EBELONG Technology Co., Ltd. The product specification and information is for reference only. Update of content will not be further notified. Except for special agreement, information from this manual shall not constitute any form of responsibility. Without written approval from Shenzhen EBELONG Technology Co., Ltd, no unit is allowed to copy, translate any content from this manual, and shall not in any forms or by any means (electronic, mechanical photocopying, recording etc) diffuse product information for commercial profit purpose.</p> <p>Shenzhen EBELONG Technology Co., Ltd. Address: 4th Floor, Building 2, Hengqingshi Shaping Industrial Park, Xianggang Road, Bantou, Shenzhen, Guangdong, China. 400 64400 000 362 TEL: +86-755-2188 8758</p>  <p>Copyright © 2014-2022 Shenzhen EBELONG Technology Co., Ltd</p>