
One page folded, black and white



Model Number: XBH9-1029

855-999-8041 WWW XTREMECABLES COM



Media Buttons
Micro USB Charge Port & Micro SD Card Slot
Built-in Mic
LED Indicator
Flexible Neck Band
Open-ear Headphone Speakers

SPECIFICATIONS

Bluetooth® version: V5.1 Operation Distance: ~32.8 ft (10M) Frequency: 2.4GHz - 2.48GHz Frequency Response: 20Hz ~ 20kHz Music Play time: Up to 16 hours (at 30%~50% volume) Call time: Up to 16 hours (at 30%~50% volume) Standby time: Up to 12 days Battery: 230 mAh Charge Time: Up to 2 hours Charge Input: 5V/500mA

BUTTON FUNCTION (while in Bluetooth® mode)	
Power On	Press and hold "+" button for 3 seconds
Power Off	Press and hold "+" button for 5 seconds
Volume Increase	Press "+" button
Volume Decrease	Press "-" button
Next Song	Press and hold "+" button for 1.5 seconds
Previous Song	Press and hold "-" button for 1.5 seconds
Play/Pause Song	Double Press "+" button
Voice-Assistant	Triple Press "+" button
Answer Phone Call	Press "+" button to answer incoming phone call
End Phone Call	Press "+" button to end current phone call
Reject Phone Call	Press and hold "+" button for 1.5 seconds when receiving incoming phone call
Switch to SD card mode	Double Press "-" button

BUTTON FUNCTION (while in SD card mode)

· · · · · · · · · · · · · · · · · · ·	
Power On	Press and hold "+" button for 3 seconds
Power Off	Press and hold "+" button for 5 seconds
Volume Increase	Press "+" button
Volume Decrease	Press "-" button
Next Song	Press and hold "+" button for 1.5 seconds
Previous Song	Press and hold "-" button for 1.5 seconds
Play/Pause Song	Double Press "+" button
Switch to Bluetooth® mode	Double Press "-" button

PAIRING YOUR DEVICE

When pairing the headphones for the first time, start by powering them on, they will automatically go into pairing mode as signified by the pairing voice prompt. The headphone's LED indicator will alternately flash red and blue, letting you know it is ready for Bluetooth[®] pairing. Ensure your smartphone is within range of the device and open the smartphone's Bluetooth[®] settings, then select "Xtreme XBH9-1029". If the connection is successful the LED indicator will turn blue.

If the connection is unsuccesful, turn the headphones off and on again to repeat the pairing process above.

CHARGING YOUR DEVICE

When the battery level is low, a beep will sound notifying you to charge the headphones. The headphones will automatically shut down when the battery is completely discharged.

To charge the headphones, open the charging port cover (located on the bottom of the right earphone) to reveal the Micro USB charge port. Using the included charge cable, connect the USB connector to a USB power supply (not included), and connect the Micro USB connector to the headphone's Micro USB port. The red LED on the device will turn on, when it is fully charged it will turn blue.

NOTE: Lithium-ion batteries will self-discharge over time. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long the lithium-ion battery will no longer have the ability to be recharged.

SAFETY AND CARE INSTRUCTIONS:

- This product contains a non-replaceable rechargeable lithium-ion battery. When discarding, follow your local/state guidelines.
- Do not expose to rain or moisture, and do not use near water such as swimming pools, bathtubs, or sinks.
- Do not attempt to disassemble the unit. Repairs to electrical equipment should only be performed by a qualified service person. Improper repairs may place user as risk and void warranty.
- Do not use this unit for anything other than its intended user or purpose. Doing so may damage the device and void warranty.
- Do not puncture or harm the exterior surface of the product in any way.
- Warning: This is not a toy. Keep out of reach of young children. Small parts can pose a choking hazard.
- Do not expose batteries or battery pack to excessive heat or open flame.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the device destroy the battery, and/or distort certain parts.
- Do not use abrasive cleaning solvents to clean the unit.
- In order to prolong battery life, turn off when not in use.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product and for product support, please contact Customer Service at customerservice@xtremecables.com

WHAT'S INSIDE

Open Ear Wireless Sport Headphones Micro USB Charge Cable Manual