





HAYLOU OW01

User Manual

Overview




How to wear



When calling, adjust Mic towards mouth to gain better talking experience.

How to Charge


Prior to using, please peel off sticker covering the pogo pins and top up the earphones.



Stereo Mode

Auto pairing: take out both EarBuds from the case and they will auto pair with each other in 2 or 3s. Earphones will be connectable to cellphone when LED on either EarBud blinks white slowly. On cellphone, search for HAYLOU OW01 and tap to connect. If earphones fail to be connected to cellphone, please put EarBuds back to the case and repeat the above steps. Earphones will auto reconnect to the last device in connectivity records, if any.

Note: earphones have been setted to factory when shipping out.



Manual pairing: manually power on two EarBuds and they will auto pair with each other when LED blinks white promptly. Then LED on the either EarBud will blink white slowly and now you can tap it on cellphone to connect.

Bone-conducted earphone

Earbuds Parameters

Operation range: 10m(open space with no obstacle)

Model : Haylou OW01

Charging time: approx. 1.5hr

Caling time: approx. 3hr

Standby time: approx. 105hr

Input: 5V == 430 mA

Battery type: Li-ion

Bluetooth version: V5.2

Working temperature: -10~50

! Factory Setting

If earphones do not function well, please refer the following steps to reset factory: take earbuds out from the case. Power off the earphones then touch both panels for about 15s (LED will blink red and white three times twice). After that, put them back to the case. Delete connectivity record on cellphone before processing another pairing (All connectivity records relating to the earbuds will all be removed).

! Audio only outputs from single earbud

It's really rare. Please reset GT1 Pro, remove connectivity record on your cellphone and re-connect the earphones to your cellphone.

! Other cases in charging

LED glows solid white for 1 minute when earbuds are topped up.
Carry case cannot charge earbuds, if its battery drains. LEDs on carry case will turn off once the case is topped up. If you charge it once again, LEDs will not give any notice, which does not mean the case is not charged.

Daily maintenance

Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth after use in pursuing a longer service life.



FCC ID: 2AMQ6-OW01

This device complies with part 15 of the FCC results.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1.1. Reorient or relocate the receiving antenna
 - 1.2. Increase the separation between the equipment and receiver
 - 1.3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
 - 1.4. Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Aftersales & Support

Warranty Period:

12 months after purchase

(please keep your receipt properly)

Free Service:

If any quality defects happen during the warranty period, please take the receipt and contact with your distributor for aftersales service.

Following cases or any damages/defects that are not due to quality issue are not covered in the warranty.

1. Any defects or damages caused by natural disasters, abnormal voltage or other environmental facts.
2. Any unauthorized disassembly, modification or change of parts.
3. Any damages caused by improper use of the product including soaking, corroding, falling down, squeezing or exposure to abnormal temperature or humidity.

Model Number:
Date of Purchasing:
User's Name:
User's Phone:
User's Address:
Shop's Name:
Shop's Address:
Comments: