
Quick Installation Guide

1 Download the Meross app.





2 Plug MSS110 into an outlet near main WiFi.*



^{*} Proximity to main WiFi is required only during the initial setup process.


3 Open Meross app and simply follow the inbuilt setup wizard for configuration.



Relocate MSS110 into a desired outlet, no configuration is required.

^{*} MSS110 only supports 2.4GHz networks.

LED and Button Rules



LED Solid amber:

Initialization/ Reset/ Firmware

upgrading mode.

Flashing amber and green slowly:

Configuring mode.

Flashing green rapidly:

WiFi connecting mode.

Solid green: Successfully connected, and the socket is at ON status.

Solid red: No Internet connection,

and the socket is at ON status .

Off: The socket is at OFF status or the MS110 is powered off.

Press to turn the socket ON or OFF.
Press and hold (for 5 seconds) until LED is lit a solid amber to initiate factory reset process.

Frequently Asked Questions

- What devices can I control with the Smart Plug Mini? You can control lights, fans, humidifiers, portable heaters, and any small appliances in accordance with MSS110's specifications (up to 15A output).
- What should I do when the LED is lit a solid red?

A solid red indicates no internet connection.

You can troubleshoot the following:

- · Check the main WiFi's internet connection.
- · Make sure that main WiFi's password hasn't been changed.
- · Make sure your MSS110 is not too far from the main WiFi.
- · Factory reset MSS110 and try to add it again.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.