


UUD ARIES Operation Manual



UUD Aries Bluetooth Speaker Specification: Frequency range: 2.4GHZ-2.48GHZ

Speaker: power: 22W

Distortion: $\leq 1.0\%$

Frequency range: 40-20KHZ

The sound pressure level: ≥ 92dB

Working time: 10 hours maximum

Wireless range: 10-20M Bluetooth version: V4.2+EDR Support A2DP, V1.3, AVRCP, V1.6, HFP, V1.7, HSP, V1.2. USB2.1 play support APE/FLAC/MP3/WMA/WAV. (APE supports FAST/NORMAL, 800-1000KBPS FLAC support LO-L8. 1000-1200KBPS) Bluetooth play time: longest 8 hours, Talk time: 16 hours Microphone directivity: all directional Microphone sensitivity:-38dB Basic parameter: Size: 218*89.5*112mm Weight: 980 grams Speaker: NdFeB magnet 45 mm[4.00] * 2 Woofer: NdFeB magnet 70 mm [4.0Ω]

Name of Bluetooth (UUD ARIES)

Mode indicator light: BT: blue light, USB: green light and AUX: purple light Backward Key: short press for last song PLAY key (short press to play/ pause/answer.long press to open Mobilte

Forward Key: short press for next song

V- Volume minus V+ Volume plus

phone voice assistant)


Microphone: for Bluetooth call use.

Mode Functions: Long press/BT(blue light), USB(green light) and AUX(purple light). Short press for change RGB lamp and breathing lamp. Charging Indicator light: The red and blue light are charging or full

USB Flash Disk: support lossless music such as APE, WAV, FLAT-etc. TYPE - C charging interface(support SV,1-3A) U disk (support USB2.1 play)

Power: press button 2 seconds for turn on or off

AUX input (external audio input)



Front Touch Panel Explanation

connector Explanation: 10: TYPE-C charging button 2 seconds interface(support 5V for turn on or off. 1-3A) _ ____

13: AUX input (external

audio input)

Back Panel button and

000 -


11: USB Flash Disk:


such as APE, WAV. FLAC-etc.


support lossless music


9: Charging Indicator light: The red and

blue light are charging or full











RF Exposure Information and Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

This device complies with part 15 of the FCC rules and RSS-247 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.