

# HIFI acrylic wireless charger

## TECH SPECS:

Input: 5V3A, 9V2.2A


Output: 5W/7.5W/10W/15W(Phone)

Output: 2.5W(Watch)

Max Output: 20W

Material: Acrylic

## PRODUCT OVERVIEW:



\*Connect USB-C charging cable to USB-C connection point.  
Connect other end of cable to a suitable power source.

- ❶ Phone and earbuds wireless charging surface
- ❷ Wireless watch charger
- ❸ USB-C connection point

## USING THE ACRYLIC WIRELESS CHARGER

Connect the included USB-C charging cable to the USB-C port on the charging pad

Plug the other end of the charging cable into an appropriate power source.

Place your wireless charging enabled device over the center of the copper coils on the charging pad with the screen facing up. The charging pad will glow with a white light to indicate a successful charging connection.

The wireless charger will flash the white LED light 3 times when power is connected. The LED light will also display for 25 seconds after successful connection to device and then turn off.

Your device will continue to charge after the LED light has turned off.

\*Note: The wireless charger will display the white LED light to indicate a successful wireless charge connection. This function cannot be turned off. The white LED light will be illuminated for approx. 25seconds and then it will shut off automatically.

## TROUBLESHOOTING:

### **Device not charging**

- Make sure your device is wireless charging compatible
- Make sure the charging pad is connected to a working power source
- Make sure that your wireless charging capable device is positioned properly on the top side of the charging pad
- Make sure there are no other objects on the charging pad
- Remove your device's protective case. This could block a wireless charging signal

### **Device charging slowly**

- Your device may charge more slowly with the charging pad than with a charging cable. This is normal behavior
- Make sure your device is positioned in the center of the charging pad
- If multiple devices are charging at once, the wattage will naturally be lower causing your devices to charge slower

## **SAFETY INFORMATION**

- Do not attempt to disassemble the product. It may result in short-circuit or damage
- The product should be kept in a dry and ventilated environment. Do not store it in areas with high humidity or temperature
- Keep out of reach of children

**This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**

**FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help