倍思智能 T2 挂绳款防丢器

Baseus Intelligent T2 Rope Type Anti-loss Device

产品使用说明书

Operation Manual of Product



使用产品前请仔细阅读本说明书,并妥善保管 Please read the instruction manual carefully before using the product and keep it with proper care

产品介绍

用户可通过防丢器和手机 APP 互联, 防止物品丢失或及时找到物品。每个防丢器只有一个主 人, 主人可通过 APP 进行授权管理。一键寻物、防丢提醒、屏蔽设置、解除绑定。 使用场景:钥匙上/钱包里/旅行箱里/重要文件里等。

Product introduction

Users can prevent items from being lost or find items in time by connecting the anti-loss reminder with the mobile phone APP. Each anti-loss reminder has only one owner, and the owner can manage authorization through APP. One-key searching, anti-loss reminding, shielding setting, unbinding.

Application scenario: key/wallet/suitcase/important documents, etc.

产品特点

一键寻物:找寻物品,找寻手机,分享防丢器
防丢功能:物品防丢,手机防丢,双向防丢
屏蔽设置:屏蔽区域(手机定位一定范围内不提醒),屏蔽时间(设置某个时间段不提醒)
解除绑定: APP 操作,防丢器解绑


Product features

One-key searching: searching for items and mobile phones and sharing anti-loss reminder Anti-loss function: anti-loss of items and mobile phones, two-way anti-loss Shielding settings: shielding area (no reminders within a certain range of mobile phone positioning), shielding time (setting a certain period of time to switch off reminder) Unbinding: unbind anti-loss reminder via APP

产品参数 产品材质: PC 产品尺寸: 37*25*6mm 产品净重:5g 额定电压: 3V 额定电流: 3.3mA 额定功率: 10uW 音量: 80-100dB 电池: 75mAh 3V 工机时间: 6个月以上(按每天使用 15 次计算) 通讯距离: 空旷室外 30m, 扩宽室内 30m, 普通室内环境 10m 配件: 挂绳 x1 执行标准: GB4943.1-2011

Product parameters

Product material: PC Product size: 37*25*6mm Net weight: 5g Rated voltage: 3V Rated current: 3.3mA Rated power: 10uW Volume: 80-100dB Battery: 75mAh 3V Working time: more than 6 months (calculated by 15 times per day) Communication distance: 30m outside the open space, 30m inside the widened space and 10m in the common indoor environment Accessories: Lanyard x1 Implementation standard: GB4943.1-2011



挂绳子 按键 出音孔 拆卸口

Product part name

Lanyard port Keys Sound output port Removal opening

下载客户端

在应用商店搜索"倍思智能"或扫描说明书的二维码下载安装 App。如第一次下载使用,请 点击"注册"按钮注册账号,如已有账号,则点击"登录"按钮。



Download client

Search for "Baseus intelligent" in the APP Store or scan the QR-code code in the instruction manual to download and install App. For the first download, please click the "Register" button to register your account, or click the "Login" button if you already have an account.

连接设备

- 下载完成 APP, 打开"蓝牙功能和定位功能"。
- 打开"蓝牙",点击"去设置"选项;打开"蓝牙"按钮,打开"地理位置",点击"去设置"选项;打开"位置信息"按钮。
 *连接设备时,请保持网络流畅。

·连按设备旳,		
≝o≝al*al\$@ 後N(053% ■□ 18:10	■• ⁴ .4 ³ .4 % ♥ () 0%\$53%■O	18:10
X	\leftarrow Bluetooth	
Please Turn on Bluetooth	Bluetooth Currently visible to nearby devices	0
	Device name HUAWEI P	20 >
	Received files	>
	PAIRED DEVICES	
*	GEELY_BlueTooth	ŝ
	↓ wangerchao1234的家	ŝ
	(j) A5	
	Show more $ \smallsetminus $	
	AVAILABLE DEVICES	$^{\circ}$
	Redmi	
Required to connect with your Baseus. Help you to find it when lost	Smart Lock	
	Smart Lock	
Go to Settings	Baseus T2	
	X ⑦ Stop Help	
Io ^u .al ^a .al 完 世 ♀		18-11
X		()
Please Choose Always	Access my location Allow selected apps to access your location. Statement About Location Services and Privacy	D
	Advanced settings	>
	RECENT LOCATION REQUESTS	
	 Amer	
	Amap	>
 ♥ 	Low battery use	>
e	Low battery use Baseus High battery use Baseus Smart	>
>	Low battery use Baseus High battery use Baseus Smart High battery use, using location service	
(Low battery use Baseus High battery use Baseus Smart	>
Required to located your Baseus's location	Low battery use Baseus High battery use Baseus Smart High battery use, using location service Coogle Play services	>
Required to located your Baseus's location when lost.	Low battery use Low battery use High battery use High battery use Google Play services Low battery use HUAWEI Assistant	>
Required to located your Baseus's location when lost.	Low battery use Low battery use	>
when lost.	Low battery use Low battery use High battery use High battery use Low battery use Low battery use Low battery use HUAWEI Assistant Low battery use High battery use High battery use	> > > >

Connect to device

- After downloading the APP, open the "Wireless function and location".
- Open "Wireless" and click "Settings" option; Turn on the "Wireless", open the "Geographic location" and click the "Settings" option. Turn on the "Location information".

* Please keep the network smooth when connecting to device.

- 进入首页,点击右上角的 "+",绑定你的设备。
- 进入"添加设备"页面,点击"倍思 T2"添加设备。
- 添加完成后,将设备靠近手机,长按"按键"3秒,直到听到"哔"的一声。
- 设备连接完成,点击查找。

@ = ".d	Hs#N● 0300% ■1731 Baseus Smart +	©ा स्थल क छ। X Add a Device	∜\$05% ■017.31	Add Baseus T2	ଷା≱0.5% =) 17:32 ସି•ିଲା ⁸ ଲା ବିଶାଷା ● <	© \$ 056% ==) 1749
	Click to Add Your First Device :)	Baseus T1	Add		Baseus T2 Connected	
		Baseus T2	Add	Baseos		
		Smart Lock	Add	Step1 Firmlu press the button for you hear "BI" sou Step2 Place Baseus device near	und.	0
						arby ∞■
						Find

•

- Go to home page and click the "+"in the upper right corner to bind your device.
- Go to the page of "Add device" and click "Baseus T2" to add the device.
- After the device is added, place the device close to the mobile phone and press the "Key" for 3 seconds until you hear the "Beep".
- Device connection is completed, click find.

设备设置

- 进入"设备连接完成"页面,点击"防丢器头像",进入"查找"页面。
- 点击右上角"设置"按钮,进入"设备设置"页面,更改头像和设备名称。

™ "র ≈ এ হা ় — Baseus Smart	ଞଃହଽଽ୬ ≡େ 17:49	७३०५६% ■ 17:49	ଅତ୍ୟାଳ୍ୟାର୍ଲ୍କରାଢ Contraction Contraction	ଷ≭©56% ∎ି) 17:50	≊ைங்கைல⊳ く Device Setting	©≭©56% ≡0 17:50 gs
Baseus T2 Connected	Baseus T2	Γ2	Avatar		Avatar	
	Connected		Name	Baseus T2	Name	Baseus T2
\sim			Battery	32% 🗖	Battery	32% 🗖
Betons	C		Alert	>	🌲 Alert	>
Find	Валесо	0	Firmware:1.0.1 MAC:30f7d70187fb		Firmware:1.0.1 MAC:30f7d70187fb	
	Ν	learby ₃2% ■				
		Find	Remove De	vice	Remove I	Device

•

Device settings

- Go to the page of "Device connection complete" page, click "Anti-loss reminder avatar" and go to the "Find" page.
- Click the "Settings" button in the upper right corner to enter the page of "Device settings" to change the avatar and device name.

报警模式

 在"设备设置"页面,点击"报警模式",进入"报警设置"页面,开启或者关闭手机 警报响铃、防丢器警报响铃。

🖾 o ".d	×41 ⊗ ⊕ 🕅 🗢	७३056% ∎0 17:50	□ ¹⁴ .d ¹ .d S & N ● (3 ★ 0.56% =) 17.38	: ■ ¹¹ .41 % ⊕ 🕅 🛛 🗇 🗇 🖏 🖉 30 58% 💷 17:38	
<	Device Settings		Taking scrolling screenshot · · Touch scrolling and to end	Taking scrolling screenshot	
8	Avatar		Phone Alert Ringtone	Phone Alert Ringtone	
	Name	Baseus T2	phone will make alert.	phone will make alert.	
	Battery	32% 🖿	Ringtone Option	Ringtone Option >	
	Alert	>	Device Alert Ringtone	Device Alert Ringtone	
Firmware:1.0.1 MAC:30f7d70187fb			Enable: When they're disconnected, the device will make alert. *It will influence the lifespan of the device's battery when always enable.	Enable: When they're disconnected, the device will make alert. *t! will influence the lifespan of the device's battery when always enable.	
			Do Not Disturb Mode	Do Not Disturb Mode >	
	Remove Devi	ce	Tips	Tips	
			nWhen out of the Do Not Disturb zone, the device and the phone will alert following your settings.	nWhen out of the Do Not Disturb zone, the device and the phone will alert following your settings.	

Alarm mode

• Go to the page of "Device settings", click "Alarm mode" to enter the page of "Alarm settings", and turn on or off the alarm ringing of the mobile phone and the alarm ringing of the anti-loss reminder.

报警模式(设置手机响铃音效)

● 点击"手机响铃音效",调节手机响铃音效,选择你想要的铃声。

Alarm mode (set sound effect of phone ringtone)

• Click "Ringtone sound effect" to adjust the ringing sound effect of mobile phone and select the ringtone you want.

In "	D 17:38	● Ø & S h. ^s h. ^s a	७३०58% ■0 17:39
Taking scrolling screenshot · · Touch scrolling area to end		Kingtone Option	
Phone Alert Ringtone Enable: When they're disconnected, the	•	default	۲
phone will make alert.		electron	0
Ringtone Option	>	limpid	0
Device Alert Ringtone			
Enable: When they're disconnected, the device will make alert. *tt will influence the lifespan of the device's battery when always enable.	•		
Do Not Disturb Mode	>		
Tips			

nWhen out of the Do Not Disturb zone, the device and the phone will alert following your settings.

报警模式(设置勿扰模式)

- 点击"勿扰模式",添加免打扰区域,设置名称、免打扰时间、免打扰区域。
- 设置完成, 点击右上角"保存"按键。

□ ¹ al ² al ² 3 (1) 0 17:38	■6 ".dl ?.dl ?? db <> ▲ ■18:50	Image: Solution and Solutio	■ ".d ".d ?? @ (10) ○ (0) * ○ 58% ■) 17:40
Taking scrolling screenshot · · Touch scrolling area to bind	C Do Not Disturb Mode	< Edit 🔲	< Edit 🔲
Phone Alert Ringtone	Add Do Not Disturb zone In the Do Not Disturb zone, both the device and the phone	Name Zone1	Name Zone1
Enable: When they're disconnected, the phone will make alert.	won't make alert.	Do Not Disturb Zone	Do Not Disturb Zone
Ringtone Option >		Do Not Disturb Place	Do Not Disturb Place
Device Alert Ringtone			
Enable: When they're disconnected, the device will make alert. *tt will influence the lifespan of the device's battery when always enable.			
Do Not Disturb Mode	_		
Tips		Radius: 200 feet	Radius: 200 feet
nWhen out of the Do Not Disturb zone, the device and the phone will alert following your settings.		Google	Google

Alarm mode (set do not disturb mode)


• Click "Do not disturb mode" to add the DND area and set the name, DND time and DND area.

When the setting is completed, click the "Save" button in the upper right corner.

拆换电池

拿起防丢器,找到拆卸口,用指甲稍稍用力打开机身更换电池,更换完成后,盖上后盖,稍

稍用力卡住,完成操作。



Change the battery

Hold the anti-loss reminder, and find the removal opening, open the reminder slightly and replace the battery with fingernails. After the replacement is completed, cover the rear cover and jam slightly to complete the operation.

注意事项

本产品请勿在潮湿环境下使用。 本产品非玩具、请让儿童远离本设备,以免误食。 清洁本产品请勿使用液体,喷雾清洁剂或湿布进行清洁。 使用时远离水源、和热源,以免损坏产品并产生安全隐患。

Important notice

Do not use this product in humid environment.

This product is not a toy, please keep it away from children to avoid eating by mistake.

Do not use liquid, spray cleaner or wet cloth to clean this product.

Keep away from water sources and heat sources when using, so as not to damage products and pose potential safety hazards.

QA 小问答

Q&A:

手机和防丢器的提醒距离是多少米?

答:设备与手机的有效连接距离室内约 10-20 米,室外 20-40 米,可能受周围环境和障碍物 影响有不同程度的变化,比如电磁波、水、金属等。所以在人很多拥挤的地方,蓝牙信号距 离会变短,开阔的地方,蓝牙距离就可以变长。 What is the reminding distance between the mobile phone and the anti-loss reminder?

A: The effective connection distance between the device and the mobile phone is about 10-20 meters indoors and 20-40 meters outdoors, which may vary in different degrees due to the influence of the surrounding environment and obstacles, such as electromagnetic wave, water, metal, etc. Therefore, the wireless signal distance will be shorter in crowded places, and it can be longer in open places.

为什么防丢器在手机旁边却无法连接?

答: 这种情况有可能是手机蓝牙通信阻塞。

- 请做以下操作:
- 1. 请尝试重启 APP。
- 2. 请尝试重启手机蓝牙。
- 3. 请尝试重启手机。
- 4. 请确认防丢器电池使用时间。

Why can't the anti-loss reminder can't be connected beside the mobile phone?

A: This may be caused by the blocking of wireless communication on the mobile phone.

Please perform the following steps:

- 1. Please try to restart the APP.
- 2. Please try to restart wireless.
- 3. Please try to restart your mobile phone.
- 4. Please confirm the battery level of the anti-loss reminder.

设备多久耗尽电量?

答: T2 型号正常待机 6 个月以上, 跟进用户使用环境和客观因素可能有不同程度的变化, APP 中有电量提醒功能, 用户可根据使用情况为产品更换对应型号电池。

How long can the reminder last from its battery?

A: T2 model can last for more than 6 months in normal standby. It may vary with user's application environment and objective factors, there may be different degrees. APP is featured with battery level reminder, and users can replace the battery of the corresponding model for the product based on the usage conditions.

一个手机最多可以绑定几个防丢器?

答: 一个安卓手机一般可以同时连接 4 个蓝牙设备, 一个 iP 手机一般可以同时连接 6 个蓝 牙, 但一个防丢器只可以同时绑定一个手机。

What's the maximum number of anti-loss reminders one mobile phone can be bound with?

A: An Android phone can connect 4 wireless devices at the same time, while an iP mobile phone can connect 6 wireless devices at the same time, but an anti-loss reminder can only be bound to one phone at the same time.

手机与防丢器的蓝牙连接断开,没有收到提醒?

答: 请检查以下内容:

- 1. 是否在 APP 页面打开防丢器警报功能。
- 2. 是否在设置-通知里面把通知功能打开。
- 3. 是否在设置-通用-后台应用启动中,给 APP 权限。
- 4. 手机蓝牙是否一直保持开启。

Why didn't I receive any reminder when the wireless connection between the mobile phone and the anti-loss reminder was lost?

A: Please check the following items:

1. Check whether you have turned on the anti-loss alarm function on the APP page.

2. Check whether the notification function is turned on in the Settings-Notifications.

3. Check whether the APP is given the necessary permissions from Settings-General-Background App Running.

4. Check whether the wireless of the mobile phone is always on.

怎么删除防丢器?

答:删除设备须在 APP "设备设置"页面最底部点击移除设备。

How do I remove the anti-loss reminder?

A: To remove the device, click "Remove device" at the bottom of the APP "Device settings" page.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.