True Wireless Earbud and Mic

Instruction Manual 7198-06



- 1. LED indicator
- 2. Multi-Function Button
- 3. Earbud
- 4. Charging port

What's included:

- 1 x True Wireless Earbud and Mic
- 1 x USB to 2.0mm Charging Cable
- 1 x Carrying Pouch
- 1 x Instruction Manual

Tech Specifications


- Product size: 30 x 16 mm
- Bluetooth version: 4.2
- Earbuds driver unit diameter: 14mm
- Rated output power:5mW
- Max output power:10mW
- Frequency response: 20Hz-20K Hz
- Built in 40mAh/3.7V lithium polymer battery
- Charging input: 5V/100mA
- Playback time at max volume: 90 minutes

Instructions:

- Press the Call button for 5 seconds until the LED Light flashes Red & Blue and you hear a voice prompt saying. "Enter Pairing". Once in pairing mode, turn on your Bluetooth mode on your smartphone/tablet and connect to "True Wireless". Once connected you will hear a voice prompt saying "Connected Successful".
- Music player: tap the call button to stop the music or continue to play music.
- Receive or make a call : when there is a call , the Bluetooth Earbuds will ring. Tap the call button to answer or reject a call .
- Call the last phone number : pressing the call button twice will automatically call the last phone number.
- Charging: Please use 2.0mm charging cable provided. The LED light will be a solid red when the earbud is charging. When the earbud is fully charged the LED light will turn Blue. It takes 2 hours to charge the Earbuds fully.
- Attention: The earbud is only suitable for the right ear.

SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed, including the following:
- Read all the instructions before using the product.
- Device main unit contains an internal lithium-ion battery. Upon initial use or after a prolonged storage period, fully charge it once.
- The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- 5. Do not expose the device to moisture.
- Use of a power supply or charger not recommended or sold by device manufacturer may result in a risk of fire or injury to persons.
- Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
- Do not use the device if damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
- Do not expose a device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
- Have services performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- 12. Do not charge the device while using the





FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.