









<h2>Wyze Sense Starter Kit</h2> <h3>QUICK START GUIDE</h3>	<h3>IN THE BOX</h3> <ul style="list-style-type: none"> Wyze Contact Sensor (battery pre-installed) x2 Wyze Motion Sensor (battery pre-installed) x1 Wyze Sensor Bridge x1 Quick Start Guide x1 Pin x1 <p style="text-align: center;">1</p>	<h3>Wyze Contact Sensor (WHCS1)</h3>  <ul style="list-style-type: none"> 1 Reset button 2 Status Light <p style="text-align: center;">2</p>	<h3>Wyze Motion Sensor (WHMS1)</h3>  <ul style="list-style-type: none"> 1 Status Light 2 Reset button <p style="text-align: center;">3</p>	<h3>Wyze Sensor Bridge (WHBS1)</h3>  <ul style="list-style-type: none"> 1 Status Light 2 USB <p style="text-align: center;">4</p>
<h3>SETUP</h3>  <ol style="list-style-type: none"> Ensure your Wyze Cam or Wyze Cam Pan is setup, online, and has the most updated firmware. <p style="text-align: center;">5</p>	<ol style="list-style-type: none"> Insert the Sensor Bridge into the USB port of a Wyze Cam or Wyze Cam Pan and wait for the Status Light to turn solid blue.  <p style="text-align: center;">6</p>	<ol style="list-style-type: none"> Open the Wyze app and tap the 3 dots on the top right corner of the Home Page. Select "Add a Product" and then select the Sensor type you want to setup first. Follow the instructions in the Wyze app to finish setup.  <ol style="list-style-type: none"> Repeat Step 3 for each Contact and Motion Sensor. <p style="text-align: center;">7</p>	<h3>CONTACT SENSOR PLACEMENT</h3>  <p>Ensure the two sections of the Contact Sensor are at most 2 cm apart when closed.</p> <p style="text-align: center;">8</p>	<h3>MOTION SENSOR PLACEMENT</h3>  <p>Place Sensor approximately 6 feet high and ensure the Wyze Logo is in the top left corner.</p> <p style="text-align: center;">9</p>

<h3>STATUS LIGHT</h3> <h4>Bridge</h4> <ul style="list-style-type: none"> Solid yellow light The Bridge is powered on, but not connected. Remove the Bridge, make sure the camera is online, has the latest firmware, and then reinsert the Bridge. Flashing yellow/blue light The Bridge is trying to connect. If <p style="text-align: center;">10</p>	<p>it doesn't turn solid blue after several minutes check to ensure your camera is online and has the latest firmware. Remove the Bridge, wait for camera connection to be stable, then reinsert the Bridge.</p> <ul style="list-style-type: none"> Solid blue light The Bridge is working properly. Flashing blue light The Bridge is pairing to a sensor. <p style="text-align: center;">11</p>	<h3>Sensors</h3> <ul style="list-style-type: none"> Red light Sensor triggered <h3>TROUBLESHOOTING</h3> <h4>The Sensor Bridge isn't connecting</h4> <p>Ensure your camera is online, has a stable connection, and the latest firmware. If problems persist, remove</p> <p style="text-align: center;">12</p>	<p>the Bridge from your camera, wait 30 seconds, and then reinsert into the camera.</p> <h4>A sensor won't connect to the Bridge</h4> <p>Ensure the Bridge is solid or flashing blue and the camera has a stable connection. If problems persist, try moving the camera closer to the sensor (we recommend sensors are placed on the same floor as the Bridge).</p> <p style="text-align: center;">13</p>	<h4>A sensor isn't working properly</h4> <p>Ensure your camera is online and has a stable connection. Replace the sensor's battery if its status light doesn't blink when triggered.</p> <h3>NEED MORE HELP?</h3> <h4>Resources & Support</h4> <p>support.wyze.com</p> <h4>Community</h4> <p>forums.wyze.com</p> <p style="text-align: center;">14</p>
<h3>FCC Statement</h3> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in</p> <p style="text-align: center;">15</p>	<p>accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -- Reorient or relocate the receiving antenna. -- Increase the separation between the <p style="text-align: center;">16</p>	<p>equipment and receiver.</p> <ul style="list-style-type: none"> -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help <p>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p style="text-align: center;">17</p>	<h3>IC Statement</h3> <p>This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:</p> <ol style="list-style-type: none"> (1) This device may not cause interference; (2) This device must accept any interference, including interference that may cause undesired operation of the device. <p>The term "IC," before the certification/registration number only signifies that the Industry Canada technical specifications</p> <p style="text-align: center;">18</p>	<p>were met. This product meets the applicable Industry Canada technical specifications.</p> <p>Le présent appareil est conforme aux CNR d'Industrie Canada applicable aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement</p> <p style="text-align: center;">19</p>