Product Name

Fm transmitter and Car charge

Introduction

FM transmitter wirelessly connects your phone or MP3 to your car stereo easily over FM radio waves, let you enjoy the high quality music of your phone or other devices. At the same time, it can charge for other devices by USB output slot.

Features

- * Plays music from your phone or other audio devices on your car stereo system using FM transmitter.
- * Autoscan function automatically finds the clearest frequency.
- * Full frequency range.
- * Memory for last frequency.
- * Powered by the car's power source.
- * Charges your mobile or other devices through USB outlet.

Specifications

- * Frequency: 88.1-107.9MHz
- * Distortion: \leq 0.5 %
- * Operating current: 20±3mA
- * Input voltage: DC 12V
- * Output:5V, 1A
- * Dimensions: W 75 x H 35 x D 12 (mm)
- * N.W.: 43g

Compatible with

* All iPod, iPhone, iPad and other audio devices with 3.5mm audio socket

Operation

1. Connect the FM transmitter to your compatible device and plug the car charger to your cigarette lighter. When the transmitter is powered on, the displaying the default screen interface shown below:




- 2. Play music on your phone.
- 3. To manually tune:
- a. Tune the car's FM stereo to a clear frequency.
- b. Tune the transmitter to the same frequency by using the "CH+" or "CH-" buttons.
- 4. To automatically scan for the best clear frequency:
- a. Press the autoscan button(S).
- b. Tune the car's FM stereo to the same frequency.

5. To automatically store the three best frequencies in memory, press the autoscan button**(S)** down for 3 seconds.

AUTOSCANING ...

The transmitter displays the three best frequencies and automatically saves them to memory. Then the screen will display one of the stored frequencies.

English



6. To tune to a frequency in memory:

a. Press the "M" button. The display shows the three stored frequencies "M1, M2, or M3". (If you don't press one of the memory buttons ("M1, M2, M3") within 5 seconds or press "M" button again, the screen back to the default screen.)

b. Select one of the above frequency by CH+/CH- and confirm by "(S)".

c. Tune the car's stereo to the same frequency.

7. If the FM signal is interrupted, please reset the car radio and the FM transmitter to another clear frequency.

Notes: This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to Part 15 of the FCC Rules. These limits

are designed to provide reasonable protection against harmful

interference in a residential installation. This equipment generates, uses

and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference

to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

This device and its antenna(s) must not be co-located or operation in

conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.