

MODEL

6535: TraceableGO™ Datalogging Thermometer

6537: TraceableGO™ Datalogging Hygrometer



Figure 1: 6535 (left), 6537 (right)

Dimension L x H x D: 3.5 x 2 x 0.79" (89x51x20mm)

TEMPERATURE

Operating Range: -20 to 60°C

Resolution: 0.1°C

Accuracy:

6535: ±0.4°C

6537: ±0.4°C between -10 and 60°C, otherwise ±0.5°C

RELATIVE HUMIDITY (6537 ONLY):

Range: 0% to 95%RH, non-condensing

Resolution: 0.1% RH

Accuracy: ±3% RH between 5 to 75%, otherwise ±5% RH

BATTERY

• 2 AAA Alkaline batteries (3.0V)

Battery Level Indication:

Battery level	LCD symbol
≥ 80% (2.78V)	
≥ 60% (2.56V), < 80%	
≥ 40% (2.34V), < 60%	
≥ 20% (2.12V), < 40%	
≥ 10% (2.01V), < 20%	
< 10% Flashing	

Note: Battery level is updated every 5 minutes.

Note: Once battery level drops to below 10%, device may not work properly. Replace batteries immediately.

Note: When replacing batteries, after removing the old batteries, wait 10 seconds before inserting new batteries. Otherwise, Bluetooth may not work properly.

MEASUREMENT READING UPDATE FREQUENCY

Temperature and humidity: 5 seconds;

Note: If a reading is out of operating range, the corresponding location on LCD will display '---', and such out of range reading will not trigger alarm.

DATA LOGGING FREQUENCY

5 min by default, user-adjustable between 1 minute and 12 hours with 1 minute step.

DATA STORAGE CAPACITY

Alarm: most recent 90 Alarm events

Data: 64K (65536) data points, 7.5 months on 5-minute logging interval

Note: If maximum number of alarm events is reached, device will overwrite the oldest alarm events.



Figure 2 Device not initialized

DEVICE OPERATING MODES

- IDLE Mode: First time battery inserted, and device has not been configured;
- STANDBY Mode: Device has been configured, but not started;
- RUN Mode: Device starts to measure and log data.
- STOP Mode: Device stops from RUN Mode. In STOP Mode, device does not update measurements or log data, and the last measurements are displayed.

VIEW CURRENT READING

1. Temperature ONLY unit: Current reading, minimum/ maximum reading, run time/alarm time toggling. Memory mode are shown on LCD.
2. Humidity and Temperature unit: Current temperature/humidity reading toggling every 5 seconds, minimum/maximum reading since last clearing, run time/alarm time, Memory mode are shown on LCD.

VIEW CURRENT MIN/MAX

Temperature ONLY unit: Current temperature Min/Max values are displayed on LCD.

Humidity and Temperature unit: Current temperature/humidity Min/Max values are toggled display.

Note: Every time device is configured, or resumes to run from STOP Mode, Min/Max values are reset.

VIEWING RUN TIME/ALARM TIME

Run Time/Alarm Time is toggled to display on LCD. If Run Time is displayed, LCD symbol RUN TIME appears; if Alarm Time is displayed, LCD symbol ALARM TIME appears.

Note: Alarm Time is accumulated for both Low Alarm and Hi Alarm for each channel (temperature, humidity).

VIEW MEMORY USAGE, CURRENT DATE/TIME, DEVICE'S SERIAL NUMBER

1. Press and release START/STOP button

2. Memory usage and percentage is shown on LCD.

The percentage indicates how much internal data memory storage has been used;

3. Number of days, hours, minutes left till memory is full are also displayed on the second line;



Figure 3

4. Within 10 seconds, press START/STOP again, current date/time is displayed on device LCD. The following figure shows 9/14/2017, 17:30



Figure 4

5. Within 10 seconds, press START/STOP again, device S/N will be displayed on LCD.



Figure 5

6. To return to normal working status, press START/STOP again, or wait for 10 seconds and device will automatically go back to normal working status.

Note: If Memory Mode is set to WRAP WHEN FULL: LCD symbol starts to flash on the display when the memory is full. Once memory is full, the oldest data points will be overwritten with new data points.

If Memory Mode is set to STOP WHEN FULL: LCD symbol starts to flash on the display when the memory is 95% full. Once memory is full, the device will stop logging new data points.

ENABLE/DISABLE BLUETOOTH

1. Quick press twice START/STOP to enable Bluetooth, and Bluetooth LCD symbol appears;
2. Device starts to advertise to be found, and to be connected. Device Name shown on TraceableGO™ App discovered list looks like CC6535-xxxx, or CC6537-xxxx, where xxxx is the last 4 digits of device serial number.
3. If no connection has been made for ONE MINUTE, Bluetooth will be disabled to save battery life, and Bluetooth LCD symbol disappears, or quick press twice again to disable Bluetooth. To enable again, go to Step (1).

HOW TO SETUP DEVICE

Configure device before use

1. Enable Bluetooth on device.
2. Use TraceableGO™ App to connect to device.
3. Follow TraceableGO™ App instruction to configure device.
4. The following parameters are configured through TraceableGO™ App: START Mode, STOP Mode, ALARM Enable/Disable, Celsius/Fahrenheit, Memory Mode, Data Logging Interval, Alarm Setting.
5. Once device has been configured, device enters STANDBY Mode.

Note: While device is connected to our TraceableGO™ App, if no action has been taken for 5 minutes, device will terminate the connection from our TraceableGO™ App.

Note: If Memory Mode is set to WRAP WHEN FULL, appears on LCD; If Memory Mode is set to STOP WHEN FULL, MEM appears on LCD.

ALARM

1. Once an alarm is triggered by any of temperature, humidity out of set alarm range, LCD symbol **LOW ALM** and/or **HI ALM** starts to flash. An Alarm Event will be logged.
2. Pressing START/STOP once will clear the alarm, LCD symbol stops flashing. An Alarm Acknowledge Event will be logged.
3. If temperature, or humidity falls back to normal range, an Alarm event will be logged. If any of temperature, humidity measurement goes back to out of alarm range, alarm will be triggered again.

HOW TO START, STOP, AND RESUME DATA LOGGING

1. Devices are factory initialized with default setting:
 - START Mode: Push Start
 - STOP Mode: Push Stop
 - Memory Mode: Wrap when Memory is Full
 - Temperature Unit: Celsius
 - Data Logging Interval: 5 minutes
 - Alarm Enable/Disable: Enabled
 - Alarm Setting High Alarm:
 - Temperature: 8°C
 - Humidity: 75% RH (6537 only)
 - Alarm Setting Alarm Low:
 - Temperature: 2°C
 - Humidity: 25% RH (6537 only)
 - Date/Time is also set to current to central time.

Note: Devices are shipped with battery, powered on, and ready to use if using default setting. Without powered on, device will lose track of date/time.

Note: If a user intends to use device for different setting other than default, device must be re-initialized.

2. If device's START Mode is configured as **PUSH BUTTON TO START** (default), device LCD displays 'push to start' (Figure 4). Press and hold **START/STOP** until LCD symbol appears. Device enters RUN Mode. If device's START Mode is configured as **IMMEDIATE START**, device enters RUN Mode immediately. If device's START Mode is configured as **DELAYED TIME START**, delayed start time set by user is counting down on device LCD. Once the counting time reaches 0, device enters RUN Mode.



Figure 6

3. If in **RUN Mode**, LCD symbol **RUN** appears, and logs data at user-defined interval. If STOP Mode is configured as **PUSH BUTTON TO STOP**, press and hold **START/STOP** until LCD symbol **STOP** appears. Device enters STOP Mode. If STOP Mode is configured as **NEVER STOP**, device will ignore button press, and will stop when memory is full if Memory Mode is set to **STOP WHEN FULL**, or will stop when TraceableGO™ App is connected to device and downloads the data.

4. If in **STOP Mode**, press and hold **START/STOP** until LCD symbol **RUN** appears. Device enters RUN Mode and resumes to log data at current setting. Anytime device resumes to log data from STOP Mode, Min/Max values are reset.

Note: If device in STOP Mode, START Mode will be set to **PUSH BUTTON TO START** regardless of previous Start Mode Setting. If Delayed Start Mode is needed while device in STOP Mode, device must be re-configured.

Note: While device is connected to TraceableGO™ App, once Device has received command from App to upload data to App, device will stop logging data and enter STOP Mode if it is still in RUN mode.

CLEAR DATA MEMORY STORAGE

1. Data points stored in device internal storage can only be cleared through TraceableGO™ App.
2. Each time device is configured, all stored data points will be cleared.
3. Run Time/Alarm Time are also reset.

DOWNLOAD DATA

1. If device is not in STOP Mode, press and hold **START/STOP** for 3 seconds until LCD symbol appears. Device enters STOP Mode

-OR-

If Stop Mode is set to **NEVER STOP** and Memory Mode is set to **STOP WHEN FULL** and device is in RUN Mode, skip Step (1).


2. Quick press **START/STOP** twice to enable Bluetooth, and Bluetooth LCD symbol  appears. Device starts to advertise.
3. Connects to device through TraceableGO™ App. Once connected, device LCD displays 'ble connect':



Figure 7

4. Follow TraceableGO™ App instruction on how to download data from device. While data downloading is in process, device LCD displays 'dat upload_':



Figure 8

5. Once download process is complete, device LCD displays 'ble connect'.
6. User can view, export data through TraceableGO™ App.

Note: Full memory data downloading takes as little as 5 minutes to complete. The actual downloading time varies on how data logged, mobile device type, and distance between device and mobile device.

REGULATORY INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Hereby, Control Company, declares that this digital thermometer is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

WARRANTY, SERVICE, OR RECALIBRATION

For warranty, service, or recalibration, contact:

TRACEABLE® PRODUCTS

12554 Old Galveston Rd. Suite B230
Webster, Texas 77598 USA
Ph. 281 482-1714 • Fax 281 482-9448
E-mail support@traceable.com • www.traceable.com

Traceable® Products is ISO 9001:2008 Quality-Certified by DNV and ISO/IEC 17025:2005 accredited as a Calibration Laboratory by A2LA.

Cat. No. 6535, 6537

Traceable® is a registered trademark of Cole-Parmer.

©2018 Traceable® Products. 92-6535-00 Rev. 0 013118

TRACEABLEGO® DATALOGGER INSTRUCTIONS

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.