


Blackview

AirBuds 3


USER GUIDE

■ Product Overview



■ About the charging box


The charging box can be charged through the Type-C interface. The white light on the charging box flashes during charging. After the lid is closed, the earbuds are charged in the charging box.




■ Device Connectivity

First Pairing

1. Open the case and the wireless earbuds will automatically turn on. When entering the pairing state, the blue indicator light on the earbuds flashes alternately and quickly.



2. Turn on the Bluetooth on the device, select "AirBuds 3", and click connect.



Note: The above is the first pairing method. In subsequent use, the earbuds will be automatically turned on and connected after being taken out of the earbuds box.

■ Method of operation

	L Airbud	R Airbud
Play /Pause	Click twice	Click twice
Next song	Click 3 times	Click 3 times
Reply	Click twice	Click twice
Hang up	Click twice	Click twice
Refuse	Long press for 2 seconds	Long press for 2 seconds
Voice assistant	Long press for 2 seconds	Long press for 2 seconds
Reset	Click 4 times	Click 4 times

■ Specification

Model: AirBuds 3

Bluetooth Version: 5.1

Battery Type: Li-ion Ploymer(3.7V, 30mAh)

Bluetooth Frequency: 2.402GHz-2.480GHz

Bluetooth Transmission Modulation: A2DP, AVRCP, HSP, HFP

Dynamic Driver: 13mm

Dynamic Frequency Response: 20Hz-20KHz

Battery Capacity (charging box): 220mAh

Charging Time (charging box): <2hrs

Continue Time (headphone): About 5hrs

Charging Time (headphones): <1.5hrs

Bluetooth Effective distance: 10m

Storage Temperature: -20~70°C

Operating Temperature: -10~50°C

■ Indication of LED

Headphone Mode	Status
Turn on	The blue indicator light keeps flashing
Power off	The blue light lasts for 3 seconds and then goes out
Timeout standby when no device is connected	The blue light lasts for 3 seconds and then goes out
Bluetooth pairing	The blue indicator light keeps flashing
Connected	Blue light off
Low power	No light
The earbuds are in the charging box-fully charged	No light
Charging box-charging	The white indicator light of the charging box flashes slowly
Charging case-fully charged	The white indicator light of the charging box is always on
R / L Pair	The blue indicator light keeps flashing

■ **Answers for common questions**

(1) Bluetooth headset cannot be turned on.

Reason: The battery of the Bluetooth headset is low or dead.

Solution: Put the earphones in the charging case, close the cover and charge them for more than 1 hour before turning on the earphones.

(2) The phone cannot search for the Bluetooth earphones.

Reason: 1. The Bluetooth earphones are not in the power-on pairing state.

Reason: 2. There is a setting problem with the phone's Bluetooth.

Solution: 1. Put the earbuds back into the charging box, close the cover and open the cover, wear both ears, the earbuds (that is, the blue light flashes) enters the Bluetooth pairing;

You can also tap the earbuds 4 consecutive times (that is, the blue light flashes quickly) to activate Bluetooth pairing;

Solution: 2. Please restart your phone, and clear all the pairing data stored in Bluetooth, then search for Bluetooth again.

(3) No sound from earphones speakers.

Reason: 1. The earphone and mobile phone volume is inappropriate. e.g. the volume has been adjusted to the minimum.

Reason: 2. The Bluetooth headset is not properly connected to the mobile phone.

Reason: 3. The Bluetooth headset is not within the limited working range.

Solution: 1. When the earbuds is connected, press the phone to adjust the volume.

Solution: 2. Bluetooth and mobile phone re-pair connection.

Solution: 3. Keep the earbuds within 10 meters of the mobile phone and use it without obstructions such as bulky objects and walls between the earbuds and the device.

(4) The earphone cannot convey the voice or the voice is very low.

Reason: 1. The Bluetooth headset is too far away from the mouth.

Reason: 2. The Bluetooth microphone hole is blocked or water has entered.

Solution: 1. The Bluetooth headset should be worn on the ear for normal use.

Solution: 2. Remove the blockage of the microphone hole or prevent water from entering it.

(5) Possible reasons why the earbuds caton or disconnects during a call or listening to a song :

Reason: 1. The Bluetooth earbuds is too far away from the phone or there are obstacles.

Reason: 2. There is a problem with the Bluetooth signal of the mobile phone or there is strong signal interference nearby.

Reason: 3. Bluetooth earbuds power is low, please charge the earbuds as soon as possible.

Solution: 1. Keep the earbuds within 10 meters of the mobile phone, and there are no large objects and walls between the earbuds and the device, and be careful not to cover the Bluetooth earbuds with your hands. In order to maintain the continuous stability of the signal, please try to keep the Bluetooth and mobile phone in Same direction.

Solution: 2. It is best to keep metal objects away from the phone. You can also try another phone or another place.

Solution: 3. Please charge the earbuds as soon as possible.

(6) The headset is not disconnected after closing the earphones box.

Reason: 1. The charging box is completely out of power.

Reason: 2. If the headset is not put in the box correctly, it will cause abnormal communication between the headset and the base.

Reason: 3. The charging box is damaged.

Solution: 1. Charge the charging box

Solution: 2. Reopen the charging case and take out the earphones. Put the earphones in the charging case again and close the cover. The charging box flashes green once and the cover is closed.

Solution: 3. Replace the charging box.

(7) The earphone is silent during the call , the sound comes out of the phone.

Reason: The earphone was operated when the call incoming or during the call, and the headset was double-clicked.

Solution: Turn off the mobile phone's Bluetooth then turn it on again, or put the earphones into the case and close it, then open the earphone case again ; the earphone does not support the voice call connection or voice call hang up. When there is a voice call, please operate it on the mobile phone.

■ Attention

- Please do not disassemble this product by yourself.
- Please use standard charging cable and adapter to avoid damage and accidents.
- Please avoid using corrosive cleaning detergent to clean this product.
- Please avoid product usage in the rain and keep away from heating or fire.

■ Maintenance

Please follow the following suggestions to prolong product working life.

- Keep product dry and don't put in damp places in case of affecting internal circuit.
- Avoid product usage during intense sporting or on sweating occasions in case sweat infiltrate into product and cause damages.
- Keep off sunlight or high temperature in case of shortening working life of electric parts battery damage, plastic parts deformation.
- Keep off intense vibration and impact from hard material in case of internal circuit damages.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device(FCC ID: 2APMJ-AIRBUDS3) has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Due to product design, FCC ID can only be printed on the charging box.