



What's in the Box?

Check to make sure you have everything below.



1. AC Adapter
2. Power Cable
3. 14 Inch Laptop
4. Cleaning Cloth
5. QSG

Get to Know Your Notebook




1. Micro SD slot
2. Power light
3. Audio jack
4. USB port
5. Power connector
6. USB Type-C port
7. AC adapter and battery light

7. Internal microphone
8. Camera
9. Power button
10. Touchpad

Let's Get Started!

01

Charge your device by connecting your laptop to a wall outlet with the provided adapter & power cable.



Power On

02

Press power button to power on .



Initial Setting & Connect to Wifi







03


Follow these 7 steps to get your device up and running.

- Step 1: Select language.
- Step 2: Select country.
- Step 3: Select keyboard layout.
- Step 4: Connect to your preferred wifi.
- Step 5: Review the license agreement.
- Step 6: Account & security settings.
- Step 7: You are finished and can now enjoy your new laptop.

About Windows Start Screen

You can use a keyboard & mouse or trackpad to navigate the windows start screen.

- Find Settings**
Select the Start button , and then select the Settings icon .
- Shut down your computer**
Select the Start button , select the Power icon , and then select Shut down.
- Display the Start menu**
Select the Start button , in the lower-left corner of the taskbar.
- Search**
In the taskbar search box, begin typing the name of an app, setting, file, or Internet topic.
- Switch between open apps**
Select the Task view icon  in the taskbar.

 The features and appearance of the Windows screen vary, depending on the version of the operating system and additional software installed on your computer.

But Wait ... There's More! About Q & A.

1. I cannot turn my device on.
Press the power button for 3~5 seconds until the power light turns on; connect the provided charging adapter & power cable to the device and press the power button again.
2. My system is unresponsive.
Press CTRL+ALT+DEL and open the task manager. Find the program that is unresponsive and end the task
3. My laptop runs slow.
Empty your Recycle Bin and periodically run an antivirus program.
4. My laptop gets hot.
Use your device in a cooler area. Use an external fan if you intend to use the device for an extended period of time.
5. I cannot connect to my wifi or my wifi is slow.
Use your device closer to your router. If this does not solve the issue restart your router.
6. I cannot connect to my bluetooth device.
Turn off and on bluetooth then try to connect your bluetooth device again.

Warnings & Cautions

1. Do not install near any heat sources such as radiators,heat registers,stoves,or other apparatus (including amplifiers) that produce heat.
2. WARNING:Only use attachments/accessories specified or provided by the manufacturer(such as the exclusive supply adapter,battery etc).
3. WARNING:The mains plug is used as disconnect device,the disconnect device shall remain readily operable.
4. WARNING:To reduce the risk of fire or electric,do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids. Such as vases,shall not be placed on apparatus.
5. WARNING:Please refer the information on exterior bottom enclosure for electrical and safety information before installing or operating the apparatus.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1). This device may not cause harmful interference,and
 - (2). This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Walmart store,inc Limited Warranty

Walmart warrants this product against defects in material or workmanship for a period of one (1) year from the original date of purchase.During this period,Walmart will replace a defective part with a new or refurbished part without a charge to you. If your unit is deemed unrepairable, **onn.** will replace the unit with a new or refurbished unit at Walmart's sole discretion .The customer is responsible for transportation cost and insurance charges (if applicable) to Corporate. It is the customer's responsibility to retain original packaging or provide like packaging in order to facilitate the warranty process. Walmart will incur no liability whatsoever to provide packaging for warranty items. Should the product be damaged due to insufficient packaging, the warranty may be voided. You must receive a return authorization number (RMA #) before sending the unit in for service. Service that is provided is warranted for the duration of the original warranty or 45 days whichever is greater.

Your Responsibility

It is strongly recommended to make a backup copy of the contents on your hard drive in case of operational failure. Walmart will not be held liable for content that is on the device. Retain a copy of the bill of sale to provide proof of purchase. The warranty extends only to defects in materials or workmanship as limited above and does not extend to a cracked screen, damaged USB or DC port, cosmetic damage, or any other products, parts or accessories that have been lost, discarded, damaged by misuse or accident, neglect, acts of God such as lightning, voltage surges in the home, improper installation, or serial number rendered illegible

Walmart store,inc Limited Warranty

Please contact Customer Support directly at 1-800-985-9728. Hours of operation are from 8:00AM-to 5:00PM Monday through Friday. You will be instructed on how your claim will be processed so have information available including a date of purchase, serial number and the problem with the product. Should a problem be determined to be within the limits of the warranty you will be provided with an (RMA) authorization number and instruction. Proof of purchase must be confirmed before any warranty service can be provided. Should a claim not be covered by the limited warranty, you will be asked whether you wish to have service provided for a fee.

Google, Android, Google Play and other marks are trademarks of Google LLC.



onn.TM

**14 Inch Clamshell Notebook
Quick Start Guide**

**We'd love to hear from you.
Scan with your Walmart app
let us know what you think.**