

Holiday
Smart RGBw
Cafe String Lights

Quick Start Guide

WARNINGS
PLEASE READ BEFORE PROCEEDING

This string light set is not a toy. Keep out of reach of children. The light set should not be plugged in while still in the packaging. For indoor and outdoor use. Do not attempt to splice this light set to another light set. The electric cord cannot be replaced. Only use the included hardware and adapter.

If the string light is damaged or does not work properly, the whole unit should be replaced if under warranty, or disposed of in accordance with local, state and federal regulations.

WARNING – RISK OF ELECTRIC SHOCK. IF BULBS ARE BROKEN OR MISSING, DO NOT USE.

1. The total connected sets may not exceed the maximum allowed number of 2 extensions to an original set. If this limit is exceeded, it may result in a risk of electric shock or malfunction.
2. Ensure that the supply cord and inner wiring are not subject to mechanical load or stress.
3. Never hang or mount any object to the lightning chain.
4. Always disconnect the supply cord from the electrical outlet when the light set is not in use, or when the area where in use will be unattended for long periods of time.
5. For outdoor use, ensure the electrical outlet or any extension cord is in compliance with the protection class IP44 (splash and water proof). If there is any doubt, consult a professional electrician.
6. Each section of a connected light set must be mounted individually.
7. Dispose of an entire light set if any portion of it is mechanically or electrically damaged.

FCC COMPLIANCE

Contains FCC ID: 2APYD-850008271083

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio / TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

TWO YEAR LIMITED WARRANTY

WHAT IS COVERED



The manufacturer warrants this product to be free of defects in material and workmanship for a period of two (2) years from the date of purchase. This warranty only applies to the original consumer purchaser and only to products used in normal use and service. The manufacturer's only obligation and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modification, alteration, neglect, or mishandling. Proof of purchase must accompany all warranty claims.

WHAT IS NOT COVERED

This warranty does not apply to products that are found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty does not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation. Batteries supplied with this product are not included in this warranty. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. This warranty does not cover consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of the product.

Contact the Customer Service Team at **1-800-933-7188** or visit **NOVOLINKINC.com**.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Novolink, Inc. is under license. Other trademarks and trade names are those of their respective owners.



Setup

1. Download the Novolink Lightscape Holiday App from Google Play (Android) or the App Store (iOS).
2. Connect the string lights to the controller. Twist the threaded locking ring until tightly secured.
3. Plug the controller into a wall outlet. The controller's light will flash rapidly. It's now ready to pair with the app.
4. Open the Novolink Lightscape Holiday App and log in. Select "Add Device" at the bottom of the screen.
5. Select "Cafe Light" and choose in the next screen, select your newly-added Device. You'll then be connected, and able to customize color, pattern, theme, etc.

Troubleshooting

Controller Light	Meaning
Rapid Flashing	Ready to pair
Slow Pulse	Already paired, but App not detected
Steady On	Actively paired with App

Pair with Another Device

To pair string lights with another smartphone or tablet, sever its current pairing by pressing and holding the controller button until the light blinks, stops flashing, and then flashes rapidly. It will then be ready to pair with a new device.

