



RTL8822CE

RTL8822CU

RTL8822CS

COB

MP FLOW

R12

This document is subject to change without notice. The document contains Realtek confidential information and must not be disclosed to any third party without appropriate NDA.

Table of Contents

1.	<i>DUT MP Flow</i>	7
2.	<i>Environment setup</i>	8
2.1.	Test platform	8
2.2.	CMD environment setup	9
3.	<i>WiFi Mass Production Flow</i>	10
3.1.	WiFi calibration	10
3.1.1.	WiFi initialize.....	10
3.1.2.	Pre-heating	11
3.1.3.	Load default map to fake map from eFuse/Mask map files.	13
3.1.4.	Crystal calibration	14
3.1.5.	Tx index calibration and thermal.....	17
3.1.5.1.	Tx index location in eFuse.....	17
3.1.5.2.	Defined target power	19
3.1.5.3.	Tx index calibration flow.....	20
3.1.5.4.	Tx index calibration command and sample	21
3.1.5.4.1.	Interpolation for finding Tx index	22
3.1.5.4.2.	The Tx power difference	23
3.1.6.	Thermal meter	25
3.2.	WiFi performance verification	26
3.2.1.	Tx performance verification	26
3.2.1.1.	Tx performance verification criterion	26
3.2.1.2.	Verify Tx performance	29
3.2.2.	Rx performance verification.....	30
3.2.2.1.	Rx performance verification criterion.....	30
3.2.2.2.	Verify Rx performance	31
4.	<i>Bluetooth Mass Production Flow</i>	33
4.1.	Bluetooth device environment setup	34
4.1.1.	Android OS	34
4.1.2.	Linux OS	35
4.2.	Bluetooth device initial	36
4.3.	Bluetooth calibration	38
4.3.1.	Calibration Tx gain K.....	41

4.3.2.	Calibration Tx flatness K	42
4.3.3.	Shift Tx Level.....	43
4.3.4.	Calibration thermal meter.....	43
4.4.	Bluetooth verify.....	44
4.4.1.	Verify Bluetooth BDR/EDR.....	44
4.4.1.1.	Verify Bluetooth BDR/EDR Tx.....	44
4.4.1.2.	Verify Bluetooth BDR/EDR Rx	46
4.4.2.	Verify Bluetooth BLE	48
4.4.2.1.	Verify Bluetooth BLE 1M Tx (BT4.0)	49
4.4.2.2.	Verify Bluetooth BLE 2M Tx(BT5.0)	51
4.4.2.3.	Verify Bluetooth BLE 1M Rx(BT4.0)	52
4.4.2.4.	Verify Bluetooth BLE 2M Rx(BT5.0).....	53
4.5.	Bluetooth MP Exit	54
5.	Dump result to HW efuse.....	55
5.1.	WiFi MP results eFuse check-in flow.....	56
5.1.1.	Read default eFuse file to driver fake area	56
5.1.2.	Checkout the driver fake map.....	56
5.1.3.	Modify the specific offset of the fake map	56
5.1.3.1.	Write WiFi MAC address to driver fake map	57
5.1.3.2.	Write thermal value to driver fake map	57
5.1.3.3.	Write calibrated crystal value to driver fake map	58
5.1.3.4.	Write Tx index to driver fake map.....	58
5.1.4.	Update HW eFuse from fake-map.....	59
5.1.5.	Check the HW eFuse content	59
5.2.	Bluetooth MP result eFuse check-in flow	60
5.2.1.	Read Default E-fuse-File to Driver-Fake-Area	60
5.2.2.	Checkout the driver fake map.....	60
5.2.3.	Modify the specific offset of the fake map	60
5.2.3.1.	Write BT MAC address to driver fake map:.....	61
5.2.3.2.	Write thermal value to driver fake map	61
5.2.3.3.	Write Tx gain/Flatness/LBT calibration value to driver fake map.....	61
5.2.4.	Update HW E-fuse from fake-map.....	62
5.2.5.	Check the HW E-fuse content	62
6.	WiFi MP flow appendix.....	63
6.1.	Hardware Tx parameters.....	63

6.2.	Software Rx parameters.....	65
7.	<i>Bluetooth MP flow appendix.....</i>	66
7.1.	Bluetooth MP tool command usage.....	67
7.1.1.	Bluetooth start , exit and help command	68
7.1.2.	Bluetooth MP initialize commands at Linux/Android platform	70
7.1.3.	Bluetooth MP mode control parameters commands.....	71
7.1.4.	Bluetooth MP mode execute commands	76
7.1.5.	Bluetooth MP mode report commands.....	79
7.2.	Bluetooth eFuse definition about calibrates of Tx power.....	80
7.3.	Tx flatness K mapping table	82
7.4.	Bluetooth Tx power table	83
7.5.	Verify Bluetooth BDR/EDR Tx SPEC	85
7.6.	Verify Bluetooth BDR/EDR Rx SPEC	88
7.7.	Verify Bluetooth BLE Tx Performance (BLE 1M).....	89
7.8.	Verify Bluetooth BLE 5.0 Tx Performance	90
7.9.	Verify Bluetooth BLE Rx Performance.....	91

List of Tables

Table 1: Crystal calibration offset in eFuse	17
Table 2: Tx index and Thermal meter offset in eFuse	18
Table 3: The default target power	19
Table 4: The recommended measured channel for Tx power calibration	22
Table 5: The example of finding Tx index in 2G band by interpolation	22
Table 6: The example of finding power difference	23
Table 7: The recommended test items of WiFi Tx	26
Table 8: The recommended test items of 5G WiFi Tx	27
Table 9: The recommended test items of WiFi Tx with 2-stream measurement.....	28
Table 10: The recommended test items of WiFi Tx with 256-QAM measurement	28
Table 11: The recommended test items of WiFi Rx	30
Table 12: Tx gain K mapping table	41
Table 13: RTL8822CE WiFi MAC address offset in eFuse.....	57
Table 14: RTL8822CU WiFi MAC address offset in eFuse	57
Table 15: RTL8822CS WiFi MAC address offset in eFuse.....	57
Table 16: Bluetooth MAC address offset in eFuse	61
Table 17: BT_MP_initialize_CMD	70
Table 18: BT MP CONTROL_PARAM_CMD	71
Table 19: BT PARAM_INDEX.....	72
Table 20: BT PKT_TYPE.....	73
Table 21: BT BLE5.0_Tx_PKT_TYPE.....	73
Table 22: BT BLE5.0_Rx_PKT_TYPE	73
Table 23: BT BLE5.0_MODULATION_TYPE.....	73
Table 24: BT PAYLOAD_TYPE	74
Table 25: BT LE_PAYLOAD_TYPE	74
Table 26: BT PACKET_HEADER	74
Table 27: BT_ACTIONCONTROL_TAG	78
Table 28: BT Tx gain index offset in eFuse	80
Table 29: Verify Bluetooth Tx Basic 1M	85
Table 30: Verify Bluetooth Tx EDR 2M	86
Table 31: Verify Bluetooth Tx EDR 3M	87
Table 32: Bluetooth Legacy Rx criterion.....	88
Table 33: Bluetooth BLE Tx criterion.....	89
Table 34: Bluetooth BLE 5.0 Tx criterion.....	90
Table 35: Bluetooth BLE Rx criterion.....	91

List of Figures


Figure 1: Brief diagram about test environment setup of DUT	8
Figure 2: Connect PC to Android/Linux device	9
Figure 3: Check the connection between PC & Android/Linux device.....	9
Figure 4: Enter Android/Linux device command line	9
Figure 5: WiFi calibration flow	10
Figure 6: Finding Crystal Cap. Index Flow	14
Figure 7: Tx calibration flow	20
Figure 8: Finding Tx index flow	20
Figure 9: Bluetooth TxPower/TxGainK/TxFatnessK relationship	38
Figure 10: BT_5 dBm setting example (Capture image from efuse map file) RTK default map.....	81
Figure 11: BT_4 dBm setting example (Capture image from efuse map file)	81

Revision History:

Revision	Date	Changes	Author
R12	2020/03/12	Re-write from COB flow R11	DeanKu

1. DUT MP Flow

The below diagram shows a global view of Mass-Production-Flow, please refer to the following sub-section to get the detail description of each step.



2. Environment setup

2.1. Test platform

The calibration flow described in following sections are based on WiFi tester.

Realtek had qualified tester is listed below:

Include 802.11ac Test		Only 802.11a/b/g/n Test	
Vendor	Modal Name	Vendor	Modal Name
LitePoint	IQxel	LitePoint	IQFlex
Itest	WT-200	LitePoint	IQView
NI	PXIe-5644R/5645R	LitePoint	IQnxn
Anritsu	MT8870A	Agilent	N4010A
Aeroflex	PXI 3000 Series		

The test environment setup is as below:




Figure 1: Brief diagram about test environment setup of DUT

*To reduce the mismatch effect between DUT and environment,
10dB-fixed attenuator is supposed to set closed to DUT as possible.

2.2. CMD environment setup

Step1 : Use USB cable to connect PC and Android/Linux devices as Figure 3.




Figure 2: Connect PC to Android/Linux device

Step2 : Use adb command as below:

adb devices

How to check whether the Android/Linux devices were connected or not?

Figure 4 shows a result if the PC connects to Android/Linux devices successfully.

```

C:\WINDOWS\system32\cmd.exe

C:\android-sdk-windows\tools>adb devices
adb server is out of date. killing...
* daemon started successfully *
List of devices attached
[redacted] device
[redacted] Device Number
C:\android-sdk-windows\tools>

```

Figure 3: Check the connection between PC & Android/Linux device

Step3 : Use adb command as below:

adb shell

Figure 5 shows the CMD line under shell.

```

C:\WINDOWS\system32\cmd.exe - adb shell

C:\android-sdk-windows\tools>adb shell
adb server is out of date. killing...
* daemon started successfully *
shell@android:/ $
shell@android:/ $

```

Figure 4: Enter Android/Linux device command line

3. WiFi Mass Production Flow

3.1. WiFi calibration

The WiFi calibration steps are shown as Figure 6:




Figure 5: WiFi calibration flow

3.1.1. WiFi initialize

Refer to [Section 2.2](#), PC can connect to Android/Linux devices with USB port and ADB command. The relative commands of DUT WiFi initializing is listed as below :

```
remount
```

```
root
```

```
rmmod wlan
```

```
insmod 8822c.ko rtw_RFE_type=X
```

(delay 5 second)

*If the efuse of RTL8822C was empty, please make sure your HW-Layout of board type and PA/LNA.

```
ifconfig wlan0 up
```

```
rtwpriv wlan0 mp_start
```

3.1.2. Pre-heating

Pre-heating is an one-time experiment to grab essential setup, it made DUT closed to the usual temperature and improved the stability of mass production. It will pre-heat the DUT for seconds before mass production.

Step 1 : Read and record thermal value $THER_{RX}$ at steady Rx status which lasts 5 minutes at room temperature.

```
rtwpriv wlan0 mp_start //Enter WiFi MP mode
```

Wait for 5 minute.

```
rtwpriv wlan0 mp_ther //Get the thermal value  $THER_{RX}$ 
```

Record the $THER_{RX}$ value.

Step 2 : Use MP HW Tx to do the following pre-heating operation.

```
rtwpriv wlan0 6 1 a HTMCS7 1 TxPacketInterval TxPacketLength
```

```
//Supposed initial value of Tx TxPacketInterval = 100
```

```
//Supposed initial value of Tx TxPacketLength = 1000
```

```
rtwpriv wlan0 mp_ther //Get the heated thermal value  $THER_{Heating}$ 
```

Step 3 : To figure out pre-heat settings ($TxPacketInterval/TxPacketLength/TIME_{Heating}$).

Trim the $TxPacketInterval$ or $TxPacketLength$, then do HW Tx and record how long does the DUT be heated to $THER_{RX}$ temperature. If $THER_{Heating} - THER_{RX} \leq 3$, means DUT is heated to desired temperature. The time-spent records as $TIME_{Heating}$.

Use these settings ($TxPacketInterval/TxPacketLength/TIME_{Heating}$) as pre-heating setup.

Pre-heating DUT before calibration by the found settings set :

```
Do HW Tx rtwpriv wlan0 6 1 a HTMCS7 1 TxPacketInterval TxPacketLength
```

Last for $TIME_{Heating}$. So that DUT can be pre-heated to desired thermal range.

Example :

```
rtwpriv wlan0 mp_start //Enter WiFi MP mode
```

Wait for 5 minute.

```
rtwpriv wlan0 mp_ther //MP feedback the thermal value = 2d
```

Record the **THER_{RX}** = 2d

```
rtwpriv wlan0 6 1 a HTMCS7 1 200 1000
```

Example : Use HW Tx, HT40 HTMCS7 channel 6, TxPacketInterval = 200, TxPacketLength = 1000 to pre-heat DUT.

5 seconds past.

```
rtwpriv wlan0 mp_ther //MP feedback the thermal value = 2e
```

Record the **THER_{Heating}** = 2e

2e (**THER_{Heating}**) – 2d (**THER_{RX}**) \leq 3, DUT is heated to desired thermal range!

(5 seconds is just a sample value here. In the operation, please do HW Tx and observe the **THER_{Heating}** variance. How long does the DUT be heated to the thermal range.)

Finally, get a pre-heating settings set :

```
rtwpriv wlan0 6 1 a HTMCS7 1 200 1000
```

Heating time-spent is **TIME_{Heating}** = 5 seconds.

DUT can be heated to desired thermal rang by

HW Tx(**rtwpriv wlan0 6 1 a HTMCS7 1 200 1000**) for 5 seconds (**TIME_{Heating}**).

```
rtwpriv wlan0 stop //Stop HW Tx
```

The pre-heating settings were found.

Please pre-heat DUT before calibration.

3.1.3. Load default map to fake map from eFuse/Mask map files.

Load external eFuse map file to driver fake map

```
rtwpriv wlan0 efuse_file ../../efuse.map
```

Load external mask map file to driver fake map :

```
rtwpriv wlan0 efuse_mask /xx/xx/xxmask.txt
```

3.1.4. Crystal calibration




Figure 6: Finding Crystal Cap. Index Flow

InitIndex: the default value is 0x40. Index range is 0x0 to 0x7F.

MeasuredCFOffset: Carrier frequency measured by instrument - ideal carrier frequency
target range Abs. Value of 2ppm in 2.4GHz band is about 10KHz(±5KHz).

TargetCFOffset: generally is 0 ppm.

Step: The value will be different from modules dominated by external capacitor beside the crystal, so it must be able to modify simply in the initial file of test program. By experience, the value variation is about +2 ~ +3KHz. The value should be checked by hardware RD and be filled in the setup file of test program. The plus symbol means that the crystal Cap. index and carrier frequency is positive-dependent (The larger index is relative to major carrier frequency).

Command is as below:

Step 1 :

```
rtwpriv wlan0 mp_setrfpath 1
```

//WiFi MP driver will set RF path automatically, too.

```
rtwpriv wlan0 7 1 a HTMCS7 1 2000 //start HW Tx
```

Step 2 :

1. To measure frequency error (ppm), Freq_Err.
2. Freq_Err should be limited to ± 2 ppm.
3. If Freq_Err is between ± 2 ppm, it means the Index_cry is correct.
4. If the Freq_Err is out of ± 2 ppm, try the algorithm below to find next index_cry_next until Freq_Err is between ± 2 ppm.

$$index_cry_next = Index_cry - \frac{Freq_Err \times 2442}{2500}$$

Example : Set Index_cry =32, measured Freq_Err = -23.49ppm. How to find next index ?

$$The\ next\ index\ is\ index_cry_next = 32 - \frac{(-23.49) \times 2442}{2500} \approx 9$$

Step3 :

The index_cry_next must be **rounded to an integer**, and use the following command to update index:

```
rtwpriv wlan0 mp_phypara xcap=index_cry_next
```

Example :

```
rtwpriv wlan0 mp_phypara xcap=9 //update crystal calibration value to MP
```

Repeat **Step2, Step3** until the measured Freq_Err is limited to ± 2 ppm and note down

Index_cry_ok. And **Index_cry_ok** should be updated to eFuse after calibration.

Step 4 : After measurement, stop HW Tx.

rtwpriv wlan0 stop

//stop HW Tx

Crystal calibration eFuse offset and notice :

The values must be well-calibrated and filled in the correct eFuse location.

Crystal Calibration	0xB9, 0x110, 0x111
---------------------	--------------------

Table 1: Crystal calibration offset in eFuse

- 0xB9, 0x110, 0x111 should be the same value as each other.**
- For the situation of K-free flow ,the eFuse content may be loaded from an external file in the system. These xtal-related-offset must be written in the HW eFuse even the eFuse-content could be set from an external file.**

3.1.5. Tx index calibration and thermal

The following flow will show the Tx index calibration flow, criterion, and sample command.

3.1.5.1. Tx index location in eFuse

There are the Tx index for each channel group with PHY data rate.

The Tx index value and thermal value should be calibrated and updated to eFuse.

Tx index location in eFuse of Antenna A						
	Group 1 CH1 – CH2	Group 2 CH3 – CH5	Group 3 CH6 – CH8	Group 4 CH9 – CH11	Group 5 CH12 – CH13	Group 6 CH14
MCS7 B40	0x16[7:0]	0x17[7:0]	0x18[7:0]	0x19[7:0]	0x1A[7:0]	
CCK	0x10[7:0]	0x11[7:0]	0x12[7:0]	0x13[7:0]	0x14[7:0]	0x15[7:0]
	Group 7 CH36 – CH40	Group 8 CH44 – CH48	Group 9 CH52 – CH56	Group 10 CH60 – CH64		
MCS7 B40	0x22[7:0]	0x23[7:0]	0x24[7:0]	0x25[7:0]		
	Group 11 CH100 – CH104	Group 12 CH108 – CH112	Group 13 CH116 – CH120	Group 14 CH124 – CH128	Group 15 CH132 – CH136	Group 16 CH140 – CH144
MCS7 B40	0x26[7:0]	0x27[7:0]	0x28[7:0]	0x29[7:0]	0x2A[7:0]	0x2B[7:0]
	Group 17 CH149 – CH153	Group 18 CH157 – CH161	Group 19 CH165 – CH169	Group 20 CH173 – CH177		
MCS7 B40	0x2C[7:0]	0x2D[7:0]	0x2E[7:0]	0x2F[7:0]		

Tx index location in eFuse of Antenna B						
	Group 1 CH1 – CH2	Group 2 CH3 – CH5	Group 3 CH6 – CH8	Group 4 CH9 – CH11	Group 5 CH12 – CH13	Group 6 CH14
MCS7 B40	0x40[7:0]	0x41[7:0]	0x42[7:0]	0x43[7:0]	0x44[7:0]	
CCK	0x3A[7:0]	0x3B[7:0]	0x3C[7:0]	0x3D[7:0]	0x3E[7:0]	0x3F[7:0]
	Group 7 CH36 – CH40	Group 8 CH44 – CH48	Group 9 CH52 – CH56	Group 10 CH60 – CH64		
MCS7 B40	0x4C[7:0]	0x4D[7:0]	0x4E[7:0]	0x4F[7:0]		
	Group 11 CH100 – CH104	Group 12 CH108 – CH112	Group 13 CH116 – CH120	Group 14 CH124 – CH128	Group 15 CH132 – CH136	Group 16 CH140 – CH144
MCS7 B40	0x50[7:0]	0x51[7:0]	0x52[7:0]	0x53[7:0]	0x54[7:0]	0x55[7:0]
	Group 17 CH149 – CH153	Group 18 CH157 – CH161	Group 19 CH165 – CH169	Group 20 CH173 – CH177		
MCS7 B40	0x56[7:0]	0x57[7:0]	0x58[7:0]	0x59[7:0]		

Thermal Meter PathA	0xD0[7:0]
Thermal Meter PathB	0xD1[7:0]

Table 2: Tx index and Thermal meter offset in eFuse

3.1.5.2. Defined target power

According to EMI/EMC regulatory IEEE TX EVM / Spectrum Mask requirement, the target power of each channel group and PHY data rate can be defined.

Assuming that all the channels have the same target power for each PHY data rate, the recommended target power is listed as below :

Data Rate	MCS9-Nss1-B80	MCS7-B40	MCS7-B20	54M	CCK
Target Power 2G		16dBm	16dBm	17dBm	18dBm
Target Power 5G	14dBm	16dBm	16dBm	17dBm	

Table 3: The default target power

The target power in the table is RTK default value. The value can be defined by yourself.

Power-by-rate table and target power must be the same value.

***If there is any concern, or want to know the more details, please contact Realtek FAE.**

3.1.5.3. Tx index calibration flow




Figure 7: Tx calibration flow

The flow to find each index is shown as below:




Figure 8: Finding Tx index flow

Init Index : The power value of **init index** should be closed to target power.

3.1.5.4. Tx index calibration command and sample

Step 1 : Switch the Tx power tracking state to the Tx index calibration state.

```
insmod 8822c.ko rtw_RFE_type=X
```

Tx index for each channel group with PHY data rate in path a, path b should be calibrated.

The following command take “ **Path A, Channel 7, HT40, HTMCS7**” as example.

Step 2 : MP start and enter Tx index calibration mode.

```
rtwpriv wlan0 mp_start
```

```
rtwpriv wlan0 7 1 a HTMCS7 1 2000 //start HW Tx
```

*About HW Tx function parameters detail, please refer to appendix.

Step 3 : Make Tx power to fit target power by adjusting Tx power index.

```
rtwpriv wlan0 mp_txpower patha=63,pathb=0 //set a Tx power index 63
```

Target power values were defined in [section 3.5.2](#).

The variation between defined Tx target power and measured Tx power should be adjusted to $\pm 0.25\text{dB}$.

Defined Tx target power – Measured Tx power = $\pm 0.25\text{ dB}$

The sample command uses the index 63, it is the center index.

Step 4 : Record the Tx index value after measured power had fit target power.

Record the Tx index value. Find out all the Tx index value for each channel group and each PHY data rate. **There is a recommended interpolation method which described at [section 3.1.5.4.1](#)**

The Tx index value should be updated to HW eFuse.

Step 5 : Before measuring the next channel, stop HW Tx.

```
rtwpriv wlan0 stop
```

```
//Stop HW packet Tx
```

3.1.5.4.1. Interpolation for finding Tx index

Theoretically, we need to measure all value defined in eFuse to calibrate the Tx power level. But since it needs too much time, we only measure several channels with MCS7-B40 signal and figure out the other non-measured value by interpolation method.

Usually, the recommended measured channels are listed below:

2G Band		5G Band1		5G Band2		5G Band3			5G Band4	
CH4	CH10	CH38	CH46	CH54	CH62	CH102	CH126	CH142	CH151	CH175

Table 4: The recommended measured channel for Tx power calibration

Example : If the measured Tx index in CH4 is 1 and the measured Tx index in CH10 is 3, all 2G group MCS7-B40 TSSI DE is shown as below:

CH4 is group 2, CH10 is group 4.

Group 1	Group 2	Group 3	Group 4	Group 5
70 (Calculated by Interpolation)	71 (Measured)	72 (Calculated by Interpolation)	73 (Measured)	74 (Calculated by Interpolation)

Table 5: The example of finding Tx index in 2G band by interpolation

We have measured all groups of 5G band 1 and 5G band 2, so just use the interpolation for 5G band 3 and 5G band4.

3.1.5.4.2. The Tx power difference

The power value difference are between +7 and -8.

The value 0x0 ~ 0x7 in eFuse means 0 ~ +7 and the value 0x8 ~ 0xF in eFuse means -8 ~ -1.

The +1 power difference will plus 0.5dB power.

We take Table 7 as an example :

The 2G power difference are shown as below:

MCS7-B20 to MCS7-B40	$(MCS7-B20_Tatget_Power - MCS7-B40_Tatget_Power) \times 2$ $= ((13 - 13) \times 2) = 0$
54M-1T to MCS7-B40	$(54M_Tatget_Power - MCS7-B40_Tatget_Power) \times 2$ $= ((14 - 13) \times 2) = 2$
MCS15-B40 to MCS7-B40	$(MCS15-B40_Tatget_Power - MCS7-B40_Tatget_Power) \times 2$ $= ((12 - 13) \times 2) = -2$ $\Rightarrow 0xE$
MCS15-B20 to MCS7-B20	0xE
54M-2T to 54M-1T	0xE
CCK-2T to CCK-1T	0xE

Table 6: The example of finding power difference

Power Difference Location in EFuse of Antenna A		
2G Band	54M-1T to MCS7-B40	0x1B[3:0]
	MCS7-B20 to MCS7-B40	0x1B[7:4]
	MCS15-B40 to MCS7-B40	0x1C[7:4]
	MCS15-B20 to MCS7-B20	0x1C[3:0]
	54M-2T to 54M-1T	0x1D[7:4]
	CCK-2T to CCK-1T	0x1D[3:0]
5G Band	54M-1T to MCS7-B40	0x30[3:0]
	MCS7-B20 to MCS7-B40	0x30[7:4]
	MCS7-Nss1-B80 to MCS7-B40	0x36[7:4]
	MCS15-B40 to MCS7-B40	0x31[7:4]
	MCS15-B20 to MCS7-B20	0x31[3:0]
	54M-2T to 54M-1T	0x34[7:4]
	MCS7-Nss2-B80 to MCS7-Nss1-B80	0x37[7:4]

Power Difference Location in EFuse of Antenna B		
2G Band	54M-1T to MCS7-B40	0x45[3:0]
	MCS7-B20 to MCS7-B40	0x45[7:4]
	MCS15-B40 to MCS7-B40	0x46[7:4]
	MCS15-B20 to MCS7-B20	0x46[3:0]
	54M-2T to 54M-1T	0x47[7:4]
	CCK-2T to CCK-1T	0x47[3:0]
5G Band	54M-1T to MCS7-B40	0x5A[3:0]
	MCS7-B20 to MCS7-B40	0x5A[7:4]
	MCS7-Nss1-B80 to MCS7-B40	0x60[7:4]
	MCS15-B40 to MCS7-B40	0x5B[7:4]
	MCS15-B20 to MCS7-B20	0x5B[3:0]
	54M-2T to 54M-1T	0x5E[7:4]
	MCS7-Nss2-B80 to MCS7-Nss1-B80	0x61[7:4]

3.1.6. Thermal meter

Normal driver will load thermal meter to do power-tracking, so the value must be filled in correct eFuse location. Use the below MP API function to get thermal meter value:

Read Path A thermal vaule :

```
rtwpriv wlan0 mp_ther 0
```

Read Path B thermal vaule :

```
rtwpriv wlan0 mp_ther 1
```


And the feedback information would show like below, 29 is the thermal value.

```
wlan0 mp_ther:29
```

Write the thermal value into efuse. PathA writes to 0xD0. PathB writes to 0xD1.

Thermal Meter PathA	0xD0[7:0]
Thermal Meter PathB	0xD1[7:0]

3.2. WiFi performance verification



3.2.1. Tx performance verification

The following flow will show the Tx performance verification flow, criterion, and sample command.

3.2.1.1. Tx performance verification criterion

Use the calibrated Tx index in previous step and measure Tx power, EVM, frequency offset and LO leakage to check Tx performance is ok or not. The recommended test items are listed below:

Data Rate	Antenna	Channel	Item	Criterion
MCS7-B40	Antenna A Antenna B	CH10	Power	Typical: 16dBm, Acceptable Range: +1/-1.5dB
			EVM	< -28dB
			Freq. Err.	±15ppm
			Leakage	< -20dBtotal
			Mask	IEEE spec. defined
OFDM 54M	Antenna A Antenna B	CH1	Power	Typical: 17dBm, Acceptable Range: +1/-1.5dB
			EVM	< -25dB
			Freq. Err.	±15ppm
			Leakage	< -15dBtotal
			Mask	IEEE spec. defined
CCK 11M	Antenna A Antenna B	CH7	Power	Typical: 18dBm, Acceptable Range: +1/-1.5dB
			EVM	< 8%
			Freq. Err.	±15ppm
			Mask	IEEE spec. defined

Table 7: The recommended test items of WiFi Tx

Data Rate	Antenna	Channel	Item	Criterion
MCS7-Nss1-B80	Antenna A Antenna B	CH42 CH58 CH138 CH155	Power	Typical: 16dBm, Acceptable Range: +1.5/-2dB
			EVM	< -28dB
			Freq. Err.	±10ppm
			Leakage	< -25dBtotal
			Mask	IEEE spec. defined
MCS7-B40	Antenna A Antenna B	CH118	Power	Typical: 16dBm, Acceptable Range: +1.5/-2dB
			EVM	< -28dB
			Freq. Err.	±10ppm
			Leakage	< -20dBtotal
			Mask	IEEE spec. defined
OFDM 54M	Antenna A Antenna B	CH100	Power	Typical: 17dBm, Acceptable Range: +1.5/-2dB
			EVM	< -25dB
			Freq. Err.	±10ppm
			Leakage	< -15dBtotal
			Mask	IEEE spec. defined

Table 8: The recommended test items of 5G WiFi Tx

If the instrument supports true MIMO, switch MIMO or composite EVM analysis method, the VHT and HT items (OFDM is as same as above) criterion can be changed to below table:

Data Rate	Antenna	Channel	Item	Criterion
MCS7-Nss2-B80	Antenna AB	CH42 CH58 CH138 CH155	Power	Typical: 15dBm, Acceptable Range: +1.5/-2dB
			EVM	< -28dB
			Freq. Err.	±10ppm
			Leakage	< -25dBtotal
			Mask	IEEE spec. defined
MCS15-B40	Antenna AB	CH118	Power	Typical: 15dBm, Acceptable Range: +1.5/-2dB
			EVM	< -28dB
			Freq. Err.	±10ppm
			Leakage	< -20dBtotal
			Mask	IEEE spec. defined
MCS15-B40	Antenna AB	CH10	Power	Typical: 15dBm, Acceptable Range: +1/-1.5dB
			EVM	< -28dB
			Freq. Err.	±15ppm
			Leakage	< -20dBtotal
			Mask	IEEE spec. defined

Table 9: The recommended test items of WiFi Tx with 2-stream measurement

While MP driver is going to measure 256-QAM, Tx index will take the power value in power-by-rate table as measuring reference itself. The criterion would be changed as below table :

Data Rate	Antenna	Channel	Item	Criterion
MCS9-Nss1-B80	Antenna A Antenna B	CH42 CH58 CH138 CH155	Power	Typical: 14dBm, Acceptable Range: +1.5/-2dB
			EVM	< -32dB
			Freq. Err.	±10ppm
			Leakage	< -25dBtotal
			Mask	IEEE spec. defined

Table 10: The recommended test items of WiFi Tx with 256-QAM measurement

* The table target power is RTK default value , the user can define traget power by yourself.

3.2.1.2. Verify Tx performance

The following steps are the Tx performance verify command sample :

Step 1 : Enter WL MP mode.

```
rtwpriv wlan0 mp_start
```

Step 2 : Set HW Tx and Tx index to the case which is going to do the verification.

Example : To verify path A, CH10, HT40, MCS7, Calibrate Tx index

```
rtwpriv wlan0 mp_txpower patha=calibrated_tx_index, pathb=calibrated_tx_index
```

```
rtwpriv wlan0 10 1 a HTMCS7 1 2000
```

Step 3 : Measure Tx performance and check the performance with criterion table.

Path A CH10 HT40 MCS7 criterion :

Data Rate	Antenna	Channel	Item	Criterion
MCS7-B40	Antenna A Antenna B	CH10	Power	Typical: 16dBm, Acceptable Range: +1/-1.5dB
			EVM	< -28dB
			Freq. Err.	±15ppm
			Leakage	< -20dBtotal
			Mask	IEEE spec. defined

Check whether the measured result is fit the criterion or not.

Step 4 : Before change the measuring channel, stop HW Tx.

```
rtwpriv wlan0 stop
```

```
//Stop HW packet Tx
```

3.2.2. Rx performance verification

The following flow will show the Rx performance verification flow, criterion, and sample command.

3.2.2.1. Rx performance verification criterion

Measure the DUT Rx sensitivity to check Rx performance is ok or not. The recommended test items are listed below:

Data Rate	Antenna	Channel	Item	Criterion
MCS7-B40	Antenna A	CH10	Sensitivity	< -61dBm (1R)
	Antenna B			
OFDM 54M	Antenna AB	CH1		< -68dBm (2R)
CCK 11M	Antenna A	CH7		< -76dBm (1R)
	Antenna B			

Data Rate	Antenna	Channel	Item	Criterion
MCS9-Nss1-B80	Antenna A	CH42	Sensitivity	< -51dBm (1R)
	Antenna B			
MCS9-Nss1-B80	Antenna AB	CH58		< -54dBm (2R)
		CH138		
		CH155		
MCS7-B40	Antenna A	CH118		< -64dBm (2R)
	Antenna B			
OFDM 54M	Antenna A	CH100		< -68dBm (2R)
	Antenna B			

Table 11: The recommended test items of WiFi Rx

The recommended packet-error-rate is < 10%(MCS, OFDM), < 8% (CCK).

*The criterion can be modified by customer requirement.

*If there is any concern, or want to know the more details, please contact Realtek FAE.

3.2.2.2. Verify Rx performance

Set the instrument to Tx packets, and DUT MP Rx the packets.
Then parsing the error rate to verify Rx performance.

The following steps are the Rx performance verify command sample :

Step 1 : Start SW(Software) Rx

Example : Verify path A, MCS7, bandwidth 40, CH10 Rx.

```
rtwpriv wlan0 mp_start //Start MP mode
rtwpriv wlan0 mp_channel 10 //Set Rx channel
rtwpriv wlan0 mp_ant_rx a //Set path a
rtwpriv wlan0 mp_bandwidth 40M=1,shortGI=0 //Set bandwidth
//40M→40M=1, 20M→40M=0, 80M→40M=2
rtwpriv wlan0 mp_arx start //Start Rx
rtwpriv wlan0 mp_reset_stats //Reset the Rx report
```

Instrument Tx packets at MCS7, bandwidth 40, CH10 and
adjust the Tx power let DUT input power < -61dBm (MCS7-B40 criteria).

Data Rate	Antenna	Channel	Item	Criterion
MCS7-B40	Antenna A Antenna B	CH10	Sensitivity	< -61dBm (1R)
OFDM 54M	Antenna AB	CH1		< -68dBm (2R)
CCK 11M	Antenna A Antenna B	CH7		< -76dBm (1R)

Step 2 : While the instrument Tx is finished, parsing the Rx report.

```
rtwpriv wlan0 mp_arx phy
```

The command will report Rx OK/CRC_error counter.

Step 3 : Calculate packet-error-rate

Calculate packet-error-rate with step2 result.


The recommended **packet-error-rate is < 10%(MCS, OFDM), < 8% (CCK).**

Example :

- (1) Instrument Tx 1000 packets at MCS7, bandwidth 40, CH10.
- (2) Step 2 reports DUT had Rx 920 packets which Tx from instrument and its input power < -61dBm successfully.
- (3) $(1000 - 920) / 1000 = 8\%$
- (4) $8\% < 10\% \rightarrow$ Path A, MCS7, bandwidth 40, CH10 Rx verification pass!

4. Bluetooth Mass Production Flow

The below diagram shows a global view of Bluetooth mass production flow.



Bluetooth Set Tx power Note:

1. For general purpose, Tx value for MP is set to 5 dBm to obtain the best power consumption performance and meet different certification (FCC, CE, etc.)
2. If customer who uses our module may need to provide permissive change files (Efuse map)during certification of your own product for different Tx power setting. Here listed the main power restraint due to CE compliance, EIRP should less than 10 dBm.

4.1. Bluetooth device environment setup

To do BT RF test, “rtlbtmp” is a necessary tool.

4.1.1. Android OS

MP tool package is provided to customers in binary format:

MP ADB tool → rtlbtmp
MP library → btmp.default.so

Customers should copy these binary files to respective directories on target production:

rtlbtmp → save to → [/system/bin/](#)
chmod rtlbtmp → [chmod 755 /system/bin/rtlbtmp](#)

btmp.default.so → save to → [/system/lib/hw/](#)
mp_rtlxxx_fw, mp_rtlxxx_config → save to → [/system/etc/firmware/](#)

Notice: If the system is android o or above:

rtlbtmp → save to → [/vendor/bin/](#)
chmod rtlbtmp → [chmod 755 /vendor/bin/rtlbtmp](#)

btmp.default.so → save to → [/vendor/lib/hw/](#)
mp_rtlxxx_fw, mp_rtlxxx_config → save to → [/vendor/firmware/](#)

Notice: The above files are recommended to be put into the SDK, which will not affect the using of normal Bluetooth.

Notice: Before using RTLBTMP, normal BT must be turned off . The following methods is for turn off normal BT.

Method 1: Turn off bluetooth on the UI

Method 2: [service call bluetooth_manager 8\(close\) /6\(open\)](#)

Method 3: Using command to rename driver file :

[cd /system/lib/hw](#)

[mv bluetooth.default.so bluetooth.default.so_ORG](#)

(for android P : [mv libbluetooth.so libbluetooth.so_ORG](#))

Reboot

4.1.2. Linux OS

MP tool package is provided to customers in binary format:

MP CMD tool → rtlbtmp
 MP firmware and configure files → mp_rtlxxx_fw, mp_rtlxxx_config

Customers should copy these binary files to respective directories on target production:

rtlbtmp → save to → **/usr/sbin/**
 chmod rtlbtmp → **chmod 755 /usr/sbin/rtlbtmp**
 mp_rtlxxx_fw, mp_rtlxxx_config → save to → **/lib/firmware/**

Notice: The above files are recommended to be put into the SDK, which will not affect the using of normal Bluetooth.

Notice: UART interface chip preparation :

Please turn off normal Bluetooth. That is rtk_hciattach and the other processes will not be loaded by default after starting up. The command are as below :

```
killall rtk_hciattach
killall bluetoothd
echo 0 > /sys/class/rfkill/rfkill0/state
sleep 1
echo 1 > /sys/class/rfkill/rfkill0/state
sleep 1
```

Notice: USB interface chip preparation :

Turn on normal Bluetooth first,
then

```
hciconfig hci0 up
```

4.2. Bluetooth device initial

In the initial stage, the Bluetooth device must set to factory default and set antenna patch .

The Initial command list as :

Step1 : Change BT RF path

```
ifconfig wlan0 up
```

```
sleep 1
```

```
rtwpriv wlan0 mp_start
```

```
rtwpriv wlan0 mp_setrfpath 0 // 0 or 1
```

```
rtwpriv wlan0 mp_ant_tx a // a or b
```

Step2 : Bluetooth initial

Start MP CMD Tool

```
rtlbtm
```

```
root@tristan-PORTEGE-R700:~# rtlbtm
::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
:::::::::::: Bluetooth MP Test Tool Starting ::::::::::::::
>
```

Enable MP Stack

Check Bluetooth stack HCI interface first, then run the enable MP stack CMD.

Please refer "[7.1.2. : Bluetooth MP initialize commands at Linux/Android platform](#)".

```
enable usb:/dev/rtk_btusb //usb I/F
```

```
enable uart:/dev/ttyS0 // uart I/F, device node specified by vendor (platform)
```

```
enable sdio:/dev/sdio //sdio I/F
```

```
root@tristan-PORTEGE-R700:~# rtlbtm
::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
:::::::::::: Bluetooth MP Test Tool Starting ::::::::::::::
> enable uart:/dev/ttyUSB0
> > > enable[Success:0]
```

Step3 : Bluetooth reset**Disable Thermal power tracking**

```
bt_mp_SetParam 18,0,0
```

```
bt_mp_Exec 42
```

Set Tx gain K to 0 to “ Reset Tx Gain K “

```
bt_mp_SetParam 18,1,0x00 // set ;The value (2's complement) is TX Gain k value
```

```
bt_mp_Exec 45
```

Set Flatness K to 0 to ” Reset Flatness K ”

```
bt_mp_SetParam 18,1,0,0
```

```
bt_mp_Exec 46
```


Set antenna path

```
bt_mp_SetParam 18,0 //The value is antenna path : 0:S0 1:S1
```

```
bt_mp_Exec 40
```

4.3. Bluetooth calibration

The flow show as below:



The schematic diagram of this Tx gain K, flatness K and shift Tx level is as follows :




Figure 9: Bluetooth TxPower/TxGainK/TxFlatnessK relationship

Now ,We should control the bluetooth device then to enter 2 or 3 command :



Step1 : Set parameters :

`bt_mp_SetParam`

The Format is :

`bt_mp_SetParam Index0,value0; Index1,..;IndexN,valueN`

If there is a requirement to check the parameters, enter the command below :

`bt_mp_GetParam`

Example : If you want to set the channel 10 and packet type “BT_PKT_3DH5” :

`bt_mp_SetParam 0x01,0x0a;0x02,0x08`

```

> bt_mp_SetParam 0x01,0x0a;0x02,0x08
bt_mp_SetParam[Success:0]
> bt_mp_SetParam,2,0x00
  
```

Or set channel and packet type separately.

```

> bt_mp_SetParam 0x01,0x0a
bt_mp_SetParam[Success:0]
> bt_mp_SetParam,1,0x00

> bt_mp_SetParam 0x02,0x08
bt_mp_SetParam[Success:0]
> bt_mp_SetParam,2,0x00
  
```


Step2 : Execute commands

To execute the parameters/command set in **Step1** :

bt_mp_Exec ACTION_INDEX

Example: To run “PACKET_TX_START” and “PACKET_TX_STOP” actions,
please use :

bt_mp_Exec 12 //PACKET_TX_STRAT

bt_mp_Exec 14 //PACKET_Tx_STOP

```
> bt_mp_Exec 12
bt_mp_Exec[Success:0]
> bt_mp_Exec,12,0x00

> bt_mp_Exec 14
bt_mp_Exec[Success:0]
> bt_mp_Exec,14,0x00
```

For the detail parameters/indexs/command-IDs,
please refer to appendix “[7.1.4. : Bluetooth MP mode execute commands](#)”.

Step3 : Report result

These commands used to report Bluetooth DUT Tx/Rx status are as below:

bt_mp_Report Item_Index

For the whole Item_Index indexes for result report,
please refer to appendix “[7.1.5. : Bluetooth MP mode report commands](#)”.

4.3.1. Calibration Tx gain K

Here demonstrate the flow about calibrating Tx power to target power. We supposed to use desired target power as calibration power in this step. This Tx gain K is a signed value.

Tx gain K value	value
12	0x0C
...	...
4	0x04
3	0x03
2	0x02
1	0x01
0	0 (Default)
-1	0xFF
-2	0xFE
-3	0xFD
-4	0xFC
...	...
-12	0xF4

Table 12: Tx gain K mapping table

Step 1 : Begin 2DH5 packet Tx in channel “0x27”.

```
bt_mp_SetParam 1,0x27;2,0x06;3,0x07;4,0x00;6,0x7F;7,0x0;11,0x0000009e8b33
```

```
bt_mp_Exec 30
```

Step 2 : measured by Bluetooth test instrument (e.g. Litepoint IQNxN)

Txpower_measure is measured value.

Step 3 : Calculate Tx Gain K value and keep the TxgainK.

$$TxgainK = round((Txpower_target - Txpower_measure) / 0.5)$$

Example : Txpower_target = 6 dBm

Step 4 : Stop Packet Tx (FW_PACKET_TX_STOP=31)

```
bt_mp_Exec 31
```

Keep the Tx gain k value write to device in last work.

4.3.2. Calibration Tx flatness K

Let's correct the flatness of the channel. The step by step commands are in the below.

Step 1 : Begin 2DH5 packet TX in channel 12/32/52/70

If Channel 12 :

bt_mp_SetParam 1,0x0B;2,0x06;3,0x07;4,0x00;6,0x7F;7,0x0;11,0x0000009e8b33

If Channel 20 :

bt_mp_SetParam 1,0x20;2,0x06;3,0x07;4,0x00;6,0x7F;7,0x0;11,0x0000009e8b33

If Channle 52 :

bt_mp_SetParam 1,0x34;2,0x06;3,0x07;4,0x00;6,0x7F;7,0x0;11,0x0000009e8b33

If Channel 70 :

bt_mp_SetParam 1,0x46;2,0x06;3,0x07;4,0x00;6,0x7F;7,0x0;11,0x0000009e8b33

bt_mp_Exec 30

Step 2 : measured by Bluetooth test instrument (e.g. Litepoint IQNxN).

Step 3 : Stop Packet Tx (FW_PACKET_TX_STOP=31),

then repeat to 4 channels to complete the measurement

bt_mp_Exec 31

Step 4 : Calculate flatness value and keep the flatnessK value.

*flatnessK value [0~3] =floor((Txpower_flat_target- Txpower_flat_measure[0~3])*2)*

Step 5 : Write to efuse of device .(This action can be placed after the final verification)

This tx flatness k is a signed value, please refer to section "[7.3.Tx flatness K mapping table](#)".

4.3.3. Shift Tx Level

After finished “Calibrate Tx power to target power” and “Calibrate Tx power flatness”, then use the table below to set the target Tx power for different antenna paths. Please refer “[7.4. : Bluetooth Tx power table](#)”.

The Offset Tx power to RAM command show as:

Step 1 : Get TX power level:

bt_mp_Exec 38

bt_mp_Report 17

Step 2 : Set TX power level to ram:

(1M=0x38);(2M=0x3F);(3M=0x3F),(BLE1M=0x38),(BLE2M=0x38)

bt_mp_SetParam 18,0x38,0x3F,0x3F,0x38,0x38;

bt_mp_Exec 51

4.3.4. Calibration thermal meter

Normal driver will load thermal meter to do power tracking. So this value must be filled in correct eFuse location. Use the command below to read Bluetooth thermal meter once.

For Linux/Android platform to get the thermal value from device.

bt_mp_Report 7

***Note: The Thermal Value is RAW Data of Realtek define**

4.4. Bluetooth verify

The flow show as:



4.4.1. Verify Bluetooth BDR/EDR

The verify need to verify Tx and RX.

4.4.1.1. Verify Bluetooth BDR/EDR Tx

If the device is UART interface, use below commands at android and Linux platform. Please refer the [“7.5. : Verify Bluetooth BDR/EDR Tx SPEC”](#) to check performance SPEC.

The step by step command:

Step 1 : Enter MP Mode and download patch code

```

root@tristan-PORTEGE-R700:~# rtlbtmp
::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
::::::::: Bluetooth MP Test Tool Starting ::::::::::
> enable uart:/dev/ttyUSB0
> > > enable[Success:0]
  
```

Step 2 : Set antenna path.

If the path is S1, then :

```

bt_mp_SetParam 18,1           //The vale is antenna path : 0:S0 1:S1
bt_mp_Exec 40
  
```

Step 3 : Set Parameter : For example , Only show some settings for DH1 and 3DH5.

Test Item		Command
		If Channel = 0x27
DH1	Maximum Power	<code>bt_mp_SetParam 1,0x27;2,0x00;3,0x07;4,0x00;6,0x7F;7,0x0;11,0x0000009e8b33</code>
	Delta F1	<code>bt_mp_SetParam 1,0x27;2,0x00;3,0x05;4,0x00;6,0xFF;7,0x0;11,0x0000009e8b33</code>
	Delta F2	<code>bt_mp_SetParam 1,0x27;2,0x00;3,0x02;4,0x00;6,0xFF;7,0x0;11,0x0000009e8b33</code>
3DH5	ALL	<code>bt_mp_SetParam 1,0x27;2,0x06;3,0x07;4,0x00;6,0x7F;7,0x0;11,0x0000009e8b33</code>

Step 4 : Run Packe Tx (FW_PACKET_TX_START=30)

`bt_mp_Exec 30`

Step 5 : measured by Bluetooth test instrument (e.g. Litepoint IQN_xN)

Step 6 : Stop Packet Tx (FW_PACKET_TX_STOP=31)

`bt_mp_Exec 31`

If you need to test other parameters, please stop packet tx and go back to step 2.

4.4.1.2. Verify Bluetooth BDR/EDR Rx

For android and Linux ,you can use below command to test. Please refer the “[7.6. : Verify Bluetooth BDR/EDR Rx SPEC](#)” to check performance SPEC.

The below command only shows some settings for DH1 and 3DH1.

Step 1 : Enter MP Mode and download patch code

```

root@tristan-PORTEGE-R700:~# rtlbtmp
::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
:::::::::::: Bluetooth MP Test Tool Starting ::::::::::::::
> enable uart:/dev/ttyUSB0
> > enable[Success:0]
    
```

Step 2 : Set Parameter

Test Item		adb command
Channel	Packet type	PayloadType = PRBS9; WhiteningCoeffValue = 0xFF(disable); PacketHeader = PACKET_HEADER Table; HitTarget = 0x000000c6967e
6	DH1	bt_mp_SetParam 1,0x06;2,0x00;3,0x07;6,0xFF;11,0x000000c6967e
42	DH1	bt_mp_SetParam 1,0x2a;2,0x00;3,0x07;6,0xFF;11,0x000000c6967e
70	DH1	bt_mp_SetParam 1,0x46;2,0x00;3,0x07;6,0xFF;11,0x000000c6967e
6	3DH1	bt_mp_SetParam 1,0x06;2,0x06;3,0x07;6,0xFF;11,0x000000c6967e
42	3DH1	bt_mp_SetParam 1,0x2a;2,0x06;3,0x07;6,0xFF;11,0x000000c6967e
70	3DH1	bt_mp_SetParam 1,0x46;2,0x06;3,0x07;6,0xFF;11,0x000000c6967e

Please refer [7.1.3. : Bluetooth MP mode control parameters commands](#).

Step 3 : Run Packe Rx (FW_PACKET_RX_START=32)

Step 4 : To setting parameter with the Bluetooth test instrument. Bluetooth test instrument begin transmit.

bt_mp_Exec 32

Step 5 : Report Received Result.

-- **“bt_mp_Report 3”** should be executed every 1s.

Step 6 : Stop Packet Rx (FW_PACKET_RX_STOP=33)

bt_mp_Exec 33

Step 7 : Exit MP Mode

```
> disable
disable[Success:0]
> quit
:::::::::: Bluetooth MP Test Tool Terminating ::::::::::::
root@tristan-PORTEGE-R700:~# █
```


4.4.2. Verify Bluetooth BLE

This BLE RF performance includes spec for BT4.0 and BT5.0. This test item contains the following items:

- Verify Bluetooth BLE 1M TX
- Verify Bluetooth BLE 2M TX
- Verify Bluetooth BLE 1M RX
- Verify Bluetooth BLE 2M RX

4.4.2.1. Verify Bluetooth BLE 1M Tx (BT4.0)

To measure the DUT BLE TX power and modulation index to check whether BLE TX performance is fine or not. The steps shows the adb commands for UART interface device at Android/Linux platform.

Step 1 : Enter MP Mode and download patch code

Step 2 : Set Parameter :

INDEX	VALUE	Value Range (BLE 5.0)
1	ChannelNumber	0~39
3	PayloadType	BT_LE_PAYLOAD_TYPE_PRBS9 = 0, BT_LE_PAYLOAD_TYPE_1111_0000 = 1, BT_LE_PAYLOAD_TYPE_1010 = 2, BT_LE_PAYLOAD_TYPE_PRBS15 = 3, BT_LE_PAYLOAD_TYPE_ALL1 = 4, BT_LE_PAYLOAD_TYPE_ALL0 = 5, BT_LE_PAYLOAD_TYPE_0000_1111 = 6, BT_LE_PAYLOAD_TYPE_0101 = 7,
15	LEDataLen	0x00~0xFF
16	PHY	0x00 : Reserved 0x01 : LE 1M PHY 0x02 : LE 2M PHY 0x03 : LE Coded PHY with S=8 data coding 0x04 : LE Coded PHY with S=2 data coding

Channel	Test item	Command
0	Avg_power	<code>bt_mp_SetParam 1,0x00;3,0x00;15,0xff;16,1</code>
19	Avg_power	<code>bt_mp_SetParam 1,0x13;3,0x00;15,0xff;16,1</code>
39	Avg_power	<code>bt_mp_SetParam 1,0x27;3,0x00;15,0xff;16,1</code>
0	Delta F1	<code>bt_mp_SetParam 1,0x00;3,0x01;15,0xff;16,1</code>
0	Delta F2	<code>bt_mp_SetParam 1,0x00;3,0x02;15,0xff;16,1</code>

Step 3 : LE TX TEST

`bt_mp_Exec 22`

Step 4 : LE TEST END

`bt_mp_Exec 24`

Please refer "[7.7. : Verify Bluetooth BLE Tx Performance \(BLE 1M\)](#)".

4.4.2.2. Verify Bluetooth BLE 2M Tx(BT5.0)

If need to verify BLE 5.0, then the step show below:

Step 3 : Set Parameter

Channel	Test item	Command
0	Avg_power	<code>bt_mp_SetParam 1,0x00;3,0x00;15,0xff;16,2</code>
19	Avg_power	<code>bt_mp_SetParam 1,0x13;3,0x00;15,0xff;16,2</code>
39	Avg_power	<code>bt_mp_SetParam 1,0x27;3,0x00;15,0xff;16,2</code>
0	Delta F1	<code>bt_mp_SetParam 1,0x00;3,0x01;15,0xff;16,2</code>
0	Delta F2	<code>bt_mp_SetParam 1,0x00;3,0x02;15,0xff;16,2</code>

Step 3 : LE TX TEST

`bt_mp_Exec 22`

Step 4 : LE TEST END

`bt_mp_Exec 24`

Please refer "[7.8. : Verify Bluetooth BLE 5.0 Tx Performance](#)".

4.4.2.3. Verify Bluetooth BLE 1M Rx(BT4.0)

For android and Linux ,you can use below command to test.

Step 1 : Set Parameter

INDEX	VALUE	Value Range (BLE 5.0)
1	ChannelNumber	0~39
16	PHY	0x00 : Reserved 0x01 : LE 1M PHY 0x02 : LE 2M PHY 0x03 : LE Coded PHY
17	Modulation Index	0x00 : Standard 0x01 : Stable

Test Item		Commands
Channel	Payload type	
0x00	PRBS9	<code>bt_mp_SetParam 1,0x00;16,0x01;17,0x0</code>
0x13	PRBS9	<code>bt_mp_SetParam 1,0x13;16,0x01;17,0x0</code>
0x22	PRBS9	<code>bt_mp_SetParam 1,0x22;16,0x01;17,0x0</code>

Step 2 : Run LE Packet Rx

```
bt_mp_Exec 23 //LE RX TEST
```

Step 3 : To setting Parameter with the Bluetooth test instrument. Bluetooth test instrument begin transmit.

Step 4 : Stop LE Packet Rx and to obtain the receive packet count

```
bt_mp_Exec 24 //LE TEST END
```

```
bt_mp_Report 11 //REPORT LE RX Number of Packets
```

4.4.2.4. Verify Bluetooth BLE 2M Rx(BT5.0)

The Command step by step list below :

Step 1 : Enter Hci reset to reset the DUT.

Step 2 : Set Parameter & Run LE Packet Rx

Test Item		Command
Channel	Payload type	
0x00	PRBS9	<code>bt_mp_SetParam 1,0x00; 16,0x02;17,0x0</code>
0x13	PRBS9	<code>bt_mp_SetParam 1,0x13; 16,0x02;17,0x0</code>
0x22	PRBS9	<code>bt_mp_SetParam 1,0x22; 16,0x02;17,0x0</code>

Step 3 : LE RX TEST

`bt_mp_Exec 23`

Step 4 : LE TEST END

`bt_mp_Exec 24`

Step 5 : Report LE Rx number of packets

`bt_mp_Report 11`

Please refer "[7.9. : Verify Bluetooth BLE Rx Performance](#)".

4.5. Bluetooth MP Exit

Disable MP Stack

disable


```
> disable
disable[Success:0]
>
```

Exit MP Tool

quit

```
> quit
:::::::::: Bluetooth MP Test Tool Terminating ::::::::::
root@tristan-ORTEGE-R700:~#
```

5. Dump result to HW efuse



5.1. WiFi MP results eFuse check-in flow

5.1.1. Read default eFuse file to driver fake area

If the default map have already loaded in [section 3.1.3.](#), please skip 5.1.1..

Load external eFuse map file to driver fake map :

```
rtwpriv wlan0 efuse_file ../../efuse.map
```

Load external mask map file to driver fake map :

```
rtwpriv wlan0 efuse_mask /xx/xx/xxmask.txt
```

5.1.2. Checkout the driver fake map

Read current driver fake map :

```
rtwpriv wlan0 efuse_get wlrkmap
```

We could check the current driver fake map after the map file was loaded or any modification was applied.

Most of all, please confirm the modified driver fake map cautiously, before updating the driver fake map to fact eFuse map.

5.1.3. Modify the specific offset of the fake map

```
rtwpriv wlan0 efuse_set wlwfake,Addr,Value(Hex)
```

In this step, MAC Addr./Thermal /Power index/Tx index/Crystal calibration value should be check-in to the Fake-Area.

5.1.3.1. Write WiFi MAC address to driver fake map

EFuse offset address :

WiFi MAC address	0x120 ~ 0x125
------------------	---------------

Table 13: RTL8822CE WiFi MAC address offset in eFuse

WiFi MAC address	0x157 ~ 0x15c
------------------	---------------

Table 14: RTL8822CU WiFi MAC address offset in eFuse

WiFi MAC address	0x16a ~ 0x16f
------------------	---------------

Table 15: RTL8822CS WiFi MAC address offset in eFuse

Example : To write RTL8822CE MAC address to driver fake map.

(Ex : MAC Addr = 023456789ABC)

```
rtwpriv wlan0 efuse_set wlwfake, 120, 023456789ABC
```

5.1.3.2. Write thermal value to driver fake map

EFuse offset address : Refer to [section 3.1.6. : Read thermal meter](#).

Path A thermal meter : 0xD0[7:0]

Path B thermal meter : 0xD1[7:0]

```
rtwpriv wlan0 efuse_set wlwfake,d0,thermal_value_path(Hex)
```

Example : If path A thermal value = 29, path B thermal value = 30.

```
rtwpriv wlan0 efuse_set wlwfake,d0,1d
```

```
rtwpriv wlan0 efuse_set wlwfake,d1,1e
```

5.1.3.3. Write calibrated crystal value to driver fake map

EFuse offset address : Refer to section [3.1.4. : Crystal calibration](#).

RTL8822C crystal calibration value should be filled in 0xB9, 0x110, 0x111.

```
rtwpriv wlan0 efuse_set wlwfake,Addr,Crystal_value(Hex)
```

Example : If the calibrated crystal value = 0x40.

```
rtwpriv wlan0 efuse_set wlwfake,B9,40
```

```
rtwpriv wlan0 efuse_set wlwfake,110,40
```

```
rtwpriv wlan0 efuse_set wlwfake,111,40
```

5.1.3.4. Write Tx index to driver fake map

EFuse offset address : Refer to [3.1.5.1. : Tx index locations in eFuse](#).

The Tx index for each channel group with PHY data rate should all updated to driver fake map.

```
rtwpriv wlan0 efuse_set wlwfake,Addr,index_value(Hex)
```

Example : If the pathA group 1 MCS7 B40 Tx index value = 72

pathA group 3 MCS7 B40 Tx index value = 71

pathA group 5 MCS7 B40 Tx index value = 70

```
rtwpriv wlan0 efuse_set wlwfake,16,48
```

```
rtwpriv wlan0 efuse_set wlwfake,18,47
```

```
rtwpriv wlan0 efuse_set wlwfake,1A,46
```

5.1.4. Update HW eFuse from fake-map

Before updating the modified driver fake map to fact hardware eFuse map, please use below command to confirm whether the modification is completed :

```
rtwpriv wlan0 efuse_get wlrkmap
```

If the modification are completed and confirmed, please use below command for updating the driver fake map into the fact hardware eFuse :

```
rtwpriv wlan0 efuse_set wlfk2map
```

Attention : It would return error, if the **mask map** file haven't been loaded simultaneously in the case of the operating MP driver version is over than "rtl8xxx_WiFi_linux_v5.X.X_19292".

5.1.5. Check the HW eFuse content

The hardware eFuse map can be gotten by using below command :

```
rtwpriv wlan0 efuse_get realmap
```

And also check the value which were modified in section 5.1.3.1~5.1.3.4 are all correct.

5.2. Bluetooth MP result eFuse check-in flow

5.2.1. Read Default E-fuse-File to Driver-Fake-Area

Load external eFuse map file to driver fake map :

```
rtwpriv wlan0 bt_efuse_file ../../bt_efuse.map
```

Load external mask map file to driver fake map :

```
rtwpriv wlan0 efuse_bt_mask /xx/xx/xx_bt_mask.txt
```

5.2.2. Checkout the driver fake map

Read current driver fake map :

```
rtwpriv wlan0 efuse_get btffake //Front part map
```

```
rtwpriv wlan0 efuse_get btbfake //Back part map
```

We could check the current driver fake map after the map file was loaded or any modification was applied.

Most of all, please confirm the modified driver fake map cautiously, before updating the driver fake map to fact eFuse map.

5.2.3. Modify the specific offset of the fake map

```
rtwpriv wlan0 efuse_set btwfake,Addr,Value(Hex)
```

In this step, the BT MAC_Addr, thermal value, Tx Gain K result, Tx power flatness K result should be check-in to the Fake-Area.

5.2.3.1. Write BT MAC address to driver fake map:

EFuse offset address :

BT MAC address	0x30
----------------	------

Table 16: Bluetooth MAC address offset in eFuse

Example : To write RTL8822CE BT MAC address to driver fake map.

(Ex : MAC Addr. = 00E04CAABBCC)

```
rtwpriv wlan0 efuse_set btwfake, 30,CCBBAA4CE000
```

5.2.3.2. Write thermal value to driver fake map

EFuse offset address : Refer to [7.2. : Bluetooth eFuse definition about calibrates of Tx power](#).

BT thermal meter : 0x28C[7:0]

```
rtwpriv wlan0 efuse_set btwfake,28c,thermal_valu (Hex)
```

Example : If BT thermal value = 80

```
rtwpriv wlan0 efuse_set btwfake, 28c,50
```

5.2.3.3. Write Tx gain/Flatness/LBT calibration value to driver fake map

EFuse offset address :

Refer to [7.2. : Bluetooth eFuse definition about calibrates of Tx power](#)

Tx gain K valid bit = 0x278[1].

Tx flatness K valid bit = 0x278[2].

LBT valid bit = 0x278[5]

Tx gain K result saves to 0x279[7:0].

Tx Flatness K result saves to 0x27A[7:0]~0x27B[7:0].

```
rtwpriv wlan0 efuse_set btwfake,Addr,value(Hex)
```

Example : If both of Tx gain K result = 0, Tx flatness K result = 0, and no LBT.

```
rtwpriv wlan0 efuse_set btwfake,278,6
```

```
rtwpriv wlan0 efuse_set btwfake,279,0
```

```
rtwpriv wlan0 efuse_set btwfake,27a,0
```

```
rtwpriv wlan0 efuse_set btwfake,27b,0
```

5.2.4. Update HW E-fuse from fake-map

Before updating the modified driver fake map to fact hardware eFuse map, please use below command to confirm whether the modification is completed :

```
rtwpriv wlan0 efuse_get btffake //Front part map
```

```
rtwpriv wlan0 efuse_get btbfake //Back part map
```

If the modification are completed and confirmed, please use below command for updating the driver fake map into the fact hardware eFuse :

```
rtwpriv wlan0 efuse_set btfk2map
```

5.2.5. Check the HW E-fuse content

The hardware eFuse map can be gotten by using below command :

```
rtwpriv wlan0 efuse_get btfmap //Front part map
```

```
rtwpriv wlan0 efuse_get btbmap //Back part map
```

And also check the value which were modified in section 5.2.3.1~5.2.3.3 are all correct.

6. WiFi MP flow appendix

6.1. Hardware Tx parameters

`rtwpriv wlan0 [Channel] [Bandwidth] [ANT_Path] [RateID] [Tx Mode]
[Packet Interval] [Packet Length] [Packet Count] [Packet Pattern]`

[Channel]	:	1~177
[Bandwidth]	:	20M = 0, 40M = 1, 80M = 2
[ANT_Path]	:	Path A = a, Path B = b, Path C = c, Path D = d, Path AB(2x2) = ab, ...
[Tx Mode]	:	Packet Tx = 1, Continuous Tx = 2, OFDM Single Tone Tx = 3
[Packet Interval]	:	(Option) 1~65535us, default is 2000
[Packet Length]	:	(Option) Data length of packet payload, default is 1500
[Packet Count]	:	(Option) For continuous packet Tx. Counting Tx packets.
[Packet Pattern]	:	(Option) 0x00~0xff, default is random HEX.

[RateID] :

1M	2M	5.5M	11M	6M	9M	12M
18M	24M	36M	48M	54M		
HTMCS0	HTMCS1	HTMCS2	HTMCS3	HTMCS4	HTMCS5	HTMCS6
HTMCS7	HTMCS8	HTMCS9	HTMCS10	HTMCS11	HTMCS12	HTMCS13
HTMCS14	HTMCS15	HTMCS16	HTMCS17	HTMCS18	HTMCS19	HTMCS20
HTMCS21	HTMCS22	HTMCS23	HTMCS24	HTMCS25	HTMCS26	HTMCS27
HTMCS28	HTMCS29	HTMCS30	HTMCS31			
VHT1MCS0	VHT1MCS1	VHT1MCS2	VHT1MCS3	VHT1MCS4	VHT1MCS5	VHT1MCS6
VHT1MCS7	VHT1MCS8	VHT1MCS9				
VHT2MCS0	VHT2MCS1	VHT2MCS2	VHT2MCS3	VHT2MCS4	VHT2MCS5	VHT2MCS6

VHT2MCS7 VHT2MCS8 VHT2MCS9

After measuring, use the below command to stop Tx.

rtwpriv wlan0 stop

//stop HW Tx

6.2. Software Rx parameters

```

rtwpriv wlan0 mp_start          //Start MP mode

rtwpriv wlan0 mp_channel [Channel]      //Set Rx channel

rtwpriv wlan0 mp_ant_rx [ANT_Path]      //Set path

rtwpriv wlan0 mp_bandwidth 40M=[Bandwidth], shortGI=[GI] //Set bandwidth

rtwpriv wlan0 mp_arx start          //Start SW Rx

rtwpriv wlan0 mp_reset_stats        //Reset the Rx report

rtwpriv wlan0 mp_arx phy            //Get Rx phy packet count.

rtwpriv wlan0 mp_query              //Get Tx/Rx packet counter.

```

```

[Channel]          : 1~177

[Bandwidth]       : 20M = 0, 40M = 1, 80M = 2

[GI]              : Long GI = 0, Short GI = 1

[ANT_Path]        : Path A = a, Path B = b, Path C = c, Path D = d, Path AB(2x2) = ab, ...

```

After measuring, use the below command to stop MP.

```

rtwpriv wlan0 mp_stop          //Stop MP mode

```

7. Bluetooth MP flow appendix

Contains the following

- Tx gain K mapping table
- Tx flatness K mapping table
- Bluetooth Tx power table

7.1. Bluetooth MP tool command usage

- Bluetooth start , exit and help command
- Bluetooth MP initialize commands at Linux/Android platform
- Bluetooth control parameters commands
- Bluetooth execute commands
- Bluetooth report commands

Exit MP Tool

quit

```
> quit
quit
:::::::::: Bluetooth MP Test Tool Terminating ::::::::::::
```

Lookup MP CMDs

help

```
> help
help
help :: Lists all available console commands
quit :: Abort the MP tool test app
enable :: Enable bluetooth
disable :: Disable bluetooth
bt_mp_HciCmd :: Send HCI Commands
bt_mp_GetParam :: Get all/individual exposed parameters
bt_mp_SetParam :: Set specific parameters<index,value>
bt_mp_SetParam1 :: Set series 1 parameters
bt_mp_SetParam2 :: Set series 2 parameters
bt_mp_SetConfig :: Set configurations to the specific file
bt_mp_Exec :: Execute specific action<action id>
bt_mp_Report :: Report specific info according to item selected
bt_mp_RegRW :: R/W Modem, RF, SYS & BB registers
>
```

7.1.2. Bluetooth MP initialize commands at Linux/Android platform

These commands used to initialize Bluetooth DUT in MP mode are listed as below:

MP Command	Parameters	Return	Description
rtlbtmp	None	[success]	Start the MP CMD tool.
enable	USB: enable usb:/dev/rtk_btusb	[success]	Enable USB I/F Bluetooth MP stack and download FW code. Device node is fixed as /dev/rtk_btusb .
	UART5: enable uart:/dev/ttyS0 enable uart5:/dev/ttyS0 UART4: enable uart4:/dev/ttyS0	[success]	Enable Uart I/F Bluetooth MP stack and download FW code. Device node is chosen by vendor specifically . H5 (UART5) or H4 (UART4) is determined by the chip configurations. Customers can consult FAE for detailed information.
disable	None	[success]	Disable Bluetooth MP stack and close the device.
quit	None	None	Exit from the MP CMD tool.
help	None	None	List all MP CMDs supported.

Table 17: BT_MP_initialize_CMD

NOTE: Before running the MP CMD tool, BT on UI settings should be **disabled**; otherwise, MP tool will be at abnormal status.

7.1.3. Bluetooth MP mode control parameters commands

These commands used to set/get Bluetooth DUT parameters.

MP Command	Parameters	Return		
bt_mp_SetParam	Index0,value0;Index1,value1;...;IndexN,valueN	Return Index	Return Status	
bt_mp_GetParam	Index	Return Index	Return Status	Return Value

Table 18: BT MP CONTROL_PARAM_CMD

Bluetooth Control Commands: Set/Get parameter command

Set parameters :

[bt_mp_SetParam](#)

Check the parameters :

[bt_mp_GetParam](#)

The Format is :

[bt_mp_SetParam Index0,value0; Index1,..;IndexN,valueN](#)

INDEX	VALUE	Length (Byte)	Value Range	Table Index
0	PGRawData	256	Row data	None (Not support Combo Chip WIFI+BT series)
1	ChannelNumber	1	0~78	None
2	PacketType	1	0~9	Refer to PKT_TYPE
3	PayloadType	1	0~7	Refer to PAYLOAD_TYPE and LE_PAYLOAD_TYPE
4	TxPacketCount (only for packet tx)	2	0~0xFFF	Refer to 2.3.3.1.3
5	TxGainValue	1		
6	WhiteningCoeffValue	1	0x00~0x7F	Enable Whitening : 0x00~0x7f Disable Whitening : 0x80
7	TxGainIndex	1	0x00:	Refer to 2.3.3.1.5

			Default tx gain	
9	PacketHeader	4	0x0~0x3FFFF	Refer to PACKET_HEADER
10	HoppingFixChannel (for Hopping mode)	1	0 : Disable 1 : Enable fix Channel	None
11	HitTarget	6	6 bytes	None
14	Xtal	4	0~0x7F	Depend on chip serials. (Not support Combo Chip WIFI+BT series)
15	LEDataLen	1	BT4.0 : 0x00~0x25 BT5.0 : 0x00~0xFF	BLE TX Data Length
16	PHY	1	1~4	Refer to BLE5.0_TX_PKT_TYPE and BLE5.0_RX_PKT_TYPE
17	ModulationIndex	1	0,1	Refer to BLE5.0_MODULATION_TYPE
18	a. set/get enable/disable tx power tracking b. bt_diff_s0s1 c. set gain K d. set flatness e. set tx default power f. SET_K_TX_CH_P WR g. TX_PATH_LOSS_ MODULE h. CONFIG_EXTEND i. set Antenna s0/s1 j. set hopping start channel and stop channel			TBD
19	calculate_XtalBoundary calculate_XtalNormal	2		TBD

Table 19: BT PARAM_INDEX

BT_PKT_TYPE

NAME	INDEX	Payload Length in bits
BT_PKT_DH1	0	0~27*8
BT_PKT_DH3	1	0~183*8
BT_PKT_DH5	2	0~339*8
BT_PKT_2DH1	3	0~54*8
BT_PKT_2DH3	4	0~367*8
BT_PKT_2DH5	5	0~679*8
BT_PKT_3DH1	6	0~83*8
BT_PKT_3DH3	7	0~552*8
BT_PKT_3DH5	8	0~1021*8
BT_PKT_LE	9	0~39*8

Table 20: BT_PKT_TYPE**BLE5.0_Tx_PKT_TYPE**

NAME	INDEX
BLE5_TX_1M_PHY	1
BLE5_TX_2M_PHY	2
LE5_TX_CODED_PHY_S8	3
LE5_TX_CODED_PHY_S2	4

Table 21: BT BLE5.0_Tx_PKT_TYPE**BLE5.0_Rx_PKT_TYPE**

NAME	INDEX
BLE5_TX_1M_PHY	1
BLE5_TX_2M_PHY	2
LE5_TX_CODED_PHY_LR	3

Table 22: BT BLE5.0_Rx_PKT_TYPE**BLE5.0_MODULATION_TYPE**

NAME	INDEX
STANDARD_MODULATION_INDEX	0
STABLE_MODULATION_INDEX	1

Table 23: BT BLE5.0_MODULATION_TYPE

The payload types are defined in Table PAYLOAD_TYPE.

NAME	INDEX
BT_PAYLOAD_TYPE_ALL0	0
BT_PAYLOAD_TYPE_ALL1	1
BT_PAYLOAD_TYPE_0101	2
BT_PAYLOAD_TYPE_1010	3
BT_PAYLOAD_TYPE_0x0_0xF	4
BT_PAYLOAD_TYPE_0000_1111	5
BT_PAYLOAD_TYPE_1111_0000	6
BT_PAYLOAD_TYPE_PRBS9	7

Table 24: BT PAYLOAD_TYPE

LE_PAYLOAD_TYPE

NAME	INDEX
BT_LE_PAYLOAD_TYPE_PRBS9	0
BT_LE_PAYLOAD_TYPE_1111_0000	1
BT_LE_PAYLOAD_TYPE_1010	2
BT_LE_PAYLOAD_TYPE_PRBS15	3
BT_LE_PAYLOAD_TYPE_ALL1	4
BT_LE_PAYLOAD_TYPE_ALL0	5
BT_LE_PAYLOAD_TYPE_0000_1111	6
BT_LE_PAYLOAD_TYPE_0101	7

Table 25: BT LE_PAYLOAD_TYPE

PACKET TYPE

PACKET TYPE	PAYLOAD(Bits)	PACKET HEADER HEX
DH1	216	33820
DH3	1464	39858
DH5	2712	A078
2DH1	432	33820
2DH3	2936	C050
2DH5	5432	3F870
3DH1	664	15C40
3DH3	4416	39858
3DH5	8168	A078

Table 26: BT PACKET_HEADER

Bluetooth TxPacketCount parameter

TxPacketCount is used to set how many Tx packets will be transmitted. The range of TxPacketCount is from **0 to 0xFFF**. If TxPacketCount value set to “0”, it means to send Tx packet counts continuously.

Bluetooth WhiteningCoeffValue parameter

The range of **WhiteningCoeffValue** is from **0 to 0x7F**. If WhiteningCoeffValue is “0x80”, it means to disable whitening.

Bluetooth TX gain cal (K) value

Set Tx gain Cal value will change BR/EDR(1/2/3M) and BLE TX power at the same time.

7.1.4. Bluetooth MP mode execute commands

Using this command to control bt mp action, and get current report.

MP Command	Parameters	Return	
bt_mp_Exec	Action	Return Action	Return Status

You can use

bt_mp_Exec ACTION_INDEX

The definition of ACTION_INDEX can refer to “BT_ACTIONCONTROL_TAG” Table.

Example: If you want to run FW packet Tx, please use

bt_mp_Exec 30 // Start FW_PACKET_TX_START

bt_mp_Exec 31 //Stop FW_PACKET_TX_STOP

```
> bt_mp_Exec 12
bt_mp_Exec[Success:0]
> bt_mp_Exec,12,0x00

> bt_mp_Exec 14
bt_mp_Exec[Success:0]
> bt_mp_Exec,14,0x00
```

Command /define	Index	Support Chip RTL8761B
HCI_RESET	0	☒
TEST_MODE_ENABLE	1	☒
WRITE_EFUSE_DATA	2	☒
SET_TX_GAIN_TABLE	3	☒
SET_TX_DAC_TABLE	4	☒
SET_DEFAULT_TX_GAIN_TABLE	5	☒
SET_DEFAULT_TX_DAC_TABLE	6	☒
SET_POWER_GAIN_INDEX	7	☒
SET_POWER_GAIN	8	☒
SET_POWER_DAC	9	☒
SET_XTAL	10	☒
REPORT_CLEAR	11	☒
PACKET_TX_START	12	☒
PACKET_TX_UPDATE	13	☒
PACKET_TX_STOP	14	☒
CONTINUE_TX_START	15	☒
CONTINUE_TX_UPDATE	16	☒
CONTINUE_TX_STOP	17	☒
PACKET_RX_START	18	☒
PACKET_RX_UPDATE	19	☒
PACKET_RX_STOP	20	☒
HOPPING_DWELL_TIME	21	☒
LE_TX_DUT_TEST_CMD	22	☒
LE_RX_DUT_TEST_CMD	23	☒
LE_DUT_TEST_END_CMD	24	☒
READ_EFUSE_DATA	25	☒
LE_CONTINUE_TX_START	28	☒
LE_CONTINUE_TX_STOP	29	☒
FW_PACKET_TX_START	30	☒
FW_PACKET_TX_STOP	31	☒
FW_PACKET_RX_START	32	☒
FW_PACKET_RX_STOP	33	☒
FW_CONTINUE_TX_START	34	☒
FW_CONTINUE_TX_STOP	35	☒
FW_LE_CONTINUE_TX_START	36	☒










FW_LE_CONTINUE_TX_STOP	37	
FW_READ_TX_POWER_INFO	38	
SET_GPIO3_0	39	
SET_ANT_INFO	40	
SET_ANT_DIFF_S0S1	41	
TX_POWER_TRACKING	42	
SET_K_TX_CH_PWR	43	
WRITE_FLASH_CONFIG	44	
TX_POWER_GAIN_K	45	
TX_POWER_FLATNESS	46	
TX_PATH_LOSS_MODULE	47	
CONFIG_EXTEND	48	
READ_FLASH_CONFIG	49	
UNLOCK_8822C	50	
SetTxPower_8822C_8761B	51	

Table 27: BT_ACTIONCONTROL_TAG

7.1.5. Bluetooth MP mode report commands

These commands used to report Bluetooth DUT Tx/Rx status are listed as below:

bt_mp_Report “Item Index”

Item Index	Item Index	Return								
PKT TX = 1	1	Status	TXBits	TxCounts						
CONT TX = 2	2		TXBits	TxCounts						
PKT RX = 3	3		RxRssi	RXBits	RxCounts	RxErrorBits				
Tx Gain Table = 4	4		Tx Gain Table							
Tx DAC Table = 5	5		Tx DAC Table							
Xtal = 6	6		Xtal							
Thermal = 7	7		Thermal							
Stage = 8	8		Stage							
Efuse = 10	10		Efuse							
LE RX = 11	11		RxCounts							
LE CONT TX=12	12		TXBits	TxCounts						
FW_PKT_TX=13	13		TXBits	TxCounts						
FW_CONT_TX=14	14		TXBits	TxCounts						
FW_PKT_RX=15	15		RxRssi	RXBits	RxCounts	RxErrorBits				
FW_LE_CONT_TX=16	16		TXBits	TxCounts						
TX_POWER_INFO=17	17		Max tx power index	default tx power index						
				1M	2M	3M	BLE 1M	BLE 2M	LE	
REPORT_GPIO3_0	18									
REPORT_MP_DEBUG_MESSAGE	19									
REPORT_MP_FT_VALUE	20									
REPORT_POWER_TRACKING	21									

REPORT_MP_TXCAL_INFO	22		TxGainK	Flatness(LSB)	Flatness (MSB)	TXPathLoss			
REPORT_FLASH_CONFIG	23								
REPORT_XTALBOUNDARY	24		DIV_int	DIV_frac(LSB)	DIV_frac (MSB)				
REPORT_XTALNORMAL	25		NewXtalIndex						

7.2. Bluetooth eFuse definition about calibrates of Tx power

First, view the eFuse (config file) content about setting of power index and channel adjust value. Normal driver will load this value in initial step. So this value must be well-calibrated and filled on correct eFuse location. Please check next page for detail introduction of Tx power setting of efuse (config file).

Efuse Offset	Explanation
0x278[1]	Tx gain K valid bit*
0x278[2]	Flatness K valid bit**
0x279[7:0]	TX Gain K
0x27A[7:0]~0x27B[7:0]	Flatness K
0x280[7:0]	1M Max TX Power [#]
0x281[7:0]	2M Max TX Power [#]
0x282[7:0]	3M Max TX Power [#]
0x283[7:0]	LE 1M Max TX Power [#]
0x28C[7:0]	Tmeter module K

Table 28: BT Tx gain index offset in eFuse

*After TX gain K flow please remember to enable this bit which 0x278 will be 02

**After TX flatness K flow please remember to enable this bit which 0x278 will be 04

Note: If both TX gain K & TX flatness K are been done please enable both valid bits which 0x278 will be 06

[#] Please note that RTK adapt max Tx setting for 8822C series combo chip in different certification (FCC, CE, etc.) in order to confirm radio characteristic of our work could still pass compliance rule under extreme condition. For general purpose, Tx value for MP is set to 5 dBm to obtain the best power consumption performance and user experience. Therefore, customer who uses our module may need to provide permissive change files during certification of your own product for different Tx power setting. Here listed the main power restraint due to CE compliance, EIRP should less than 10 dBm.

Efuse notification: Default Tx setting of efuse map release by RTK is set to 5 dBm which the setting is shown below as Fig A. If customer need to adopt other Tx target power for their own product please following the power table listed in “7.4.Bluetooth Tx power table” and revise the efuse map by themselves. For example 4 dBm setting is shown in Fig B. This efuse map file need to burn in DUT after passing through Tx calibration flow. Please note that Max Tx power variation could achieve +- 2 dB due to PCB or component variation even after calibration. Therefore we suggest customer take +- 2dB margin during changing Tx value of efuse map file. For example, if the Max power of the product could not exceed 6 dBm then Tx value for 4 dBm (Fig. 11) is a better choice.




Figure 10: BT_5 dBm setting example (Capture image from efuse map file) RTK default map




Figure 11: BT_4 dBm setting example (Capture image from efuse map file)

7.3. Tx flatness K mapping table

All flatness value can map to below table:

Txpower_flat_diff_value	Efuse Flatness value
6	0x6
5	0x5
4	0x4
3	0x3
2	0x2
1	0x1
0	0x0
-1	0xF
-2	0xE
-3	0xD
-4	0xC
-5	0xB
-6	0xA

The Txpower_flatness value is defined as :

Bits	Define	
0~3	Low Channel Flatness	CH 0~21
4~7	MidLow Channel Flatness	CH 22~43
8~11	MidHigh Channel, Flatness	CH 44~61
12~15	High Channl Flatness	CH 62~78

For example :

Channel	Measure Tx power(dBm)	Txpower_flat_diff calculate	Txpower_flat_diff	Value	Flatness value
10	-0.6	$\text{floor}((0-(-0.6))*2)$	1	0x1	0xDE01
32	-0.3	$\text{floor}((0-(-0.3))*2)$	0	0x0	
52	0.7	$\text{floor}((0-(0.7))*2)$	-2	0xE	
70	1.2	$\text{floor}((0-(1.2))*2)$	-3	0xD	

Note: Efuse offset 0x27A[7:0] = 0x01 , Efuse offset 0x27B[7:0] = 0xDE

7.5. Verify Bluetooth BDR/EDR Tx SPEC

To measure the DUT Bluetooth legacy Tx power/initial Carrier offset/modulation characteristics to check whether Tx performance is fine or not. Bluetooth legacy Tx criterion is shown as below. Below SPEC is defined by using 5 dBm as target power at normal temperature 25 degree C. **For vender's Tx verification, please adapt target power value as your own SPEC.**

Verify Bluetooth Tx Basic 1M							
Test Item	Sub Test item	Channel	Packet Type	Payload Type	SPEC		
Output Power	Peak Power	0 6 39 42 70 78	DH1 DH3 DH5	PRBS9	< 9.5 dBm NOTE: Max variation = target power value +/- 4.5 dB*		
	Average Power			PRBS9	3 dBm ~ 7 dBm NOTE: Max variation = target power variation +/- 2 dB*		
Modulation Characteristics	Delta F1 Avg.			39	DH1	00001111	140KHz ~ 175KHz
	Delta F2 Avg			42	DH3	10101010	None
	Delta F2 Max.			70	DH5	10101010	> 115KHz
	Modulation Index			78		F2avg/F1avg	> 0.8
Initial Carrier Frequency						PRBS9	abs. < 20KHz
20dB BW						PRBS9	< 1000KHz
CF. Drift						PRBS9	abs. < 25KHz
Max. Drift Rate						PRBS9	< 20KHz/50us

Table 29: Verify Bluetooth Tx Basic 1M

*Max variation SPEC only available after doing Tx calibration flow

Verify Bluetooth Tx EDR 2M								
Test Item	Sub Test item	Channel	Packet Type	Payload Type	SPEC			
Output Power	Peak Power	0 6 39 42 70 78	2DH1 2DH3 2DH5	PRBS9	< 9 dBm NOTE: Max variation = target power value +/- 4dB*			
	Average Power				3 dBm ~ 7 dBm NOTE: Max variation = target power value +/- 2 dB*			
Relative Transmit Power ($P_{GFSK} - P_{DPSK}$)								-4 ~ 1
Omega I								abs. < 20KHz
Omega 0								abs. < 10KHz
Omega I +								abs. < 20KHz
Enhanced data rate carrier frequency stability and modulation accuracy	RMS DEVM							< 0.20
	Peak DEVM							< 0.35
	0.99 DEVM							> 0.99

Table 30: Verify Bluetooth Tx EDR 2M

*Max variation SPEC only available after doing Tx calibration flow

Verify Bluetooth Tx EDR 3M					
Test Item	Sub Test item	Channel	Packet Type	Payload Type	SPEC
Output Power	Peak Power	0 6 39 42 70 78	3DH1 3DH3 3DH5	PRBS9	< 9 dBm NOTE: Max variation = target power value + / - 4dB*
	Average Power				3 dBm ~ 7 dBm NOTE: Max variation = target power value +/- 2 dB*
Relative Transmit Power ($P_{GFSK} - P_{DPSK}$)					-4.00dB - 1.00dB
Omega I					abs. < 20KHz
Omega 0					abs. < 10KHz
Omega I +					abs. < 20KHz
Enhanced data rate carrier frequency stability and modulation accuracy	RMS DEVM				< 0.13
	Peak DEVM				< 0.25
	0.99 DEVM				> 0.99

Table 31: Verify Bluetooth Tx EDR 3M

7.6. Verify Bluetooth BDR/EDR Rx SPEC

To Measure the DUT Rx sensitivity to check whether Rx performance is fine or not. The Rx performance test can be measured in signaling mode (ex: Anritsu 8852B, Agilent N4010A) or non-signaling mode (ex: LitePoint IQNxN). Bluetooth Rx criterion is shown as below :

Channel	Payload Type	Legacy sensitivity limit	Criterion
			Bluetooth SPEC
0/6/39/42/70/78	PRBS9	EDR1M_BER < 0.01%	< -85 dBm
0/6/39/42/70/78	PRBS9	EDR2M/3M_BER < 0.01%	< -80 dBm

Table 32: Bluetooth Legacy Rx criterion

7.7. Verify Bluetooth BLE Tx Performance (BLE 1M)

To measure the DUT BLE Tx power and modulation index to check whether BLE Tx performance is fine or not. Bluetooth BLE Tx criterion is shown as below. Below Spec is defined by using 5 dBm as target power at normal temperature 25 degree C. **For vender's Tx verification, please adapt target power value as your own SPEC.**

Test Item	Sub Test Item	Payload Type	Channel	Criterion
				Bluetooth SPEC
BLE Output Power	Average Power	PRBS9	0/3/19/22/36/39	3 dBm ~ 7dBm NOTE: Max variation = target power value +/- 2 dB*
	Peak Power			< 9 dBm NOTE: Max variation = target power value + / - 4dB*
Carrie freq. offset & drift	None	PRBS9		< 20KHz
Modulation Characteristics	Delta F1 Avg.	BT_PAYLOAD_TYPE_1111_000		225 kHz ~ 275 kHz
	Delta F2 Max.	BT_PAYLOAD_TYPE_1010		> 185 kHz
	F2avg/F1avg	None		> 0.8

Table 33: Bluetooth BLE Tx criterion

*Max variation SPEC only available after doing Tx calibration flow

7.8. Verify Bluetooth BLE 5.0 Tx Performance

To measure the DUT BLE 5.0 Tx power and modulation index to check whether BLE Tx performance fine or not. Bluetooth BLE 5.0 Tx criterion is shown as below. Below SPEC is defined by using 5 dBm as target power at normal temperature 25 degree C. **For vender's Tx verification, please adapt target power value as your own spec.**

PHY SPEC	Test Item	Sub Test Item	Payload Type	Channel	Criterion
					Bluetooth SPEC
2M	BLE Output Power	Average Power	PRBS9	0/3/19/22/36/39	3 dBm ~ 7 dBm NOTE: Max variation = target power value +/- 2 dB*
LR S2					< 9 dBm NOTE: Max variation = target power value +/- 4dB*
LR S8	Peak Power				
2M	Carrie freq. offset & drift	None	PRBS9		2M: < 20kHz
LR S2			PRBS9		S8: < 19.2kHz
LR S8			PRBS9		
2M	Modulation Characteristics	Delta F1 Avg.	BT_PAYLOAD_TY PE_1111_0000		2M: 450 ~ 550 kHz S8: 225 ~ 275 kHz
LR S2		Delta F2 Max.	BT_PAYLOAD_TY PE_1010		2M: > 370kHz
LR S8		F2avg/F1avg	None		2M: > 0.8

Table 34: Bluetooth BLE 5.0 Tx criterion

*Max variation SPEC only available after doing Tx calibration flow

7.9. Verify Bluetooth BLE Rx Performance

To calculate the Packet Error Rate (PER)

$$PER\% = 100 * (1 - (\text{Packets Received} / \text{Packets Send}))$$

To measure the DUT BLE Rx sensitivity to check whether Rx performance is fine or not.

The Bluetooth Rx criterion is shown as below:

Channel	SPEC	Payload Type	BLE sensitivity limit	Criterion
	PHY SPEC			Bluetooth SPEC
0/3/19/22/36/39	1M	PRBS9	PER<= 30.800 %	< -85 dBm
	2M	PRBS9	PER<= 30.800 %	< -85 dBm
	LRS2	PRBS9	PER<= 30.800 %	< -85 dBm
	LRS8	PRBS9	PER<= 30.800 %	< -85 dBm

Table 35: Bluetooth BLE Rx criterion

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference,
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Requirement per KDB996369 D03

2.2 List of applicable FCC rules

List the FCC rules that are applicable to the modular transmitter. These are the rules that specifically establish the bands of operation, the power, spurious emissions, and operating fundamental frequencies. DO NOT list compliance to unintentional-radiator rules (Part 15 Subpart B) since that is not a condition of a module grant that is extended to a host manufacturer. See also Section 2.10 below concerning the need to notify host manufacturers that further testing is required.³

Explanation: This module meets the requirements of FCC part 15C(15.247).

2.3 Summarize the specific operational use conditions

Describe use conditions that are applicable to the modular transmitter, including for example any limits on antennas, etc. For example, if point-to-point antennas are used that require reduction in power or compensation for cable loss, then this information must be in the instructions. If the use condition limitations extend to professional users, then instructions must state that this information also extends to the host manufacturer's instruction manual. In addition, certain information may also be needed, such as peak gain per frequency band and minimum gain, specifically for master devices in 5 GHz DFS bands.

Explanation: The EUT has a Ceramic Antenna, and the antenna use a permanently attached antenna which is not replaceable.

2.4 Limited module procedures

If a modular transmitter is approved as a "limited module," then the module manufacturer is responsible for approving the host environment that the limited module is used with. The manufacturer of a limited module must describe, both in the filing and in the installation instructions, the alternative means that the limited module manufacturer uses to verify that the host meets the necessary requirements to satisfy the module limiting conditions.

A limited module manufacturer has the flexibility to define its alternative method to address the conditions that limit the initial approval, such as: shielding, minimum signaling amplitude, buffered modulation/data inputs, or power supply regulation. The alternative method could include that the limited module manufacturer reviews detailed test data or host designs prior to giving the host manufacturer approval.

This limited module procedure is also applicable for RF exposure evaluation when it is necessary to demonstrate compliance in a specific host. The module manufacturer must state how control of the product into which the modular transmitter will be installed will be maintained such that full compliance of the product is always ensured. For additional hosts other than the specific host originally granted with a limited module, a Class II permissive change is required on the module grant to register the additional host as a specific host also approved with the module.

Explanation: The module is not a limited module.

2.5 Trace antenna designs

For a modular transmitter with trace antenna designs, see the guidance in Question 11 of KDB Publication 996369 D02 FAQ – Modules for Micro-Strip Antennas and traces. The integration information shall include for the TCB review the integration instructions for the following aspects: layout of trace design, parts list (BOM), antenna, connectors, and isolation requirements.

- a) Information that includes permitted variances (e.g., trace boundary limits, thickness, length, width, shape(s), dielectric constant, and impedance as applicable for each type of antenna);
- b) Each design shall be considered a different type (e.g., antenna length in multiple(s) of frequency, the wavelength, and antenna shape (traces in phase) can affect antenna gain and must be considered);
- c) The parameters shall be provided in a manner permitting host manufacturers to design the printed circuit (PC) board layout;
- d) Appropriate parts by manufacturer and specifications;
- e) Test procedures for design verification; and
- f) Production test procedures for ensuring compliance.

The module grantee shall provide a notice that any deviation(s) from the defined parameters of the antenna trace, as described by the instructions, require that the host product manufacturer must notify the module grantee that they wish to change the antenna trace design. In this case, a Class II permissive change application is required to be filed by the grantee, or the host manufacturer can take responsibility through the change in FCC ID (new application) procedure followed by a Class II permissive change application.

Explanation: Yes, The module with trace antenna designs, and This manual has been shown the layout of trace design,, antenna, connectors, and isolation requirements.

2.6 RF exposure considerations

It is essential for module grantees to clearly and explicitly state the RF exposure conditions that permit a host product manufacturer to use the module. Two types of instructions are required for RF exposure information: (1) to the host product manufacturer, to define the application conditions (mobile, portable – xx cm from a person's body); and (2) additional text needed for the host product manufacturer to provide to end users in their end-product manuals. If RF exposure statements and use conditions are not provided, then the host product manufacturer is required to take responsibility of the module through a change in FCC ID (new application).

Explanation: This module complies with FCC RF radiation exposure limits set forth for an uncontrolled environment, This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body." This module is designed to comply with the FCC statement

2.7 Antennas

A list of antennas included in the application for certification must be provided in the instructions. For modular transmitters approved as limited modules, all applicable professional installer instructions must be included as part of the information to the host product manufacturer. The antenna list shall also identify the antenna types (monopole, PIFA, dipole, etc. (note that for example an “omni-directional antenna” is not considered to be a specific “antenna type”)).

For situations where the host product manufacturer is responsible for an external connector, for example with an RF pin and antenna trace design, the integration instructions shall inform the installer that unique antenna connector must be used on the Part 15 authorized transmitters used in the host product. The module manufacturers shall provide a list of acceptable unique connectors.

Explanation: The EUT has a Ceramic Antenna, and the antenna use a permanently attached antenna which is unique.

2.8 Label and compliance information

Grantees are responsible for the continued compliance of their modules to the FCC rules. This includes advising host product manufacturers that they need to provide a physical or e-label stating “Contains FCC ID” with their finished product. See [Guidelines for Labeling and User Information for RF Devices – KDB Publication 784748](#).

Explanation:The host system using this module, should have label in a visible area indicated the following texts: "Contains FCC ID: AQ5RWF-M68B-UWK1.

2.9 Information on test modes and additional testing requirements

Additional guidance for testing host products is given in KDB Publication 996369 D04 Module Integration Guide. Test modes should take into consideration different operational conditions for a stand-alone modular transmitter in a host, as well as for multiple simultaneously transmitting modules or other transmitters in a host product.

The grantee should provide information on how to configure test modes for host product evaluation for different operational conditions for a stand-alone modular transmitter in a host, versus with multiple, simultaneously transmitting modules or other transmitters in a host.

Grantees can increase the utility of their modular transmitters by providing special means, modes, or instructions that simulates or characterizes a connection by enabling a transmitter. This can greatly simplify a host manufacturer’s determination that a module as installed in a host complies with FCC requirements.

Explanation: KTC can increase the utility of our modular transmitters by providing instructions that simulates or characterizes a connection by enabling a transmitter.

2.10 Additional testing, Part 15 Subpart B disclaimer

The grantee should include a statement that the modular transmitter is **only** FCC authorized for the specific rule parts (i.e., FCC transmitter rules) listed on the grant, and that the host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification. If the grantee markets their product as being Part 15 Subpart B compliant (when it also contains unintentional-radiator digital circuitry), then the grantee shall provide a notice stating that the final host product still requires Part 15 Subpart B compliance testing with the modular transmitter installed.

Explanation: The module without unintentional-radiator digital circuitry, so the module does not require an evaluation by FCC Part 15 Subpart B. The host should be evaluated by the FCC Subpart B.