


成品尺寸: 84X110MM

80克书写纸黑白印刷 风琴页折叠

Model: IPB203

Quick Start Guide




Package contents

- 1x Doorbell camera
- 1x Indoor chime
- 1x USB charging cable
- 1x Installation set
- 1x Reset pin
- 1x Quick Start Guide


Description

Doorbell



- 1.) Microphone
- 2.) Lens
- 3.) Light sensor
- 4.) Indicator
red- charging
blue - working

- 5.) Doorbell button
- 6.) Reset button
- 7.) Speaker
- 8.) Screw hole
(for install the doorbell and wall bracket)
- 9.) Type-C charging port



Chime

- 1.) Indicator
- 2.) Speaker
- 3.) Pairing button
- 4.) Voice +/-
- 5.) Tune
- 6.) USB 2.0 power connector


Before using the doorbell

- 1.) Charge the doorbell device via a 5V(1A~2A) adapter (adapter not included) and supplied charging cable. While the doorbell is in charging, the charging indicator(red) will be turned on. The charging indicator will be turned off automatically while the battery is fully charged.

- 2.) Before mounting the doorbell, use your smartphone to test if the Wi-Fi signal be covered and strong signal. Place the camera in a location with a clear, unblock field of view.

Pair the chime and doorbell

The indicator will be flashed when the chime is ready to pair



- 1.) Plug-in the USB chime in to a 5V(1A ~2A) adapter or a USB 2.0 socket to power on the chime.
- 2.) Hold and press the **A-pair button** of the chime, the indicator of the chime will be flashed which means the chime is ready to pair.
- 3.) Press the **B-ring button** of the doorbell camera, the chime will receive the signal and ring, means the chime is connected to the doorbell camera.
- 4.) Press the **voice +/-** button to switch the volume of the chime.
- 5.) Press the **tune button** to choose your desired tune

Installation – Connect the doorbell with the app

1.) Power the camera

After full charge the battery, hold and press the bell button for 3 seconds to turn on the doorbell.


2.) App setup and installation

Use your mobile phone or tablet to search for “TuyaSmart” or “Smartlife” in Google Play (for Android OS) or in the Apple app store (for iOS) to find the app, and install it according the instructions.




Register an account

If this is the first time using the app, you need to register an account as per below:



Note:


1.) Make sure your smartphone already connected to a 2.4GHz Wi-Fi and the Bluetooth turns ON.





2.) Press the ring button of the doorbell, then tap "scan" or "Smart camera(BLE)" from the app.



Ring the bell make sure the blue indicator is blinking.



The device only works when someone rings the bell. User will get the notification and phone call from the app. The message center helps user to check the history of the visitors.



Q: Camera will not connect to my Wi-Fi network?

A: Make sure the Wi-Fi signal is flashing. If the Wi-Fi signal is not flashing, you will need to press and hold Reset Button located at the back of the camera(see the Description section).

- Make sure the Wi-Fi network is a 2.4GHz network, device will not connect to a 5GHz network.
- Test your Wi-Fi network work with other devices such as your phone or computer to make sure it is operation properly.
- The Wi-Fi connection may be out of range during pairing. Use your phone to check range, it is recommended to have at least 2 signal bars showing for proper connection.
- Your Wi-Fi network password is case sensitive, make sure you are entering it correctly.

Q: The camera is off-line

- A: - Charging the doorbell and try again, to check if it is because of low battery.
 - There may be a temporary issue with your internet connection (e.g., service disruption). Please try again in a few minutes.
 - Make sure your Wi-Fi router is turned On.
 - The camera may not have power to it, make sure the wall switch and breaker is in the On position.
 - Make sure the camera is getting a good signal from your Wi-Fi router. Use your phone to check range, it is recommended to have at least 2 signal bars showing for proper connection.
- The camera may have been disconnected from your Wi-Fi network, press and hold Reset Button(see the Description section) until you hear an audible tone.

Warning

To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user's authority to operate this equipment.

FCC Statement

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.