







- The camera can be mounted in several ways: The base is magnetic, allowing it to sit securely on a metal surface.
- The 2-sided foam pad can be placed on the bottom of the base and then stuck to a surface.
- The metal mount and 2-sided foam pad can be placed on the
- bottom of the base and then stuck to a surface.
- The metal mount can be installed to a non-magnetic surface, allowing the camera base to stick to that.



### Installing the Metal Mount

1. Find the location of where you would like to mount the camera, then using a pencil, place the metal mount against the surface and mark where the two screw holes on the metal mount are, on the surface. These will be the location of where you will drill to place the plastic anchors.



2. Drill two holes at the spot you marked, and push the plastic anchors into the wall.

3. Place the metal mount and align the holes with the anchors and drive or drill the mount screws in.

## Indicator Light




When the red indicaor light flashes quickly, it is in setting mode and means you can setup the camera via your mobile device.


When the blue indicator light is steady, it indicates that the camera is connected to Wi-Fi.

5

Android OS 4.4 or higher







# Troubleshooting

ı.	In the mode of local accessing,there is no way to connect the smartphone
n,	or tablet to the camera.
	>Make sure that the power plug is properly plugged in. >Make sure that the camera is enabled,and that the indicator of
n. f the	power/status light is red and flashing quickly.
	>Make sure that the camera and smartphone/tablet are located within an
r users.	effective receiving distance. >Reset may be needed for the camera.Please use the Setup tool to press
service	the reset button, then the camera will change to setting mode.
nt and	The red indicator will flash quickly,and you can then configure the network to connect the camera.
ease	In Internet accessing mode, the smartphone/tablet fails to connect to the
with	camera by Wi-Fi . >Make sure that the power plug is properly plugged in.
	>Make sure that camera is enabled, and that the indicator of power/status
	light is red.
m;	>Make sure during setup of the camera's Wi-Fi network, the correct
tification'	password is entered for the Wi-Fi router. >Make sure that the camera and Wi-Fi router are located within an effective
	receiving distance.
	>Make sure that your smartphone/tablet has successfully connected to Internet by Wi-Fi.
alarm of	NOTE: Product and application are updated periodically. The interface shown are only for example. No extra notification on further changes.
'n′	
	11

# Technical Support and Warranty Information

For technical support issues please visit our website at www.vivitar.com. You can find manuals, software and FAQ's on the website. Can't find what you are looking for? E-mail us at support@vivitar.com and one of our technical support team members will answer your questions. For phone support in the US please call 1-800-592-9541, in Australia call 1800-006 -614. If you are calling from anywhere else, please visit www.vivitar.com for your local toll free number.

### Warranty Information:

This warranty covers the original consumer purchaser only and is not transferable. Products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship will be repaired at no charge for parts or labor for a period of one year from the time of purchase.

### What Is Not Covered By Warranty:

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

## What To Do When Service Is Required:

When returning your defective product (postage pre-paid) for service, your package should include: 1. Copy of original bill of sale

12

- 2. A detailed written description of the problem.
- 3. Your return address and telephone number (Daytime)

## MAIL TO THE APPROPRIATE ADDRESS BELOW:

Sakar / Vivitar International **Attention: Service Department** 195 Carter Drive Edison, NJ 08817

For Australia Customers Only Return faulty camera to the Refund Counter at the store where purchased.

## FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in mobile/fixed (Min 20cm) exposure condition without restriction.

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or experienced radio/TV technician for help.

