

How to CHARGE your Scout v2 device

- Plug your Scout V2 into a standard USB-C charger. The Battery icon will slowly "breathe" green while it is charging and will change to solid green when fully charged.

How to SETUP your Scout v2

- On first use:
 - Press and HOLD the button till both the blue LED lights up in the top of the unit.
- To see status:
 - Briefly press the button and let go. The LEDs will blink to indicate status as shown in the table below.

3 seconds Green	Battery good
3 seconds Yellow	Battery Low
3 seconds red blinking	Device error

- When the unit shows red light, it needs to be sent back to the OEM

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by **Culvert IOT Corporation** may void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The user's manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.



<p>ISED Regulation Statement</p> <p><i>This device complies with Innovation, Science and Economic Development Canada's licence-exempt RSS. Operation is subject to the following two conditions:</i></p> <p><i>(1) This device may not cause interference, and</i></p> <p><i>(2) This device must accept any interference, including interference that may cause undesired operation of the device.</i></p> <p>Cet appareil est conforme aux flux RSS exempts de licence d'Innovation, Science et Développement économique Canada. L'opération est soumise aux deux conditions suivantes:</p> <p>(1) Cet appareil ne doit pas provoquer d'interférence; et</p> <p>(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.</p>	<p>ISED Radiation Exposure Statement</p> <p>[English] Radiation Exposure Statement: This equipment complies with the IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.</p> <p>[French] Énoncé d'exposition aux rayonnements: Cet équipement est conforme aux limites d'exposition aux rayonnements ioniques RSS-102 Pour un environnement contrôlé. Cet équipement doit être installé et utilisé avec un Distance minimale de 20 cm entre le radiateur et votre corps.</p>
--	--