

SHAKS S3i

User Manual




Before use

- Check out the manual before using S3i.
- Charge S3i fully before using it for the first time.

Contents



Controller buttons



Power on

- Press **Start** for 3 seconds

Compatible device

- iPhone, iPad
- Android phone, tablet
- AndroidTV Set-top box
- Windows PC
- MAC

LED status



| Status | Function | Mode |
|---------------|---------------------|---------------------|
| 1st LED | Pairing | Pairing |
| 2nd LED | Reconnect | Reconnect |
| 3rd LED | Android mode, macOS | Android mode, macOS |
| 4th LED | Windows mode | Windows mode |
| 1st & 2nd LED | iOS mode | iOS mode |
| 1st & 2nd LED | Windows (Win) | Windows (Win) |
| 3rd & 4th LED | Option2 on | Option2 on |
| 1st & 2nd LED | Charging | Charging |
| 3rd & 4th LED | Low Battery | Low Battery |

- Please refer to the **Bluetooth key** for mode change.
- Reconnect: When device is registered but not connected.

Bluetooth

- For mode changing: Select + L1
- For Bluetooth pairing: Select + Start

SHAKS App (Only for Android)


- Gamepad condition check
- Firmware upgrade
- OPTION button support (Auto, Sleep mode, Noise, Sensitive Camera...)
- Q&A

Android, PlayStation and AndroidTV, STL, MAC

- Setting mode: Change mode by pressing [SELECT+L1] for 5 seconds until 3rd and 4th LED is on.



- Pairing device: Find and connect SHAKS S3i on your device.



- Completed: If 1st and 2nd LEDs turned off and 3rd and 4th LED is on, it's connected.

Windows

- Please download SHAKS Xinput on our website: www.shaksgame.com
- Setting mode: Change mode by pressing [SELECT+L1] for 5 seconds until 4th LED is on.




- Pairing device: Find and connect SHAKS S3i on your PC.



- Completed: If 1st and 2nd LEDs turned off and only 4th LED is on, it's connected.

Execute SHAKS X-input program. S3i will be connected automatically on PC.



- What if the version information does not appear on the program?
 - ① Check general firmware update in SHAKS App
 - ② Check if the program itself is a new version (Old versions require re-download)

- If you use windows 7, please download "Xbox360 driver" additionally. (You can check this out on our website)

Phone and Pad

- Setting mode: Change mode by pressing [SELECT+L1] twice for 5 seconds until 3th LED is on.



- Pairing device: Find and connect SHAKS S3i on your device.



- Completed: If 1st and 2nd LEDs turned off and only 3rd LED is on, it's connected.

Option Button

- Press the option button. The mouse mode while the LED is working.



- L Stick: Mouse cursor movement
- R Stick: Wheel Scrolling (Left/Right)
- Press R Stick: Wheel button click




- A Button: Left click
- B Button: Right click

• Depending on your options settings, the functionality may vary.

How to reset

- Press reset button located on back of S3i for 3 seconds with pin etc.



Technical specifications

- Product: SHAKS S3i
- Connectivity: Bluetooth 5.0
- Frequency Band: 2400 - 2483MHz
- Output Power: Class 2
- Transmission Range: ~10 M
- Supported Profiles: HID
- Playing Time: Max 8h
- Charging Time: 1h
- Size: 160(W) x 118(D) x 45(H) mm
- Weight: 220 g

How to charge

- Charge battery with charging cable to a computer or USB power charging device (DWA).



| | |
|---------------------------|---------------------|
| When battery is low | ⓐ will blink fast |
| When S3i is charging | ⓑ will blink slowly |
| When S3i is charged fully | ⓒ stops blinking |

- You can play S3i while charging.

SHAKS S3i 1 2

SHAKS S3i

SHAKS S3i 3 4

SHAKS S3i

SHAKS S3i 5 6

SHAKS S3i

SHAKS S3i 7 8

Product Warranty

Model Name: SHAKS S3i
Product warranty Period: 1 year from the date of purchase
Purchase Date: _____

Phone No. of AKS: +34 960 300 313
Address of AKS: Av. Cors Catalanes, num.2, 08173 Sant Cugat del Valles, Barcelona, Spain

• When repair service is needed, this warranty card, which shows the date of purchase, must be provided.

- The free warranty for this product is covered as described in this product warranty.
- Since the warranty period is calculated from the date of purchase, the purchase date must be stated. The warranty period is calculated based on the purchase receipt or purchase statement. If there is no proof of purchase, the standard for resolving the consumer dispute can be applied based on the production date.
- Quality assurance product range is limited to basic components such as Gamepad S3i. Any damage that occurs under normal use within the warranty period is free of charge, and repair costs must be paid by the customer in the event of failure or damage caused by user's negligence, even if the warranty period has expired or is within the warranty period.
- If you use this home product as a business purpose or means, or use it in an unusual environment, the warranty period will be shortened to 50%.
- This warranty cannot be returned.
- In the case of supply under a separate agreement, the warranty shall be a period in accordance with the main contract.

Europe
E: contact@shaksgame.com
T: +34-960-300-313
© AKS Co., Ltd.
<http://www.aks.co.kr>

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.