


# Manual and specification of the Remote controller




## Basic Specification

1. Working Voltage: DC 24V
2. Working Frequency: 433MHZ
3. Working distance: Within 20 meter
4. Working current: Standby current 10mA, working current 30mA
5. Remote controller batteries: 2\*2016 lithium button batteries, superposed voltage 6V
6. Remote controller current: Standby current 0mA, working current 8mA.

Overview of controller and remote controller:





**How to reset the pairing of the remote controller:**

Press the setting button for 3 second after powering up, when the indicator blinks, the remote controller is reset.

**How to pair the remote controller with the motor:**

1. Press the setting button after power-on, the indicator lights up.
2. Press the up button of the remote controller, and the indicator blinks.
3. Press the down key of the remote controller, and the indicator blinks.
4. Press the stop button of the remote controller, and the indicator blinks.
5. Press the stop key of the remote controller again, after the indicator flashes and then goes out, and the pairing is completed.

**To assure continued FCC compliance:**

**FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE 1:** Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment

## Overview of motor controller



## Overview of remote controller

