USER MANUAL Cooler Box Speaker TR-RTC01 45L



FCC Caution:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance 20cm between the radiator and your body: Use only the supplied antenna.

1. Important information


PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE USING KEEP INSTRUCTIONS FOR FUTURE REFERENCE

IMPORTANT SAFETY INSTRUCTION


Before operating, please read instructions carefully.

- 1. Do not use speaker near water.
- 2. Clean only with a dry cloth. Disconnect power cord from outlet bear cleaning.
- 3. Only use original power cord supplied with the speaker.
- 4. Do not place near heat sources including radiators, ovens, etc.
- 5. Do not use if power cord or speaker has been damaged.
- 6. Do not make any modifications to speaker.
- 7. Carefully arrange power cord so it can not be tripped over or pulled by children.
- 8. Turn off the power when charging the battery.
- 9. Do not overcharge the battery, the standard charging time is a maximum of 9 hrs, overcharging may shorten the battery life.
- 10. Do not immerse the cooler in water when cleaning, electronic parts will get damaged.

2. Package




3. Button Definitions



- 1) PREV/VOL- : Previous Song(tap button once)/Volume down (hold button down).
- 2) NEXT/VOL+: Skip Song(tap button once)/Volume up(hold button down).
- 3) PLAY/PAUSE: PLAY or PAUSE Song(tap button once) /Power ON or Power OFF(hold button down).

4. Interface Description



1) Power cord (DC 5V 1A input)
Charging instructions:

	Insert power cord to charge.	
Charging	LED2 Red light indicates that unit is charging.	
	LED2 Red light turns off when fully charged.	
	Do not charge for more than 9 hours.	
	Unplug power cord once charging is complete.	
Play time	More than 3 hours at 80% volume.	

5. BT Mode Operation

- 1) Turn on the power, the product enters BT status automatically.
- 2) Enter Bluetooth Pairing Mode on your device. Select 'TR-RTC01' from the device list. The speaker will audibly ping once Bluetooth connection has been successful. The Speaker will then be stored in your Bluetooth 'Device List' for future pairing.



6. Specification

Function	Specification
Bluetooth Version	5.0
Distance	6.0M at Max
Frequency Range	2.4GHz-2.48GHz
Battery	Built-in Rechargeable Li-ion Battery
Play time	more than 3hrs at 80% volume
RMS	10W+10W
Driver Impedance	4Ω
Frequency Response	90Hz-20KHz
BT Output Power	0dBm
Capacity	45L
Material	HDPE, PS, PP, PU foam
Speaker Working Environment Temperature	0 °C ~40 °C