


M8

Instruction Manual Bluetooth Speaker

A. Key definition



1. **⏮/—** : Short press to select the previous music, Long Press to decrease the volume.

Under the Time and Alarm clock mode, short Press to select 12 hour format /24 hour format.

Under FM mode, short Press to switch to the previous saved radio station.

2. **+/⏭** : Short Press to select the next music, Long Press to increase the volume.

Under the Time and Alarm mode, Short Press to select 12 hour format /24 hour format.

Under FM mode, short Press to switch to the previous saved radio station.

3. **dimmer** :Short press to switch screen to three brightness (bright, medium, low), Long press to switch mood light to three brightness (bright, low , off).

Note: The brightness of display and mood light remain the same after the top power button switch to restart when the back power switch is on.

4. **⏻** : Power on-off. Long press and hold for 2 seconds to turn off the speaker and display goes out when the power hard key switch is ON, but the Time and Alarm clock are still working. Long press and hold for 5 seconds to reset the speaker.

5. **⌚** (**sleep**): Short press to switch sleep countdown time (switch SOFF, S15, S30 and S60 to sleep in 15, 30 and 60 minutes)

6. **⏸/⏹**: Short press to play or pause music when play music; Short press to answer or hang up it when have a coming call.

7. **MODE**: Short press to select Mode (Long press into the automatic searching under FM mode and long press to set time Under Time mode).

8. **snooze** : Short Press to sleep for 10 minutes again.


9. **🕒** : Short Press to display the Alarm clock 1; Long Press to set Alarm clock 1.

10. **🕒** : Short Press to display the Alarm clock 2; Long Press to set Alarm clock 2.

11. **Mic**: Microphone for Hands-free calling

12. LED Display

B. Input / Output



1. Lithium battery power display

2. DC 5V Power supply

3. Aux input

3.1. Plug Aux cable in the "AUX" interface, another end inserts to the computer or other audio equipment, automatically enter AUX mode, and AUX icon lights but non-flash, or short press M to switch to FM mode from other mode.

3.2 Long press **⏪/-** or **+/⏩** to decrease or increase volume.

4. Power NO/OFF: It automatically enter Time mode after the back power switch is on. The clock and Alarm are still working but the display and mood light are off after top power button switch to off when the back power button is on. All function including Time and Alarm are off after the back power key switch to off.

5. USB input

6. TF Card input

7. Built in Lithium battery 2200mAh

8. Power output: 6Wx2

C. Charging use

Lithium Battery charging: The light is bright in red after the USB cable is inserted for charging, and the red light turns green after the Lithium Battery is charged to full.

D. Time Mode:

Short press **⏪/-** or **+/⏩** to select 12 /24 hour format, long press **MODE** to set Time, then short press **⏪/-** or **+/⏩** to set hour; short press **MODE** and **⏪/-** or **+/⏩** to set minute, then short press **MODE** to complete time setting.

E. Alarm Mode:

1. Short Press **1** enter Alarm clock 1, and short Press **⏪/-** or **+/⏩** to open or close Alarm clock 1. Long press **1** to set Alarm Time, then short press **⏪/-** or **+/⏩** to set hour; short press and **⏪/-** or **+/⏩** to set minute, then short press **1** and **⏪/-** or **+/⏩** to select Alarm ring (bb stands for built-in music; A stand for the saved radio station listen last time), Short press **1** to complete Alarm setting; Alarm bb ring play for 2 minutes, the bell ring alarm icon **1** and real-time flash when alarm work. Short press **1** to sleep more 10 minutes, sustainable 3 cycles, and short press to turn off the alarm when the alarm work.

2. Short Press **2** enter Alarm clock 2, and short Press **⏪/-** or **+/⏩** to open or close Alarm clock 2. Long press **2** to set Alarm Time, then short press **⏪/-** or **+/⏩** to set hour; short press and **⏪/-** or **+/⏩** to set minute, then short press **2** and **⏪/-** or **+/⏩** to select Alarm ring (bb stands for built-in music; A stand for the saved radio station listen last time), Short press **2** to complete Alarm setting; Alarm bb ring play for 2 minutes, the bell ring alarm icon **2** and real-time flash when alarm work. Short press **snooze** to sleep more 10 minutes, sustainable 3 cycles, and short press **2** to turn off the alarm when the alarm work.


F. Bluetooth Mode:

1. Short press to enter Bluetooth Mode, and hear voice "Bluetooth ready to paired".
2. Turn on the Bluetooth function of devices (such as mobile phones, MID, computer), search and select "M8" to pair, and hear voice "Bluetooth Paired", then pairing is successful, and can play music.
3. Continuous prompt "ring, ring..." when has a coming call, short press **⏏** to answer and hang up the phone after finish phone call.
4. Disconnect Bluetooth, hear voice "Bluetooth ready to pair", and Bluetooth icon flash fast under Bluetooth mode.
5. Enter Bluetooth mode, if no Bluetooth device to connect in 3 minutes, automatically switch to Time mode.

G. FM Mode:

Short press **MODE** to enter FM Mode, FM icon lights but non-flash. Long press **MODE** to automatically search and save the radio station in FM mode.

1. Short press **⏪/—** to switch to the previous saved radio station, long press **⏪/—** to decrease the volume.
2. Short press **+/⏩** to switch to the next saved radio station, long press **+/⏩** to increase the volume.



H. MP3 Mode:

1. Insert TF card or U disk in any mode, then play music automatically. Short press **⏪/—** or **+/⏩** to switch to previous or next song, long press **⏪/—** or **+/⏩** to decrease or increase the volume.
2. If no song in the TF card or U disk, display NO d.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.