


AP7633-USB


User manual

Setting for first use


- Goto internet setting
- Goto change interface card setting



Find  ASIX AX88179A USB 3.2 Gen1 to Gigabit Ethernet Adapter




Into “content” setting




- Into TCP/IP setting



- Use static IP address
192.168.1.2~255
- Mask: 255.255.255.0



- Use internet browser and goto address “192.168.1.1” into main setting page
- For first use, just press “Login”



- Main setting page

OpenWrt Status ▾ System ▾ Network ▾ Logout REFRESHING

No password set!
There is no password set on this router. Please configure a root password to protect the web interface.

Status

System

Hostname	OpenWrt
Model	AsiaRF AP7621-003
Architecture	MediaTek MT7621 ver:1 eco:3
Target Platform	ramips/mt7621
Firmware Version	OpenWrt 22.03-SNAPSHOT r19204-dfb6e95af / LuCI openwrt-22.03 branch git-22.083.69105-af8e91c
Kernel Version	5.10.108
Local Time	2022-03-30 16:06:15
Uptime	0h 17m 23s
Load Average	0.22, 0.08, 0.07

Memory

Total Available	55.96 MiB / 117.29 MiB (47%)
Used	45.56 MiB / 117.29 MiB (38%)
Buffered	52.00 KiB / 117.29 MiB (0%)

- Press “network”, then “Wireless”

The screenshot shows the OpenWrt web interface. At the top, there is a navigation bar with links for "OpenWrt", "Status", "System", "Network", and "Logout". A red circle labeled "1" highlights the "Network" link. Below the navigation bar, a yellow banner on the left says "No password set!" and "There is no password set on this router. Please set a password to protect the web interface." On the right, there is a sidebar with several options: "Interfaces", "Wireless" (which is highlighted with a red circle labeled "2"), "Routing", "DHCP and DNS", "Diagnostics", "Firewall", "MultiWAN Manager", and "QoS". The main content area displays system information in a table format:

Hostname	openwrt-22.03
Model	MediaTek MT7621 rev:1
Architecture	MediaTek MT7621 ver:1 eco:3
Target Platform	ramips/mt7621
Firmware Version	OpenWrt 22.03-SNAPSHOT r19204-dfba6e95af / LuCI openwrt-22.03 branch git-22.083.69105-af8e91c
Kernel Version	5.10.108
Local Time	2022-03-30 16:11:50
Uptime	0h 22m 57s
Load Average	0.42, 0.23, 0.13

No password set!

There is no password set on this router. Please configure a root password to protect the web interface.

- Choose this item “MediaTek MT76x2E device, then press “Scan”
- If it takes a lot of time to scan, you can press “Restart” to restart AP7633-USB device and scan again.

Wireless Overview

 radio0	MediaTek MT76x2E 802.11nac Channel: 36 (5.180 GHz) Bitrate: ? Mbit/s	Restart Scan Add
 --- dBm	SSID: OpenWrt Mode: Master BSSID: 2E:9F:BE:E5:78:9E Encryption: None	Disable Edit Remove

Associated Stations

Network	MAC address	Host	Signal / Noise	RX Rate / TX Rate
<i>No information available</i>				

[Save & Apply](#) [Save](#) [Reset](#)

- Choose one available AP, then press “Join Network”

Join Network: Wireless Scan					
Signal	SSID	Channel	Mode	BSSID	Encryption
-49 dBm		36	Master	18:31:BF:5C:0B:1C	WPA2 PSK (CCMP)
-59 dBm		2	Master	18:31:BF:5C:0B:19	mixed WPA/WPA2 PSK (CCMP)
-62 dBm		2	Master	18:31:BF:5C:0B:18	WPA2 PSK (CCMP)
-68 dBm		8	Master	D0:17:C2:64:EA:D0	WPA2 PSK (CCMP)
-76 dBm		36	Master	02:00:43:36:46:D8	None
-77 dBm		1	Master	7C:A2:3E:A6:97:08	mixed WPA/WPA2 PSK (TKIP, CCMP)
-77 dBm		36	Master	02:0A:52:19:13:74	None
-78 dBm		1	Master	00:0A:52:08:B6:3C	None
-80 dBm		1	Master	74:DA:38:F1:E8:20	WPA2 PSK (CCMP)
-91 dBm		1	Master	14:4D:67:0A:3D:BC	None

[Stop refresh](#) [Dismiss](#)

- Fill in the password for the chosen AP, then press “Submit”

Joining Network:

Replace wireless configuration

Check this option to delete the existing networks from this radio.

Name of the new network 1

The allowed characters are: A-Z, a-z, 0-9 and _

WPA passphrase * ? Specify the secret encryption key here.

Lock to BSSID

Instead of joining any network with a matching SSID, only connect to the BSSID 18:31:BF:5C:0B:1c.

Create / Assign firewall-zone wan wan: wan6: wwan: (empty) ▾ 2

Choose the firewall zone you want to assign to this interface. Select *unspecified* to remove the interface from the associated zone or fill out the *custom* field to define a new zone.

Cancel Submit

Wireless Network: Client " (radio0.network2)

Device Configuration

General Setup Advanced Settings

Status Mode: Client | SSID: AsiaRF_5G
--- dBm Wireless is not associated

Wireless network is enabled **Disable**

Operating frequency Mode Channel Width
AC 36 (5180 Mhz) 80 MHz

Maximum transmit power driver default - Current power: unknown
Specifies the maximum transmit power the wireless radio may use. Depending on regulatory requirements and wireless usage, the actual transmit power may be reduced by the driver.

- Press “Save”

Interface Configuration

General Setup Wireless Security Advanced Settings

Mode Client

ESSID

BSSID

Network wwan:

Choose the network(s) you want to attach to this wireless interface or fill out the custom field to define a new network.

Dismiss Save

- Press “Save & Apply”, then the chosen AP will be shown up on the bottom of this page

OpenWrt Status ▾ System ▾ Network ▾ Logout REFRESHING

No password set!
There is no password set on this router. Please configure a root password to protect the web interface.

Wireless Overview

	MediaTek MT76x2E 802.11nac Channel: 36 (5.180 GHz) Bitrate: 13 Mbit/s	Restart	Scan	Add
	SSID: OpenWrt Mode: Master BSSID: DA:81:EE:2D:FD:56 Encryption: None	Disable	Edit	Remove
	SSID: AsiaRF_5G Mode: Client BSSID: D8:81:EE:2D:FD:56 Encryption: -	Disable	Edit	Remove


Associated Stations

Network	MAC address	Host	Signal / Noise	RX Rate / TX Rate
2	18:31:BF:5C:0B:1C	?	-50 dBm	6.5 Mbit/s, 20 MHz, VHT-MCS 0, VHT-NSS 1 7.2 Mbit/s, 20 MHz, VHT-MCS 0, VHT-NSS 1, Short GI
Client (wlan0)				

1 [Save & Apply](#) [Save](#) [Reset](#)

Change user's name and password

- Into
“System”, “Administration”
item



- Set new password, then “Save”

OpenWrt Status ▾ System ▾ Network ▾ Logout

No password set!
There is no password set on this router. Please configure a root password to protect the web interface.

Router Password SSH Access SSH-Keys HTTP(S) Access

Router Password

Changes the administrator password for accessing the device

Password *


Confirmation  *

? Password strength: Weak





- Quit and re-into “192.168.1.1” setting page, you will need fill in the new password.



Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device must accept any interference received, including interference that may cause undesired operation. Product that is a radio transmitter is labeled with FCC ID.

Industry Canada Statement

This device complies with Industry Canada licence-exempt RSS standard.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limit set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0.5cm between the radiator and your body.

Cet équipement est conforme aux CNR-102 d'Industrie Canada. Cet équipement doit être installé et utilisé avec une distance minimale de 20 centimètres entre le radiateur et votre corps. Cet émetteur ne doit pas être co-localisé ou opérant en conjonction avec autre antenne ou émetteur. Les antennes utilisées pour cet émetteur doivent être installés et fournir une distance de séparation d'au moins 20 centimètre de toute personne et doit pas être co-située ni fonctionner en conjonction avec une autre antenne ou émetteur.