


## Adaptor Transmitter TL-4015A

### Description:

TL-4015A adaptor transmitter is an accessory to the TL-4015 that can send the messages of TL-4015 to the TL-4016P.



### Installation:

- Turn off the power of the TL-4015 before installation;
- Insert the 3.5mm plug of the device into the BPTX interface of the TL-4015;
- Pass the supplied M3 screw through the mounting hole, tighten the screw and fix it on the TL-4015;
- After the installation is complete, you can turn on the TL-4015 power supply.

### Operation:

When the TL-4015 is alerting, it will trigger the TL-4015A to send the alarm content periodically. When sending, the LED will flash and the TL-4016P will receive the alarm message.

### Technical Specifications

Input Voltage: 12VDC

Maximum Rating: 30mA

Operating Frequency: 433.92 MHz

Operational Temperature: 0°C – 60°C

Humidity: 5% – 95%

FCC Statement

FCC ID : 2AROFTL-4015A

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Use and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Interference to radio or television reception, which can be determined by turning

The equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.