# TECNOCK



# >>> INSTRUCTION MANUAL



SAVE THESE INSTRUCTIONS. READ COMPLETE INSTRUCTIONS BEFORE USE.

#### 1. How to bind


- 1. Turn on the vehicle first, then turn on the transmitter
- 2. Keep pulling the trigger of the transmitter to match the vehicle.
- 3. When the vehicle is functioning, that means they are matched.
- 4.If it doesn't complete the binding process within 8 seconds, please turn off both the vehicle and transmitter and re-start the binding process.
- 5. When the binding process is complete, whenever you switch the vehicle and transmitter on and off, it searches for the memorised code and will only lock onto the transmitter signal containing that code.
- 6.If you have more than two vehicles, please bind them one by one. When the second vehicle is binding, always keep the first vehicle and transmitter on.
- 7. Please turn off both the vehicle and transmitter and re-start the binding process if you are changing to another 2.4GHZ transmitter.

# 2. How to play

1. Switch ON the vehicle and transmitter.











3.Use the accelerator trigger to drive the vehicle forwards, stop, or backwards







- 4. Play on a smooth surface for optimum performance
- 5. Remember to switch OFF the power of the Vehicle and Transmitter after playing
- 6. The optimum control range is up to 30 metres outdoors

#### **Disposal of batteries**



Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold. You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances: Pb=Battery contains lead Cd=Battery contains cadmium Hg=Battery contains mercury

# 3. Battery installation

### 3.1 For below items





NO.S9601B





















NO.S9602B NO.QY1801D NO.QY9604C NO.QY9604B

# 3.2 Battery included (For NI-CD or NI-MH Battery)

NO.S9602A

# Contents -RC Vehicle x 1 -RC Transmitter x 1 -Instruction Manual x 1 -3.6V rechargeable Battery Pack x 1 -USB Charger cable x 1





Charging time: 3.5-4.5 Hous Playing time:20-30 minutes













Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct

pursuant to part 15 of the FCC Rules. These limits are

the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.

-Consult the dealer or an experienced radio/TV technician for help

Reorient or relocate the receiving antenna

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# the battery is full SAFETY PRECAUTIONS

Do not mix old and new batteries.

Do not mix alkaline, standard(carbon-zinc), or rechargeable (nickel—cadmium)batteries.

Insert batteries using the correct polarity. Do not short-circuit the supply terminal.

Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state. And local laws. Do not dispose of batteries in afire-they may leak or explode.

Only use manufacture specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.

Always use, replace, and recharge(if applicable)batteries under adult supervision.

Non-rechargeable batteries are not to be recharged:

Rechargeable batteries are to be removed from the for before being charged;

Rechargeable batteries are only lo be charged under adult supervision;

Exhausted batteries are to be removed from the toy;

The supply terminals are not to be short-circuited.

Packaging has lo be kept since it contains important information.

Product may vary slightly from image shown

Performance Tips: Do not drive the vehicle on grass, sand rocks or go through water.

Do not drive the vehicle into any hard object.

# **Cautions**

- 1. Do not drive on grass, dirt, sand, dusts, carpet or through water
- 2. Do not drive in windy or rainy weather
- 3. Avoid the vehicle directly impacting with obstacles
- 4. Switch OFF the power when not in use lo prevent damage to the vehicle or transmitter due to leakage of electrolytes from batteries
- 5. Remove all batteries from the vehicle and transmitter when not in use for a long period of time.
- 6. Keep fingers, hair and loose clothing away from the wheels
- 7. The operating range can be affected by a variety of factors:
- a) Low Voltage of batteries in the transmitter or vehicle
- b) Interference from other items that emit radio frequency signals
- 8. Outdoor usage is recommended in order to get optimum control range
- 9. It is recommended to play with the vehicle on a clean and smooth surface
- 10. Clean the battery compartment to make sure it is free from dust to prevent poor