# Wireless Monster Speaker User Manual



- 1. Speaker 3. Microphone
- 2. LED indicator 4. ON/OFF button
- 5. Strap Hole
- 4. ON/OFF button
  6. Micro USB socket

#### Charging the Battery:

- 1. Insert the charging Cable into the Micro USB input port. Connect the USB plug into DC 5V USB port. The Charging LED indicator will turn on.
- After Charging is complete, the LED indicator will turn off.
   Noted: when music sound volume decreases and you hear
   warning tone, please charge the speaker.
   Bluetooth pairing for music/phone call/camera remote
   shutter:
- 1. Turn on the speaker by pressing "0" button for 3 seconds.
- 2. Turn on your Bluetooth device and activate the Bluetooth

- 3. Search for Bluetooth pairing name: Amor-AHA (Green) / Lee-AHA (Blue) and click to pair. The speaker will pair automatically and the blue indicator light will turn on. Press "O" button to answer the call when a call is coming in or take a photo when the camera is open on your device.
- 4. Turn off the speaker by pressing the "O" button for 4 seconds.

**Note:** 1. If you can't take a photo, if using an Android, please open "Settings" — "Camera" then set "Volume Key" to "Shutter", if using IOS, you just need to refresh the Bluetooth connection.

- 2. If you can't play music, please reconnect the Bluetooth connection.
- 3. Self-Timer function is not compliant with all mobile phones.

## Pairing 2 speakers

- 1. Make sure no speakers are connected to your device.
- 2. Power on 2 speakers (at the same time).
- 3. Double Click "O" button on the 2nd speaker. You should hear a chirp sound, then the other speaker should make a short connect sound. (If you do not hear a connect sound, double click the opposite speaker "O" button.
- 4. In your device Bluetooth menu, locate & Select the pairing name: Amor-AHA (Green) / Lee-AHA (Blue) and click to pair. You will now be connected to both speakers

## Specification:

Frequency Response	20HZ-20KHZ
THD	≤ 1%
S/N	≥ 80 DB
Bluetooth Version	Bluetooth V5.0
Product Size	41.5*45mm
Product Weight	40g

## **Safety Information**

- a. Battery Shall not be exposed to excessive heat such as sunshine, fire or the like.
- b. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
   c. No open flame sources, such as lighted candles, should be placed near the speaker.
- d. Attention should be drawn to the environmental aspects of the battery disposal.
- e. The use of the speaker in moderate climates.
   f. Do not use the speaker on airplanes
  - g. Do not use the speaker on airpianes g. Do not attempt to modify or disassemble speaker.

### Thank you for your purchase.

PCC Discourse.

15 of the PCC Billet. These letters are disspared to period the control protection against familiar protection against familiar protection. The period to the period to

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this explainment.

This device complex with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and CI) this device must accept any interference received, including institrement with may cause device the must accept any interference received, including institrement with may cause the made and explainment of the manufacture operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.