




## SPECIFICATIONS


Bluetooth Range: Up to 33 Feet (10 Meters)  
 Charging Input: DC 5V  
 Battery Type: 3.7V Lithium Ion Battery  
 Charge Time: Approximately 2 Hours

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.

## A QUICK LOOK



## CHARGING



1. Insert the included cable's Micro USB plug into the charging port on the headphones.




2. Insert the standard USB plug into the USB port of a computer or suitable USB charging adapter.

● (red) = Charging

● (blue) = Charging Complete

3. The LED Indicator will turn red while the headphones are charging and turn blue when charging is complete.


## BLUETOOTH PAIRING



1. Press and hold the Power button for 3-4 seconds to turn the headphones On/Off.

**Pairing Mode**  
 Rapid Flashing Blue

2. The LED Indicator will turn blue and flash rapidly when the headphones are in pairing mode.




3. Go to the Bluetooth settings menu on your phone. Turn Bluetooth on and connect to "Wireless Headphone".


**Paired**  
 Blue

4. The LED Indicator will stop flashing and remain blue when the headphones are paired with your phone.


## USING YOUR HEADPHONES




1. Press the Play button to play and pause a track.



2. Press the Vol. Increase/Next track button to go to the next song. Press and hold the button to increase the volume.



3. Press the Decrease Vol./Previous Track button to go back to the previous track. Press and hold to decrease the volume.



4. Press the Play/Pause Button to Answer an incoming call. Press the button again to end the call. Press and hold the button to decline an incoming call.

## IMPORTANT SAFETY PRECAUTIONS

1. READ ALL INSTRUCTIONS BEFORE USING YOUR HEADPHONES.
2. Do not use your headphones near water. Do not place your headphones on any wet surfaces.
3. Do not allow children to use the headphones without adult supervision.
4. Do not expose your headphones to excessive heat, flames or fire.
5. Always press all buttons carefully.
6. Do not use in extremely dry environments, as this can lead to static discharge during usage.
7. Do not expose your headphones to temperatures above 104°/ 40°C. Keep out of direct sunlight.
8. Do not attempt to repair this product yourself. Contact a qualified service center if your headphones are in need of service.
9. Do not drop, puncture or expose your headphones to excessive trauma.
10. Your headphones are not intended for commercial use.
11. Use only the supplied charging cable. Unplug this device when not in use for long periods of time.
12. Use a soft cloth to clean your headphones. Never use any harsh chemicals or detergents.
13. Please recycle or dispose of your headphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your headphones for further information.

## OTHER CONTROLS



Press the mode button to change the headphones mode to Bluetooth or FM Radio.

In FM mode, press the volume buttons to change channels. Press and hold the buttons to adjust the headphone's volume.

Insert an auxiliary cable (not included) directly to the aux port on your headphones to go directly to AUX mode, where you can listen to music from an attached audio device.

## VIVITAR ONE YEAR WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

### What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

### To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at [www.vivitar.com](http://www.vivitar.com).

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

## FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.