

aiwa

## OWS TWS Earphones with charging case




- 20 hours Playtime  
Up to 5 hours initial charge plus 3 extra charges in case
- Touch Controls
- Carry Cord Included
- Pocket Sized




Item: AI1107

Quick Start Guide

## WHAT'S INCLUDED




## A CLOSER LOOK



## CHARGING

### Charging the Case




### Charging the Earphones

Place the earphones in the charging case to charge. Make sure the charging contacts on the earphones make contact with the charging contacts in the case. While charging, the indicator light on each earphone will turn red. When fully charged the indicator lights will turn OFF.

Charging can take approximately 1-2 hours.

## POWERING ON/OFF

When first using your earphones, place them into the case. To turn the earphones ON, remove them from the case. To turn the earphones OFF, put them back into the case.



aiwa


CONTACT US  
1-800-592-9541  
www.aiwa.us.com

AIWA  
Edison, NJ 08817


© 2025 Aiwa Acquisitions LLC. All rights reserved. AIWA and associated marks are owned by Aiwa Acquisitions and used under license. Keep all relevant information for future reference.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International, is under license.


## BLUETOOTH PAIRING



Once powered on, your earphones will go into pairing mode. The LED Indicator will alternately flash blue and red for both earphones.




After successful pairing, the LED indicator light on one earphone will turn OFF, and the indicator light of the other will continue blinking.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "AIWA OWS"

NOTE: After five minutes without pairing to a Bluetooth device, the earphones will automatically turn OFF.

## USING YOUR EARPHONES



### RIGHT EARPHONE

Play/Pause: Press and Hold for 2 seconds  
Next Track: Double Press  
Increase Volume: Press  
Answer Call: Press  
Reject Call: Double Press  
End Call: Press and Hold for 2 seconds  
Low Latency ON/OFF: Triple Press

### MONO MODE

While only one earphone is active and paired, it has the following limited functionality:

Decrease Volume: Press  
Increase Volume: Double Press  
Voice Assistant: Press and hold for 2 seconds.



Warning

To prevent possible hearing damage, do not listen at high volume levels for long periods. For your own safety, please be aware of your surroundings when using these earphones.

## RESET

To reset your earphones and return them to original default factory settings, make sure that Bluetooth on your phone is turned off, and then insert the earphones into the charging case. Remove one earphone from the charging case and press the touch button four times to turn off. Place back into the charging case and repeat for the second earphone.

## MAINTENANCE AND CARE

-Use a soft cloth or paper towel to clean your earphones and charging case. Never use any harsh chemicals or detergents for cleaning. Make sure your earphones and charging case are dry before charging.

-When unused, your earphones and charging case should be stored in a cool, dry place.


-Never tug or yank on a cable connected to your charging case. Connect and disconnect cables as carefully as possible.

-Never expose your earphones and charging case to high temperatures or extreme cold.

## SAFETY PRECAUTIONS

When using your earphones, basic safety precautions should always be followed, including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARPHONES.
2. Never expose your earphones to high temperatures, extreme cold, high humidity, moisture, or water.
3. To avoid the risk of electric shock, never attempt to open or repair your earphones without the assistance of certified professionals.
4. Your earphones are not to be used by children or the infirm without suitable adult supervision.
5. Always press all buttons carefully. Do not manhandle your earphones.
6. Do not use your earphones at temperatures under 32°F (0°C) or over 104°F (40°C).
7. Do not drop your earphones, throw them, or subject them to strong impacts or physical trauma.
8. Contact the manufacturer for support if you detect any abnormalities when using your earphones. In addition, do not continue to use your earphones if you detect any smoke or fire.
9. Unplug your earphones when not in use for extended periods of time.
10. When plugged in, do not place your earphones on flammable materials such as rugs, carpets, or bedding.
11. Please recycle or dispose of your earphones properly according to your municipality's laws and rules. Contact local recycling facilities and/or the manufacturer for further information.
12. Clean your earphones and charging case using a soft cloth or paper towel. Do not use harsh chemicals when cleaning your earphones, and never submerge your earphones in water.



## FCC STATEMENT

### FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
—Reorient or relocate the receiving antenna.  
—Increase the separation between the equipment and receiver.  
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

## SPECIFICATIONS

TOTAL PLAY TIME: UP TO 20 HOURS\*

CHARGES: 3 CHARGES

PLAY TIME PER CHARGE: 5 HOURS\*

\*Applicable at 50% of maximum volume. Results will be lower when volume is higher.

## WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What is Not Covered By Warranty  
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including, but not limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:  
Call 1-800-592-9541 or visit our website at [www.aiwa.us.com](http://www.aiwa.us.com)

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepai