







## JTS Securebook 5.0 Quick Start Guide

This guide covers operation of the Securebook 5.0 hardware only.

### Ports and Connectivity:

The Securebook by itself has no I/O ports for content to go on or off of the device. The Securebook connects to a docking station (the Securedock) in order to provide access to USB ports, HDMI, Ethernet, or WiFi (optional), which are included only in the Securedock.

<p><b>LEFT</b></p> 	<p><b>Left Side View:</b></p> <ol style="list-style-type: none"> <li>1. Kensington Cable Lock</li> <li>2. Power Input</li> <li>3. Headphone Jack</li> </ol>	<p><b>RIGHT</b></p> 
<p><b>TOP</b></p> 	<p><b>Top View:</b></p> <ol style="list-style-type: none"> <li>1. Power Key (Press and Hold)</li> <li>2. Status Light</li> </ol>	<p><b>BOTTOM</b></p> 

### Left Side View:

1. Kensington Cable Lock
2. Power Input
3. Headphone Jack

### Right Side View:

1. Fingerprint Reader (Windows Only)
2. Kensington Cable Lock (2<sup>nd</sup>)

### Top View:

1. Power Key (Press and Hold)
2. Status Light

### Bottom View:




1. Female Docking Port
2. Security Screws

### BIOS Administration:

The Securebook has a number of BIOS options to keep the device secure. By default, a password has been set on BIOS. For most secure deployments, BIOS is accessed with a USB unlock key. Press Fn + F12 keys at American Megatrends boot screen to enter BIOS.

### Pairing with Securedock (Sold Separately):

The Securedock is a docking station designed to add USB, HDMI, Ethernet, or WiFi (optional) connectivity ports to your Securebook for short periods of time. This is valuable for managing the device. By putting all of the connectivity ports on a separate piece of hardware (the Securedock), the Securebook cannot be abused by residents who wish to transfer content or access a network while in their living units unsupervised. Any Securebook works with any Securedock. Do not provide access to a Securebook and Securedock simultaneously unless supervised by admin.

<p><b>JTS-SD50W TOP</b></p>  <p><b>BACK</b></p> 	<p><b>Securedock:</b></p> <ol style="list-style-type: none"> <li>1. Male Docking Port</li> <li>2. Mounting Screw Bracket</li> <li>3. Dock Power Port</li> <li>4. HDMI Output</li> <li>5. 2x USB Ports</li> <li>6. Ethernet Adapter</li> <li>7. Optional WiFi Inside Dock</li> <li>8. Kensington Port Lock</li> </ol>
<p><b>DOCKED</b></p> 	<p><b>IMPORTANT:</b></p> <p>Do not provide access to a Securebook and Securedock simultaneously unless supervised by admin.</p> <p>When provided access to a Securedock, the computer can have unrestricted access to USB and network ports.</p>

### Important Note:

This guide does not cover the operation of software on the Securebook. The Securebook is compatible with a variety of operating systems, including Windows, Ubuntu Linux, Chrome (via CloudReady), and Endless OS for Corrections.

**Contact Us:** [www.justicetechsolutions.com](http://www.justicetechsolutions.com) / phone: (310) 988 9600

# FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference..

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC RF Exposure Information and Statement**

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Securebook 5.0 (FCC ID: 2AS4KJTS-SD50W) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use properly worn on the body is 0.592W/kg. This device was tested for typical body-worn operations with the back of the handset kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

## **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.